

封面 (74.25mm)

封面 (105mm)

420mm

User's Guide P3100D

Thank you for choosing our products! Please read this instruction carefully before using this product and keep it properly.

Contents

- 01 Packaging List
- 02 Product Specifications
- 03 Parts Description
- 04 Guidance on Switching on the Power Supply
- 05 App Download Method
- 06 Installation of Label Tape
- 07 Printer Connection
- 08 Print Head Cleaning
- 09 Instruction for Replacing Cutter Holder
- 10 FCC Caution
- 11 Solutions for Common Problems
- 12 After-sale Support

01. Packaging List

- Label maker*1
- User's guide*1
- Label tape*1
- Replacement cutter holder*1

02. Product Specifications

Product name	Portable label maker
Product model	P3100D
Version	Alkaline battery version
Printing technology	Thermal transfer printing
Width for label tape	6mm, 9mm, 12mm
Type for supported label tape	Continuous label and can be cut in different lengths
Printing density	180 dpi
Print head service life	50,000
Communication interface	Bluetooth 4.2
Product size	145*143*27mm (5.72*5.63*2.2inch)
Input power	9V-2A
Power supply mode	Alkaline battery
Supported operating system	Android iOS

03. Parts Description Appearance

03. Parts Description Power Button and Indicator Light

NOTE

- Please ensure that the label printer is powered on before installing the label tape.
- Long press the power button 3 seconds to turn on.
- Open the label tape compartment cover by pulling the open button outward as indicated.

Power button description

Button	Operation method	Functions
Power button	Long press for 3 seconds	Turn on/off
Power button	Double click	Print the self-checking label

Indicator light

Indicator light	State	Description
Blue light	Light is frequently on	Normal status
Orange light	Flashing quickly	Please check whether the label tape is installed properly.
Orange light	Flashing slowly	Battery power is less than 10%.
Orange light	Flashing quickly	Battery power is less than 5% and cannot support printing.
Blue light	Light is frequently on	Connected to USB or Bluetooth
Blue light	Flashing slowly	No device is connected

04. Guidance on Switching on the Power Supply

NOTE

- This label maker is powered by adapter or AAA alkaline batteries, but does not support charging.
- This label maker is NOT equipped with batteries. You need to purchase 6 standard AAA alkaline batteries, or it may have a shorter printing time and worse printing effect.
- This product is NOT equipped with an adapter. It is recommended to purchase a 9V2A adapter that complies with CE/FCC certification.
- If installed the AAA batteries and insert the adapter at the same time, the battery power will not be consumed. After installing the adapter, it will automatically switch to the battery power supply.
- After printing, please remove the AAA batteries to prevent this label maker can not be used normally because of the alkaline battery's corrosion.
- If the battery power is low, kindly replace all six batteries at the same time.

Method I: Power on with AAA alkaline battery

- When install the batteries, put the black cloth strip to the opposite side first, then install the batteries on the positive and negative pole respectively to specify remove batteries after printing. Please make sure the battery poles point in the correct direction, or label maker can not be powered.
- Turn on the power button.

Method II: Power on with the adapter

- Use the battery compartment cover.
- Insert the adapter into the battery compartment.

NOTE

- This product requires the mobile phone or tablet PC to turn on Bluetooth and connect with the label maker in the App.
- Start the requirements of the Android system, if necessary to open the location permission when using the App.

Method III: Search "phomemo" and download the phomemo App.

06. Installation for Label Tape

NOTE

- Please ensure that the label printer is powered on before installing the label tape.
- Long press the power button 3 seconds to turn on.
- Open the label tape compartment cover by pulling the open button outward as indicated.
- Make sure the end of tape passes through both tape guides.
- Insert the label tape into the label tape unit until it is fully inserted.
- When you notice the carbon fiber wheel is turning, turn the label tape unit right to avoid damage.
- Install the label tape correctly as indicated, and make sure that the bonded tape is through the tape exit slot of label maker.

07. Printer Connection

Turn on the Bluetooth for your device and open the phomemo App.

Click the Bluetooth icon on the top right corner to search the device.

NOTE

- For more information, please check the "Profile"/"Use Tutorial" in the App.
- App functions will be updated new functions in irregular. Please refer to the actual functions.

08. Print Head Cleaning

Use a cotton swab dipped in a small amount of alcohol.

Wipe the print head gently.

Wait 30 seconds for the alcohol to dry and double-click the power button to print the self-checking page.

NOTE

- The print head needs to be cleaned when printing is not clear.
- Do not scratch the print head with a hard object, otherwise the print head will be damaged and the printing effect will not be guaranteed.

09. Instruction for Replacing Cutter Holder

NOTE

- The label tape cannot be cut neatly after continuous use, please replace the cutter holder as shown in the following diagram.

10. FCC Caution

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference from any licensed operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or a qualified radio/TV technician for help.

The device has been evaluated to meet general IF without requirement. The device can be used in portable exposure condition without restriction.

11. Solutions for Common Problems

Problem	Solution
Unable to be powered on	1. Check whether the positive and negative poles of the battery are installed correctly. 2. Replace with new AAA alkaline batteries. 3. Make sure the adapter is properly connected and powered on.
Cannot print, or fail to print characters normally	1. Check whether the label tape is installed correctly. 2. Check whether the printer back cover is tightly closed. 3. Check whether the label tape has been used up.
A blank or partial label is printed	There may be dust on the print head. Please take out the label tape and gently wipe the print head in a vertical direction with a dry cotton swab. Note: Do not touch the print head with your hand to avoid staining.
When printing, the printer suddenly off	1. The AAA alkaline batteries may have low power, please replace them with new batteries. 2. Please check the label adapter specification and confirm whether it is 9V/2A.
The printer fails to feed the label tape correctly	1. Please check whether the end of tape has passed through the two tape guides. 2. It may be caused by preventing the cutter key during printing. DO NOT cut the label tape during printing.
Unable to print via mobile phone	Please check and confirm that Bluetooth has been turned on on your mobile phone and the label printer has been connected in the App.

12. After-sale Support Product Warranty

Thank you for choosing our portable label maker.

(1) We will provide our customers with reliable "replacement/return" support during the one-year warranty period from the date of purchase.

(2) Please keep the product manual and warranty card in a safe place so that you can read it when needed.

+855 957 5312195 (only)
Service time: Mon-Fri 9AM-5PM (US EST)
support@phomemo.com
www.phomemo.com

For more detailed information, please check the official website: www.phomemo.com

12. After-sale Support Warranty

Repair Return

Name: _____ Gender: _____
Phone: _____
Address: _____
Date of purchase: _____
Product order number: _____
Product serial number: _____
Fault description: _____

Reason for Return:
Repair / Replace / Renewal (Maintenance)

Produkthandbuch P3100D

Vielen Dank für die Auswahl unserer Produkte! Bitte lesen Sie dieses Handbuch sorgfältig durch, bevor Sie dieses Produkt verwenden.

Katalog

- 01 Auspackenliste
- 02 Produktspezifikationen
- 03 Maschinenschreibung
- 04 Anleitung zum Einschalten
- 05 App-Herunterladen
- 06 Montage des Farbbandes
- 07 Druckeranbindung
- 08 Kopfreinigung Drucken
- 09 Anweisung zum Auswechseln des Messerhalters
- 10 Fehlerbehebung
- 11 Kundendienst
- 12 Garantie

01. Auspackenliste

- Drucker*1
- Produktanhandbuch*1
- Farbband*1
- Ersatzmesserhalter*1

02. Produktspezifikationen

Name	Tragbarer Etikettendrucker
Modell	P3100D
Version	Trockenbatterien-Version
Drucktechnik	Thermotransferdruck
Kennzeichnung Breite	6mm, 9mm, 12mm
Unterstützung der Verbandscharakteristika	Endlospapier
Druckauflösung	180 dpi
Kopflebensdauer drucken	50,000
Kommunikationsinterface	Bluetooth 4.2
Produktgröße	145*143*27mm (5,72*5,63*2,2inch)
Stromversorgung	9V-2A
Stromversorgungsmodus	Netzadapter Trockenbatterien Android iOS
Modell	iOS

03. Maschinenschreibung Erscheinungsbild

04. Anleitung zum Einschalten

Achtung

- Dieses Produkt muss an den Drucker in der App angeschlossen werden.
- Aufgrund der Anforderungen des Mobiltelefonsystems verwenden Sie Android-Systeme, falls erforderlich, sind die Standort- und Standortberechtigungen zu aktivieren, Sie müssen die GPS einschalten und die Berechtigung bestätigen.

Method 1: Bitte um den QR-Code zu scannen und die App herunterzuladen.

Method 2: Suche und Herunterladen.

Suche Play / App Store / phomemo

03. Maschinenschreibung Leistung und Indikatorleuchte

Leistungs-Schlüssel Beschreibung

Taste	Operation	Funktion
Waffelhalter	Drücken für 3s	An / Aus
Doppelklick	Doppelklick	Selbstüberprüfung-Seite drucken

Indikatorleuchte Beschreibung

Anzeige	Status	Erklärung
Blau	Blau leuchtet häufig	Normaler Zustand
Orange	Orange leuchtet häufig	Bitte prüfen, ob das Farbband richtig montiert ist.
Orange	Orange leuchtet langsam	Die Schwachstrom-Verbrauch des Druckers übersteigt die Batterieleistung unter 10%.
Orange	Orange leuchtet schnell	Batterieleistung unter 5%, Drucken nicht möglich.
Blau	Blau leuchtet häufig	An USB oder Bluetooth angeschlossen
Blau	Blau leuchtet langsam	Keine angeschlossenen Geräte

04. Anleitung zum Einschalten

Achtung

- Dieses Produkt unterstützt Adapterstrom oder Trockenbatterien, aber es kann nicht aufgeladen werden.
- Dieses Produkt wird standardmäßig nicht mit Batterien geliefert. Bitte kaufen Sie 6 Stück von regulären AAA-Trockenbatterien, oder kaufen Sie ein AAA-USB- oder Bluetooth-Anschlussgerät. Es wird empfohlen, einen 9V-2A-Adapter zu kaufen, der die CE/FCC-Zertifizierung erfüllt.
- Wenn Sie das Produkt verwenden, stellen Sie sicher, dass die Batteriepolen richtig verbunden sind und dass die Batteriepolen richtig verbunden sind.
- Entfernen Sie nach dem Drucken die Trockenelemente, um zu vermeiden, dass die Trockenelemente korrosiv sind und das Produkt nicht mehr richtig funktioniert.
- Es wird empfohlen, beim Auswechseln einer schwachen Batterie die Batterie zu entfernen.

Method 1: Bitte um den QR-Code zu scannen und die App herunterzuladen.

Method 2: Suche und Herunterladen.

Suche Play / App Store / phomemo

06. Montage des Farbbandes

Achtung

- Stellen Sie sicher, dass das Gerät eingeschaltet ist, bevor Sie das Farbband einlegen.
- Bitte lassen Sie das Farbband für mindestens 1 Sekunde lang gediegen.
- Wenn Sie das Farbband einlegen, stellen Sie sicher, dass das Farbband richtig montiert ist.
- Nehmen Sie das Farbband heraus, indem Sie den Druckerhalter drücken.
- Stellen Sie sicher, dass das Farbband richtig montiert ist.
- Wenn Sie das Farbband durch das Farbband einlegen, stellen Sie sicher, dass das Farbband richtig montiert ist.
- Wenn Sie das Farbband durch das Farbband einlegen, stellen Sie sicher, dass das Farbband richtig montiert ist.

07. Druckeranbindung

Suchen Sie "P3100D" und klicken Sie auf "P3100D", um eine Verbindung zum Etikettendrucker herzustellen.

Achtung

- Wählen Sie Bluetooth für die Geräte- und öffnen Sie die phomemo App.
- Klicken Sie auf die Schaltfläche "OK" nach dem Scannen.

08. Kopfreinigung Drucken

Verwenden Sie einen Watson, um in eine kleine Menge Alkohol zu drucken.

Wischen Sie den Druckkopf sanft ab.

Achtung

- Der Druckkopf muss gründlich gereinigt werden, wenn der Druck nicht klar ist.
- Bitte verwenden Sie keine harten Objekte, um den Druckkopf zu reinigen, andernfalls wird der Druckkopf beschädigt, der den Druckeffekt nicht garantieren kann.

09. Anweisung zum Auswechseln des Messerhalters

Achtung

- Wenn Sie das Farbband nach ständigem Gebrauch nicht mehr sauber schneiden können, tauschen Sie bitte den Messerhalter wie unten gezeigt aus.

10. Fehlerbehebung

Probleme	Lösungen
Das Gerät kann nicht eingeschaltet werden	1. Prüfen Sie, ob die Plus- und Minuspole der Batterie richtig angeschlossen sind. 2. Ersetzen Sie die vorhandenen Trockenbatterien durch neue Trockenbatterien. 3. Stellen Sie sicher, dass der Adapter richtig angeschlossen und eingeschaltet ist.
Cannot print, or fail to print characters normally	1. Prüfen Sie, ob die Farbbandkassette richtig eingelegt ist. 2. Prüfen Sie, ob den hinteren Deckel des Druckers fest geschlossen ist. 3. Prüfen Sie, ob das Farbband verbraucht ist.
Leere horizontale Linien erscheinen auf gedruckten Etiketten	Der Druckkopf kann verschmutzt sein. Bitte reinigen Sie den Druckkopf vorsichtig mit einem weichen Watson in vertikaler Richtung. Achtung: Berühren Sie den Druckkopf nicht mit den Fingern, da dies zu Verletzungen führen kann.
Die Druckeinstellungen haben sich geändert	2. Prüfen Sie, ob das Farbband richtig montiert ist. 3. Prüfen Sie, ob das Farbband verbraucht ist.
Der Drucker transportiert das Farbband nicht richtig	1. Prüfen Sie, ob das Farbband beim Transport unter dem Führungsschlitze liegt. 2. Die Schneidkante wird versehentlich während des Druckens verschoben. Schneiden Sie das Element vorsichtig ab, wenn das Element nicht abgetrennt ist. 3. Prüfen Sie, ob das Farbband richtig montiert ist.
Ein Drucken von Handy auf ist nicht möglich	Stellen Sie sicher, dass das Bluetooth auf Ihrem Handy aktiviert ist und dass der Drucker mit der App verbunden ist.

11. Farbbandfach Anweisung zur Produktgarantie

Vielen Dank, dass Sie unseren Etikettendrucker ausgewählt haben.

(1) Geben Sie den Kunden innerhalb eines Jahres Garantieanspruch ab dem Kaufdatum einen zuverlässigen Support (Ersatz / Rendite).

(2) Halten Sie die Garantiekarte an einem sicheren Ort, um bei Bedarf zu lesen.

support@phomemo.com
www.phomemo.com

Weitere Informationen finden Sie auf der offiziellen Website: www.phomemo.com

11. Farbbandfach Garantiekarte

Ersatz Rendite

Rückkehr/Ersatz: Name: _____ Geschlecht: _____
Tel: _____
Adresse: _____
Kaufdatum: _____
Produktmodellnummer: _____
Produkt: _____
Grund für die Rückgabe oder Erstattung: _____

Rückgabe-Grund (Ersatz / Rendite / Anforderspezifisch): _____

Thank you for choosing our products! Please read this instruction carefully before using this product and keep it properly.

封面

尺寸按照展开的尺寸标注:A3 折叠要求:保证封面在最前面

User's Guide P3100D

Thank you for choosing our products! Please read this instruction carefully before using this product and keep it properly.

封面

包装工艺: 折叠

除非另有说明, 否则公差按下表:				产品型号		P3100D产品 (英德)		ZEGUAN 泽冠		珠海泽冠科技有限公司			
尺寸标注	CLASS A	CLASS B	CLASS C	名称	说明书	材料	80g书写纸						
<6.0	±0.5	±1	±2	设计	乐晓凯20210813	颜色							
6.0~30.0	±0.5	±1	±2	确认	乐星20210813	料号	30400300322						
30~120	±0.5	±1	±2	审核	彭理艳20210813	版本号	A0	比例	1:1	单位	mm	图幅	
120~400	±0.5	±1	±2			第三角度投影				第 1 张 共 1 张			
400~1000	±0.5	±1	±2										