



Product Description

Power indicator status

Indicator light color	Status	Solution
Orange light flash slowly	1. No printer ribbon 2. Press the cutting button when the printer is printing 3. Battery's lower than 5%	1. Press the cutting button again to cut the ribbon and print text again 2. Repeat the cutting button to cut the printer ribbon and print again 3. Please connect the power source
Orange light flash quickly	Power is lower than 5%, so can't print.	Connect to power source
Orange light with/without flash (50%~100%)	Charging power was lower than 60%	/
Blue light with/without flash (50%~100%)	Charging power was higher than 60%	/
Blue light	Full charge	/
Blue light on	USB or Bluetooth connected	/
Bluetooth light	USB or Bluetooth not connected	Please connect usb or bluetooth

Operation Guidance

Switch print ribbon

1. Open the side cover outwards in the direction of the arrow (see above).
2. Insert the label tape cassette correctly as shown in the picture above. Close the cover to complete the installation.

Attention

1. Insert or pull out the charge cable gently to avoid any damages to the port.
2. Pull out the cable after charging is complete.
3. Do not charge or use the printer in high temperature, high humidity, or foggy circumstances (e.g. in a bathroom, a steam room or beside a fire) which may be dangerous. (NOTE: This machine is not suitable for tropical environments)
4. Improper charging methods may cause damage.
5. Do not touch the print head; it may hot.
6. Be aware of the sharp blade.
7. If the machine is malfunctioning, the reset hole can be used to restart the machine.

Battery Warning Description

Never disassemble, strike, squeeze or put into fire; if there is severe swelling, do not continue to use; Do not put in a high temperature environment. Do not use if immersed in water: Be sure to replace with an appropriate type of battery. (There is danger of explosion if you replace it with the wrong type of battery.) Be sure to dispose of the used battery as instructed.

FCC Caution

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on; the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Product Warranty Description

1. The free warranty period is 1 year from the date of purchase.
2. Within 30 days from the date of receipt, the user can choose to return the item.

Please save the warranty/maintenance card properly. The warranty/maintenance card will not be replaced if lost or damaged.

Warranty/Maintenance Card

Replace Return Repair

User Info: Name: _____ Gender: _____ Phone: _____ Address: _____

Product Information: Date of purchase: _____ Product Order Number: _____ Product Serial Number: _____

Return, Replace, or Repair Request: Reason: _____

Maintenance records: Fault conditions: _____ Maintenance staff: _____ Processing situation: _____ Repair date: _____ Repair ticket number: _____ Date of inspection: _____

Product certification: Inspector: _____ Date of manufacture: _____

商品紹介

指示灯状態	状態	原因/解決方法
オレンジ色点滅	1. インクリボン未装着 2. 印刷中にカッターボタンを押し、 3. 電池残量が10%以下になった	1. 再装着ください 2. 再度印刷してください 3. 充電してください
電池ランプ	オレンジ色点滅 赤いランプ 青いランプ フル充電ランプ	電圧残量が10%以下、印刷不可 充電中、電池残量の60%以下 充電中、電池残量の60%以上 電源接続完了 USBやBluetoothに接続済み 電源に接続していない

使用ガイド

1. 初めてご使用の際は、表電してから、長く電圧残量を10%以上でCONにします
2. Bluetooth充電のONに、Appにて装置を接続し、印刷を開始してください

インクリボンの交換

1. 高い方向で、外へ向けてキャップを開けてください
2. 指示通りに送料材を正しくセットしてから、キャップを閉めてください

注意事項

1. 充電時、携帯電話を近づけないように、充電ケーブルを巻くこと
2. 充電終了後、充電ケーブルを巻いてください
3. 危険な状況のため、高温、高湿度、湿気や油煙等のご使用や充電をしないこと
例えば、シャワー室、サウナ室、火災など
4. 不適当な充電ではプリンターヘッドに損傷を与えるので、十分注意してください
5. 傾けなどを起こさず、プリンターヘッドを転がさないでください
6. カップを転がさないでください
7. 高湿度の機会、セットを閉じて、適切な充電を再開してください

電池警告説明

1. 禁止拆解、圧縮、短絡、火中投入
2. 分解、刺突、着火又は火に投入しない
3. 廃棄厳禁（燃焼、液体排出厳禁）
4. 着火し、膨張が起きたら、廃棄は、使用しないでください
5. 廃棄する際は、高温環境中、電流源を絶縁して廃棄してください
6. 高温環境に放置しないでください。電池が接続された後に使用しないでください

注意：不適当な電池使用による損傷や故障がありますので、同様の電池の交換はしないでください。

商品取り扱い説明

本商品のアフターサービスは「中華人民共和国消費者保護法」, 「中華人民共和国商品品質法」に基づき、アフターサービスを明示しております。詳細は下記の通りです：

1. 本商品の無料修理期間:購入日から15日以内または1年(注:返送修理費用の負担車にする)
2. ユーザーが操作ミスが原因の場合:15日以内、返品や交換無料修理を承諾することができます。受け取った日から8~15日以内、交換や無料修理を承諾することができます
3. 無料修理は保険、郵送、運送などの費用は含まなく、お宅までサービスもございません。
4. 修理期間が延長した場合は返金は致しませんので、ご了承ください。修理費用は別途お問い合わせください

非修理サービス条例 (下記の場合では有償いたします)

1. 修理有効期間オーバーの場合
2. 同様に購買履歴や修理カードのオリジナルを提供できない、又は修理カードとお客様の履歴が合わない場合。
3. 修理に修理カードの内容、商品情報と無関係、壊れ、改善しない場合と損害する行為があった場合。
4. 無断に拆解、分解などによる損害があった場合。
5. 地震、水災、火災、雷など自然災害又は、火災、腫瘍等での外部災害による損害があった場合。
6. 宛先不明(国名、土名、氏名)での使用、又は、取扱説明書に違反した、誤用や修理された場合。

修理カード

交換 返品 修理

ユーザー情報: 姓名: _____ 性別: _____ 電話番号: _____

商品情報: 購買日時: _____ 商品オーガNo.: _____ 商品シリアルNo.: _____ 返品や交換の理由: _____

返品や交換の記録: 返品理由: _____ 修理履歴: _____ 修理日時: _____ 購入日: _____ 修理店番号: _____ 修理店名: _____

商品合格证: 検査員: _____ 出荷日: _____

使用ガイド

指示灯状態	状態	原因/解決方法
オレンジ色点滅	1. インクリボン未装着 2. 印刷中にカッターボタンを押し、 3. 電池残量が10%以下になった	1. 再装着ください 2. 再度印刷してください 3. 充電してください
電池ランプ	オレンジ色点滅 赤いランプ 青いランプ フル充電ランプ	電圧残量が10%以下、印刷不可 充電中、電池残量の60%以下 充電中、電池残量の60%以上 電源接続完了 USBやBluetoothに接続済み 電源に接続していない

注意事項

1. 充電時、携帯電話を近づけないように、充電ケーブルを巻くこと
2. 充電終了後、充電ケーブルを巻いてください
3. 危険な状況のため、高温、高湿度、湿気や油煙等のご使用や充電をしないこと
例えば、シャワー室、サウナ室、火災など
4. 不適当な充電ではプリンターヘッドに損傷を与えるので、十分注意してください
5. 傾けなどを起こさず、プリンターヘッドを転がさないでください
6. カップを転がさないでください
7. 高湿度の機会、セットを閉じて、適切な充電を再開してください

電池警告説明

1. 禁止拆解、圧縮、短絡、火中投入
2. 分解、刺突、着火又は火に投入しない
3. 廃棄厳禁（燃焼、液体排出厳禁）
4. 着火し、膨張が起きたら、廃棄は、使用しないでください
5. 廃棄する際は、高温環境中、電流源を絶縁して廃棄してください
6. 高温環境に放置しないでください。電池が接続された後に使用しないでください

注意：不適当な電池使用による損傷や故障がありますので、同様の電池の交換はしないでください。

アフターサービスセンター

本商品のアフターサービスは「中華人民共和国消費者保護法」, 「中華人民共和国商品品質法」に基づき、アフターサービスを明示しております。詳細は下記の通りです：

1. 本商品の無料修理期間:購入日から15日以内または1年(注:返送修理費用の負担車にする)
2. ユーザーが操作ミスが原因の場合:15日以内、返品や交換無料修理を承諾することができます。受け取った日から8~15日以内、交換や無料修理を承諾することができます
3. 無料修理は保険、郵送、運送などの費用は含まなく、お宅までサービスもございません。
4. 修理期間が延長した場合は返金は致しませんので、ご了承ください。修理費用は別途お問い合わせください

非修理サービス条例 (下記の場合では有償いたします)

1. 修理有効期間オーバーの場合
2. 同様に購買履歴や修理カードのオリジナルを提供できない、又は修理カードとお客様の履歴が合わない場合。
3. 修理に修理カードの内容、商品情報と無関係、壊れ、改善しない場合と損害する行為があった場合。
4. 無断に拆解、分解などによる損害があった場合。
5. 地震、水災、火災、雷など自然災害又は、火災、腫瘍等での外部災害による損害があった場合。
6. 宛先不明(国名、土名、氏名)での使用、又は、取扱説明書に違反した、誤用や修理された場合。

アフターサービスセンター

本商品のアフターサービスは「中華人民共和国消費者保護法」, 「中華人民共和国商品品質法」に基づき、アフターサービスを明示しております。詳細は下記の通りです：

1. 本商品の無料修理期間:購入日から15日以内または1年(注:返送修理費用の負担車にする)
2. ユーザーが操作ミスが原因の場合:15日以内、返品や交換無料修理を承諾することができます。受け取った日から8~15日以内、交換や無料修理を承諾することができます
3. 無料修理は保険、郵送、運送などの費用は含まなく、お宅までサービスもございません。
4. 修理期間が延長した場合は返金は致しませんので、ご了承ください。修理費用は別途お問い合わせください

非修理サービス条例 (下記の場合では有償いたします)

1. 修理有効期間オーバーの場合
2. 同様に購買履歴や修理カードのオリジナルを提供できない、又は修理カードとお客様の履歴が合わない場合。
3. 修理に修理カードの内容、商品情報と無関係、壊れ、改善しない場合と損害する行為があった場合。
4. 無断に拆解、分解などによる損害があった場合。
5. 地震、水災、火災、雷など自然災害又は、火災、腫瘍等での外部災害による損害があった場合。
6. 宛先不明(国名、土名、氏名)での使用、又は、取扱説明書に違反した、誤用や修理された場合。

尺寸标注	CLASS A	CLASS B	CLASS C
<6.0	±0.5	±1	±2
6.0~30.0	±0.5	±1	±2
30~120	±0.5	±1	±2
120~400	±0.5	±1	±2
400~1000	±0.5	±1	±2

设计: 陈颖心 2020-06-24
确认: 黄沛曦 2020-06-24
审核: 彭理艳 2020-06-24

产品型号: P1000中性

名称: 说明书
料号: 30400300149
版本号: A/0
比例: 1:1
单位: mm
图幅: 第1张共1张

材料: 80g书写纸
颜色: 1:1

珠海泽冠科技有限公司