External Picture

Label Location

REMOTE CONTROL PAIRING
1. Product power off
2. Long press the stop button
3. When the lights are flashing
4. Product power on
5. The lights stop flashing and stay on
6. Remote control matched successfully