

Table of Content

1. Getting Started

- a. Hardware Layout
- b. Charging
- c. Navigation
- d. Launcher
- e. Quick Settings / Notifications
- f. Network

2. Basics

- a. Connected Devices
- b. Installing / Deleting Apps
- c. Battery
- d. Storage
- e. Sound & Vibration
- f. Display
- g. Glyphs
- h. Screen lock & Security
- i. About A065

3. Advanced

- a. Camera & Mic Optimization
- b. App Shortcuts
- c. Expanded Icons
- d. Do not disturb
- e. Google assistant
- f. Reverse charging
- g. Screenshot

4. Safety Information

- a. Need more research

Main body

1. Getting Started

- a. Hardware Layout
 - Volume up button
 - Volume down button
 - Power button
 - Charging port

Kevin Ke kevin

- Wireless charging coil
- NFC

b. Charging

- The phone (1) charges at 33W, allowing charging from 0% to 100% in just 76 minutes with wired fast charge and a compatible fast charge adapter.
- Alternatively, using the wireless 15W charger will completely charge the device in 130 minutes. To use wireless charging, place the device face up on a compatible wireless charger.

c. Navigation

- 3-button navigation
 - Back: return to the previous screen or reverse the last action.
 - Home: return to the home page of the launcher.
 - App switcher: open the app switcher to change to a recently opened app or to free up memory by "killing" app processes.
- Gesture navigation
 - Back: swipe inwards from the left or right edge of the screen.
 - Home: swipe up from the bottom edge of the screen.
 - App switcher: swipe up and hold from the bottom edge of the screen.

d. Launcher

- i. Home page
- ii. App drawer
- iii. Widgets

e. Quick Settings / Notifications

- Pull down from the status bar to access the quick settings & notification centre. In the quick settings, tap each tile to toggle each feature. The tile can also be long pressed to directly access more detailed settings.
- Pull down a second time to access the expanded quick settings. Swipe left and right to access more quick settings tiles. Press the edit (pencil) icon and drag the tiles to customize the layout.

2. Basics

a. Network

- To change your Network settings, either drag down the quick settings panel and long press the first tile on the top left, or open the Settings app and tap on "Network & Internet".
- To connect to wifi, tap on the wifi menu item and turn on the Wifi toggle. Proceed to select the wireless network of your choosing and enter the password.
- Internet sharing can also be turned on here on this page. To do so, simply tap on "Hotspot & Tethering" to select the preferred method and proceed to set it up. This option can also be easily accessed through quick settings.

b. Connected Devices

- To connect to a Bluetooth device, either drag down the quick settings panel and long press the second tile to the top right, or open the Settings app and tap on "Connected devices"
- Tap on "Pair new device" and select on the target device to connect to it.

c. Installing / Deleting Apps

- Installing

- Note: If this action is performed on the home screen, the zone will be marked as "Remove", which only removes the icon from the home screen and will not uninstall the app.

d. Battery

- The phone (1) uses a 4500mAh battery which should last a whole day of medium to heavy usage. If the battery is running low, enable Battery Saver mode by either tapping on the "Battery Saver" tile in quick settings, or pressing the Low Power notification that appears automatically when the device's battery falls under 15%
- The phone (1) optimizes its long term battery health by reducing the charging speed overnight when an alarm is set, to avoid trickle charging while ensuring that the device only becomes fully charged close to the wakeup time.

e. Storage

- To check the available storage on the device, open the Settings app and tap on "Storage" to get an overview of the storage consumption of each type of tiles.
- To clear app storage or wipe app cache, open the Settings app and tap on "App" then "All apps" to view all installed apps and the respective storage each app is using. Tap on a select app to enter its "More info" page which shows the two buttons for either clearing storage or clearing cache.

f. Sound & Vibration

- Press the physical volume up or down button on the side of the device to adjust the volume for the most recently used audio source and open the audio menu.
- In the audio menu, tap on the top most bell icon to change between the "Ring mode", "Vibration Only", and "Silent mode".
- In the audio menu, tap on the bottom three dots icon to open a slider menu with four sliders to adjust the volume of media volume, call volume, ring & notification volume, and alarm volume respectively.

g. Glyphs

-

h. Security

- To change the unlocking method, open the Settings app and find the "Screenlock & Security" option. Enter the page to set the unlocking PIN, record additional fingerprints, or record facial data used for unlocking the device.
- Note: Fingerprint / face data unlocking cannot be used without a PIN as otherwise anyone could simply swipe to unlock the device.

i. About Phone (1)

- Contains all the device specific information such as hardware information, phone number etc.
- Press on the device name to edit how the phone (1) appears on other devices.
- If there is a new software update available for the device, a red number (1) will show up next to the NothingOS version.
- Tap 9 times, you know where...

ユーザーガイド-A065

目次

1.はじめに

e. クイック設定/通知

f. 通信網

2.基本

a. 接続されたデバイス

b. アプリのインストール/削除

c. バッテリー

d. ストレージ

e. 音と振動

f. 画面

g. グリフ

h. 画面ロックとセキュリティ

私。電話について（1）

3.高度な

a. カメラとマイクの最適化

b. アプリのショートカット

c. 展開されたアイコン

d. 邪魔しないでください

e. Google アシスタント

f. 逆充電

g. スクリーンショット

4.安全情報

a. さらに調査が必要

本体

1.はじめに

- 充電ポート
- SIM カードトレイ
- フロントカメラ
- バックカメラ
- 懐中電灯
- ボトムスピーカー
- グリフ
- レコーディングライト
- ワイヤレス充電コイル
- NFC

b. 充電

- 電話（1）は 33W で充電され、有線急速充電と互換性のある急速充電アダプターを使用して、わずか 76 分で 0% から 100% まで充電できます。
- または、ワイヤレス 15W 充電器を使用すると、130 分でデバイスが完全に充電されます。ワイヤレス充電を使用するには、互換性のあるワイヤレス充電器にデバイスを上向きに置きます。

c. ナビゲーション

▪3 ボタンナビゲーション

- 戻る：前の画面に戻るか、最後のアクションを元に戻します。
- ホーム：ランチャーのホームページに戻ります。
- アプリスイッチャー：アプリスイッチャーを開いて、最近開いたアプリに変更したり、アプリプロセスを「強制終了」してメモリを解放したりします。

▪ジェスチャーナビゲーション

- 戻る：画面の左端または右端から内側にスワイプします。

ii. アプリドロワー

iii. ウィジェット

e. クイック設定/通知

- ステータスバーからプルダウンして、クイック設定と通知センターにアクセスします。

クイック設定で、各タイルをタップして各機能を切り替えます。タイルを長押しして、より詳細な設定に直接アクセスすることもできます。

- もう一度プルダウンして、展開されたクイック設定にアクセスします。左右にスワイプすると、よりクイックな設定タイルにアクセスできます。編集（鉛筆）アイコンを表示し、タイルをドラッグしてレイアウトをカスタマイズします。

2.基本

a. 通信網

- ネットワーク設定を変更するには、クイック設定パネルを下にドラッグして左上の最初のタイルを長押しするか、設定アプリを開いて[ネットワークとインターネット]をタップします。

- wifi に接続するには、wifi メニュー項目をタップして Wifi トグルをオンにします。選択したワイヤレスネットワークの選択に進み、パスワードを入力します。

- このページでインターネット共有をオンにすることもできます。これを行うには、[ホットスポットとテザリング]をタップして目的の方法を選択し、設定に進みます。このオプションには、クイック設定からも簡単にアクセスできます。

b. 接続されたデバイス

- Bluetooth デバイスに接続するには、クイック設定パネルを下にドラッグして右上の 2 番目のタイルを長押しするか、設定アプリを開いて[接続されたデバイス]をタップします

- [新しいデバイスのペアリング]をタップし、ターゲットデバイスを選択して接続します。

c. アプリのインストール/削除

アプリは、アプリドロワーにあります。

■削除

•アプリドロワーを開き、削除する必要のあるアプリを押したままドラッグして、画面の右上隅にドラッグし、[アンインストール]とマークされた領域の下でリリースします。

•注：このアクションをホーム画面で実行すると、ゾーンは「削除」としてマークされます。これにより、ホーム画面からアイコンが削除されるだけで、アプリはアンインストールされません。

d. バッテリー

•電話（1）は 4500mAh のバッテリーを使用しており、中程度から大量の使用で 1 日持続します。バッテリーが少なくなっている場合は、クイック設定で[バッテリーセーバー]タイルをタップするか、デバイスのバッテリーが 15%を下回ると自動的に表示される低電力通知を押して、バッテリーセーバーモードを有効にします。

•電話（1）は、アラームが設定されたときに夜間の充電速度を下げることで長期的なバッテリーの状態を最適化し、トリクル充電を回避しながら、デバイスがウェイクアップ時間の近くでのみ完全に充電されるようにします。

e. ストレージ

•デバイスで使用可能なストレージを確認するには、設定アプリを開き、[ストレージ]をタップして、各タイプのタイルのストレージ消費量の概要を取得します。

•アプリのストレージをクリアまたはアプリのキャッシュを消去するには、設定アプリを開き、[アプリ]、[すべてのアプリ]の順にタップして、インストールされているすべてのアプリと、各アプリが使用しているそれぞれのストレージを表示します。選択したアプリをタップして、[詳細情報]ページに入ります。このページには、ストレージをクリアするかキャッシュをクリアするための 2 つのボタンが表示されます。

f. 音と振動

•デバイスの側面にある物理的な音量の上下ボタンを押して、最近使用したオーディオソ

- オーディオメニューで、下の3つのドットアイコンをタップして、4つのスライダーを備えたスライダーメニューを開き、メディアの音量、通話の音量、呼び出し音と通知の音量、アラームの音量をそれぞれ調整します。

g. グリフ

••

h. 安全

- ロック解除方法を変更するには、設定アプリを開き、[スクリーンロックとセキュリティ]オプションを見つけます。ページを入力して、ロック解除PINを設定したり、追加の指紋を記録したり、デバイスのロック解除に使用した顔のデータを記録したりします。
- 注：指紋/顔データのロック解除はPINなしでは使用できません。そうしないと、誰でもスワイプしてデバイスのロックを解除できます。

私。電話について（1）

- ハードウェア情報、電話番号など、デバイス固有のすべての情報が含まれています。
- デバイス名を押して、電話（1）が他のデバイスでどのように表示されるかを編集します。
- デバイスで利用可能な新しいソフトウェアアップデートがある場合、NothingOSバージョンの横に赤い数字（1）が表示されます。
- 9回タップすると、どこにあるかわかります...