Wireless Item Finder

User Guide

Model: UF-07Pro

To use the Item Finder for the first time, it is recommended to fully charge the device. Please refer to the "Charging Instructions" section for detailed charging guidelines.

Once the device is fully charged, you can begin pairing it with your phone. Please refer to the "Pairing Instructions" section for step-by-step guidance.

If you encounter any issues or have questions during the setup process, please refer to the "Troubleshooting" section for common solutions. If you still need assistance, feel free to contact our customer support team for further help.

Package Contents

- 1 Wireless Item Finder
- 1 Battery Installation Tool
- 1 Instruction Manual

Product Overview

1. Battery Installation Tab
2. Lanyard Ring
3. Microphone Hole
4. Buzzer

IMPORTANT TIPS

- Installation & Setup: When using this model, it is essential to install the Tuya Smart app and complete the device pairing process. Without proper setup, the device will not function correctly.
- Battery Installation: Please ensure that the battery is installed correctly, with the positive (+) and negative (-) terminals aligned as indicated. Incorrect installation may prevent the device from powering on.
- Lanyard Installation: Attach the lanyard securely to the designated hole to prevent accidental loss. Ensure the knot is tight and the lanyard is long enough for comfortable use.
- Environmental Considerations: This model is designed for indoor use. Avoid exposing it to extreme temperatures or moisture.
- Do not remove the waterproof sealing of the device to maintain its waterproof performance. Avoid prolonged exposure to water, as the device is only splash-resistant and not fully waterproof.
- Regular Maintenance: Keep the device clean and free from dust and debris. Use a soft, dry cloth for cleaning. Avoid using harsh chemicals or abrasive materials.
- Battery Replacement: When the battery is low, replace it promptly to ensure continuous functionality. Dispose of the old battery responsibly according to local regulations.
- Troubleshooting: If you encounter any issues, refer to the troubleshooting section in the manual or contact customer support for assistance.

WARNING!

- Keep away from children.
- Avoid exposure to high temperatures.
- Do not disassemble.

Product with replaceable button/coin cell battery

- If swallowed, the button/coin cell battery can cause severe internal burns in just 2 hours and can lead to death.
- Keep new and used batteries away from children.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

Product Specifications

Dimensions: 75mm(L) x 31mm(W)

Net Weight: 20g

Battery: CR2032 (3V) Coin Cell Battery

Working Temperature: 0°C to 40°C (32°F to 104°F)

Compatibility: iOS 9.0 and Android 5.0 or above

Operating Instruction

First-time Use

- Remove the battery insulation tab to activate the device.
- Download the Tuya Smart app from the App Store or Google Play Store.
- Create an account or log in if you already have one.
- Follow the in-app instructions to add a new device.
- Select "Item Finder" from the list of available devices.
- Ensure your phone's Bluetooth is turned on.
- Press and hold the device button until the LED indicator flashes rapidly.
- The app will automatically detect the device. Tap "Connect" to pair.
- Once paired, you can customize the device name and settings.
- Test the device by using the "Find Device" feature in the app.

Usage Scope

How to Use the Product

- Press and hold the button inside the **iUiDi** until the LED indicator flashes rapidly. This indicates that the device is in pairing mode.
- Open the **Tuya Smart** app on your phone.
- Select the **"Item Finder"** option from the list of available devices.
- Follow the on-screen instructions to complete the pairing process.

How It Pairing the Product

- Make sure Apple device has Bluetooth, **Tuya Smart** and **Turning on Location Services** are turned on.
- Open the **Tuya Smart** app, tap the "+" in the top right corner, or tap "Add Device" on the Home page.
- Select the device to be added, then click to confirm that the indicator light is flashing rapidly.
- Enter the Wi-Fi password, wait for the device to connect to the network, and click "Completed" when prompted that the device has been added successfully.

- While connecting, please make sure that the device only connects to one phone. Disconnect from other devices before proceeding.
- Ensure that the device is within the Bluetooth range of your phone during the pairing process.
- If the pairing process fails, try restarting both the device and your phone, then repeat the steps.
- Keep the device's firmware updated to the latest version for optimal performance and compatibility.

Function

Function 1: One-Click Product Search

When your phone is near, tapping the device's on-screen button will trigger the device to emit a sound, helping you quickly locate it.

Function 2: Online Positioning

- Open the App and click **"Item Finder"** under the **"Smart"** tab.
- Select the location you want to see on the map from the current device list.
- Click **"Locate"** to view the location.

Function 3: Lost Item Reminder

You can set anti-loss alarms for your phone and the device. When you and the device are separated by a certain distance, both will sound an alarm to remind you.

Function 4: Double Tuck Model

- Open the App and click **"Item Finder"** under the **"Smart"** tab.
- Select the device you want to set and click **"Settings"** in the upper right corner.
- Click **"Double Tuck Model"** and enable the function.

- Select **"Notification"** and set **"Nearby Alert Left Behind"** and **"Distant Alert Left Behind"** to **"Alert"**.

- Click **"Notification"** and set **"Nearby Alert Left Behind"** and **"Distant Alert Left Behind"** to **"Alert"**.

Functions & Trackking

Tracking Location

Whenever a product is connected to the network and can report its last location, you can view the last location of the product on the map. Click **"Last Walk"** to view the last location of the product on the map.

Tracking Record

Whenever a product is connected to the network and can report its location, you can view the location of the product on the map. Click **"Tracking Record"** to view the location of the product on the map.

Switching the Product

Click **"Switching Product"** to switch the product you want to track.

Restoring While Powered Off

- Go to the App's "Item Finder" page, click the settings button in the upper right corner, then click "Remove" at the bottom of the page.
- Click "Confirm" in the pop-up window to restore the device to factory settings.

Service Definition

Function	Button operation	Sound / Alarm
Find Device	Double-click the button	The device rings
Stop Finding	Double-click the button	The ringing stops
Find Phone	Double-click the button	The phone rings
Stop Finding	Double-click the button	The ringing stops

Factory Reset

Hardware Reset

Remove the battery cover and the battery. Press and hold the button for 5 seconds. Release the button when you hear a prompt sound. The device will restart and be restored to factory settings.

Mobile

Open the App and click the settings button in the upper right corner. Click "Remove" at the bottom of the page. Click "Confirm" in the pop-up window to restore the device to factory settings.

How to replace the battery

Use the coin battery installation tool to open the battery cover, and then replace the battery with a new one. Please pay attention to the positive and negative poles of the battery.

Charging and Maintenance

Initial Charging

- Before using the device for the first time, it is recommended to fully charge it to ensure optimal performance.
- Use the provided USB cable to connect the device to a power source.
- The charging indicator will illuminate during the charging process.
- Once fully charged, the indicator will turn off.

Maintenance

- Clean the device with a soft, dry cloth to remove dust and debris.
- Avoid using harsh chemicals or abrasive materials that may damage the device.
- Keep the device away from extreme temperatures and moisture.
- Regularly check the battery level and recharge as needed to maintain functionality.
- Store the device in a cool, dry place when not in use for extended periods.

FAQ

Where can the product be located?

Within the range of Bluetooth connection, the product can be located. Please refer to the "Product Positioning" section for more details.

Why can't I find the product?

- Make sure the device is powered on and connected to the app.
- Check if the device is within the Bluetooth range. Move closer if necessary.
- Ensure that the app has the necessary permissions to access Bluetooth and location services.
- Restart both the device and your phone, then try pairing again.
- If the problem persists, refer to the troubleshooting section in the manual or contact customer support for assistance.

Is there a fee-product designed to discourage unpaired removal?

No, there is no fee associated with the product designed to discourage unpaired removal.

Can I connect to multiple devices?

- If you have set up Alexa, Google, or Siri Shortcuts, then the device can be controlled by voice commands.
- Ensure that your voice assistant is linked to your Tuya Smart account.
- Use specific commands like "Alexa, find my item" or "Hey Google, locate my item" to activate the device.

Can I customize the sound alert?

Yes, you can customize the sound alert in the app settings. Navigate to the device settings and select the desired sound from the available options.

Is there a way to prevent accidental loss?

- Set up anti-loss alarms in the app. These will notify you if the device and your phone are separated by a certain distance.
- Consider using a lanyard or attaching the device to your keychain for added security.
- Regularly check the device's location in the app to ensure it is where you expect it to be.

What if the battery is low?

- When the battery is low, the device will emit a low battery warning sound.
- You can also check the battery status in the app. It will display a notification when the battery needs to be replaced.
- Replace the battery with a new CR2032 coin cell battery.
- Ensure the positive (+) side of the battery faces up when inserting it into the device.
- **Do not dispose of batteries in fire or attempt to recharge non-rechargeable batteries.**
- **Keep batteries out of reach of children and pets to prevent ingestion.**
- **If a battery is swallowed, seek medical attention immediately.**
- **Dispose of used batteries according to local regulations and recycling guidelines.**
- **Avoid exposing the device to extreme temperatures or moisture when replacing the battery.**
- **Store spare batteries in a cool, dry place away from direct sunlight.**
- **Regularly check the battery level to ensure the device is always ready for use.**
- **If the device is not in use for an extended period, remove the battery to prevent corrosion.**
- **Clean the battery contacts with a dry cloth before installing a new battery.**
- **Do not mix different types of batteries or use old and new batteries together.**
- **Ensure the battery cover is securely closed after replacing the battery to maintain water resistance.**

FCC Statement - US Market

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF Warning

This device complies with FCC RF exposure limits for general population/uncontrolled exposure. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

尺寸：75x100mm

材质：105g 铜版纸 双面印刷 四色印刷 骑马钉

备注：蓝色实线为折痕裁切框不印刷