

## Instructions for use.

How to connect the Remote Control to your TV.

Pairing Steps:

1.Turn on the TV.

2.Press and hold keys "Return" and "Play/Pause" at the same time for 4-7 seconds until pairing successful message or completed pairing message is displayed on the TV screen.



Tips:

When the remote control isn't working, these steps may help to resolve the problem.

1.Replace new batteries.

2.Please check whether your original remote control is connecting with your TV or not .If yes, please disconnect, because one smart remote control can be paired to a TV at a time.Following Pairing step 2 to disconnect .

3.The connection between the remote control and the TV may be lost.Please pair again.

Note :

1.Please use alkaline batteries.

2.If pairing fails, please repeat Pairing step 2.

3.For energy-saving ,the remote control will enter sleep mode, press any key to wake up and use the remote control.

(This function is not malfunction, but the energy-saving mode.)

## Gebrauchsanweisungen.

So verbinden Sie die Fernbedienung mit Ihrem Fernseher.

Pairing Steps:

1.Schalten Sie den Fernseher ein

2.Halten Sie die Tasten "Return" und "Play/Pause" gleichzeitig für 4-7 Sekunden gedrückt, bis die Meldung "Pairing erfolgreich" oder "Pairing abgeschlossen" auf dem Fernsehbildschirm angezeigt wird.



Tipps:

Wenn die Fernbedienung nicht funktioniert, können diese Schritte helfen, das Problem zu beheben

1.Neue Batterien ersetzen

2.Bitte überprüfen Sie, ob Ihre Originalfernbedienung mit Ihrem Fernseher verbunden ist oder nicht. Wenn ja, verbinden Sie sich bitte, da eine intelligente Fernbedienung gleichzeitig mit einem Fernseher gekoppelt werden kann. Schritt 2 zum Trennen der Verbindung mit .

3.Die Verbindung zwischen der Fernbedienung und dem Fernseher kann unterbrochen werden. Bitte paaren Sie sich wieder.

Anmerkung:

1.Bitte verwenden Sie Alkalibatterien.

2.Wenn die Kopplung fehlschlägt, wiederholen Sie bitte den Kopplungsschritt 2.

3.For energiesparend, wird die Fernbedienung in den Ruhemodus gehen, drücken Sie eine beliebige Taste, um aufzuwachen und die Fernbedienung zu verwenden.

(Diese Funktion ist nicht malfunction, sondern der energiesparende Modus.)

## Instructions d'utilisation.

Comment connecter la télécommande au téléviseur.

Étapes d'appariement:

1. Allumez le téléviseur.

2. Maintenez les touches retour et lecture / pause enfoncées simultanément pendant 4 à 7 secondes jusqu'à ce que le message de réussite de l'appariement ou le message de fin d'appariement s'affiche sur l'écran du téléviseur.



Conseils:

Ces étapes peuvent aider à résoudre le problème lorsque la télécommande ne fonctionne pas.

1. Remplacez la nouvelle batterie.

2. Veuillez vérifier si votre télécommande d'origine est connectée à votre téléviseur. Si oui, déconnectez - vous, car il est possible d'associer une télécommande intelligente à votre téléviseur à la fois. Suivez l'étape d'appariement 2 pour déconnecter.

3. La connexion entre la télécommande et le téléviseur peut être perdue. Veuillez ré - appairer.

Notes:

1. Veuillez utiliser des piles alcalines.

2. Si l'appariement échoue, répétez l'étape 2 de l'appariement.

3. Pour économiser de l'énergie, la télécommande entrera en mode veille, appuyez sur n'importe quelle touche pour réveiller et utiliser la télécommande.

(Cette fonction n'est pas une fonction, mais un mode d'économie d'énergie.)



扫描全能王

3亿人都在用的扫描App

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.