

Sony Ericsson

Important information

Sony Ericsson Consumer Web site

On www.sonyericsson.com/support there is a support section where help and tips are given a few clicks away. Here you will find the latest computer software updates and tips on how to use your product more efficiently.

Service and support

You have access to a portfolio of exclusive service advantages such as:

- Global and local Web sites providing support
- A global network of Call Centers
- An extensive network of Sony Ericsson service partners

A warranty period. Learn more about the warranty conditions in this User guide.

On www.sonyericsson.com, you will find the latest support tools and information. For operator-specific services and features, please contact your network operator. You can also contact our Call Centers. If your country/region is not represented in the list below, please contact your local dealer. (Calls are charged according to national rates, local taxes unless the phone number is toll-free). If you need more information, you need service, please contact the dealer from whom it was purchased, or one of our service partners. For warranty claims, save proof of purchase.

Guidelines for Safe and Efficient Use

Please follow these guidelines. Failure to do so might entail a potential health risk or product malfunction. If in doubt as to its proper function, have the product checked by a certified service partner before charging or using it.

Recommendations for care and safe use of your products

- Handle with care and keep in a clean and dust-free place.
- Warning! May explode if used incorrectly. Do not use the product near fire.
- Do not expose your product to liquid or moisture or excess humidity.
- Do not expose to extreme temperatures. Do not expose the battery to temperatures above +60°C (+140°F).
- Do not use in or around flames or lit tobacco products.
- Do not drop, throw or try to bend your product.
- Do not point or attempt to disassemble or modify your product. Only Sony Ericsson authorized personnel should perform service.

Consult with authorized medical staff and the instructions of the medical device manufacturer before using your product near pacemakers or other medical devices or equipment.

- Discontinue use of electronic device or disable the radio transmitting functionality of the device when not in use.
- Do not use where a potentially explosive atmosphere exists.
- Do not place your product or install wireless equipment in the area above an air bag in your car.
- Caution: Cracked or broken displays may create sharp edges or splinters that could be harmful upon contact.
- Do not use your Bluetooth Headset in positions where it is uncomfortable or where it is subject to pressure.

Children

Warning! Keep out of the reach of children. Do not allow children to play with mobile phones or accessories. They could hurt themselves or others. Products may contain small parts that could become detached and create a choking hazard.

Power supply (Charger)

Connect the charger to power sources as marked on the product. Do not use outdoors or in damp areas. Do not alter or subject the cord to damage or stress. Unplug the unit before cleaning it. Never alter the plug. If it does not fit into the outlet, have a proper outlet installed by an electrician. When power supply is connected there is a small drain of power. To avoid this small energy waste, disconnect the power supply when the product is fully charged. Use of charging devices that are not Sony Ericsson branded may impose increased safety risks.

Battery

New Li-ionide batteries can have short-term reduced capacity. Fully charge the battery before initial use. For use intended purpose only. Charge the battery in temperatures between +5°C (+41°F) and +45°C (+113°F). Do not put the battery into your mouth. Do not let the battery contacts touch another metal object. Turn off the product before removing the battery. Performance depends on temperatures, signal strength, usage patterns, features selected and voice or data transmissions. Only Sony Ericsson service partners should remove or replace built-in batteries. Use of batteries that are not Sony Ericsson branded may pose increased safety risks.

Personal medical devices

Mobile phones may affect implanted medical equipment. Reduce risk of interference by keeping a minimum distance of 15 cm (6 inches) between the phone and the device. Use the phone at your right ear. Do not carry the phone in your breast pocket. Turn off the phone if you suspect interference. For all medical devices, consult a physician and the manufacturer.

Driving

Some vehicle manufacturers forbid the use of phones in their vehicles unless a handsfree kit with an external antenna supports the installation. Check with your vehicle manufacturer for representation of the kit that your mobile phone supports. Handsfree will not affect the electronic systems in your vehicle. Full attention should be given to driving at all times and local laws and regulations restricting the use of wireless devices while driving must be observed.

GPS/Location based functions

Some personal devices use location based functions. Location determining functionality is provided "As is" and "With all faults". Sony Ericsson does not make any representation or warranty as to the accuracy of such location information.

Use of location-based information by the device may not be uninterrupted or error free and may additionally be dependent on network service availability. Please note that functionality may be reduced or prevented in certain environments such as building interiors or areas adjacent to buildings.

Caution: Do not use GPS functionality in a manner which causes distraction from driving.

Environmental and electronic equipment
Electrical equipment and batteries should not be included as household waste but should be left at an appropriate collection point for recycling. This helps prevent potential negative consequences for the environment and human health. Check local regulations by contacting your local city office, your household waste disposal service, the shop where you purchased the product or calling a Sony Ericsson Call Center.

Antenna

Use of antenna devices not marketed by Sony Ericsson could damage your phone, reduce performance, and produce SAR levels above the established limits. Do not cover or tamper with the antenna. Do not use the product with other antenna devices or accessories.

Radio frequency (RF) exposure and Specific Absorption Rate (SAR)

When your phone or Bluetooth handsfree is turned on, it emits low levels of radio frequency energy. International safety guidelines have been developed through periodic and thorough evaluation of scientific studies. These guidelines establish permitted levels of radio wave exposure. The guidelines include a safety margin designed to assure the safety of all persons and to account for any variations in measurements.

Specific Absorption Rate (SAR) is used to measure radio frequency energy absorbed by the body when using a mobile phone. SAR will be entitled third party or independent certified power level in laboratory conditions, but because the phone is designed to use the minimum power necessary to access the chosen network, the actual SAR level can be well below this value. There is no proof of differences in safety based on differences in SAR value. Products with radio transmitters sold in the US must be certified by the Federal Communications Commission (FCC). When required, tests are performed when the phone is placed at the ear and when worn on the body. For body-worn operation, the SAR value is measured at the back of the head. For ear-to-ear use, the SAR value for any metal parts in the vicinity of the phone or when properly used with an appropriate Sony Ericsson accessory and worn on the body.

For more information about SAR and radio frequency exposure go to:

www.sonyericsson.com/health.

Malware

Malware (short for malicious software) is software that can harm your mobile phone or other computers. Malware or harmful applications can include viruses, worms, spyware, and other unwanted programs. While your device does employ security measures to resist such efforts, Sony Ericsson does not warrant or represent that your device will be impervious to introduction of malware. You can however reduce the risk of malware attacks by using care when downloading content or accepting applications, refraining from opening or installing any files from unknown sources, using trustworthy sources to access the Internet, and only downloading content to your mobile phone from known, reliable sources.

Accessories

Only Sony Ericsson branded original accessories and certified service partners.

Some products not tested by Sony Ericsson may interfere with the proper function of your device. Exposure, radio performance, sound loudness, electric safety and other areas. Third-party accessories and parts may pose a risk to your health or safety or decrease performance.

Accessible Solutions/Special Needs

TTY, computerized Sony Ericsson phones may offer compatibility with TTY terminals (with a necessary accessory). For more information call the Sony Ericsson Special Needs Center at 877 878 1996 (TTY) or 877 207 2056 (voice), or go to www.sonyericsson-snc.com.

Environmental and electronic equipment

Electrical equipment and batteries should not be included as household waste but should be left at an appropriate collection point for recycling. This helps prevent potential negative consequences for the environment and human health. Check local regulations by contacting your local city office, your household waste disposal service, the shop where you purchased the product or calling a Sony Ericsson Call Center.

Disposing of the battery

Check local regulations or call a Sony Ericsson Call Center for information. Never use municipal waste.

Memory

If your product comes complete with a removable memory card, it is generally compatible with the handset purchased but may not be compatible with other devices or the capabilities of their memory cards. Check other devices for compatibility before purchase or use. If your product is equipped with a memory card reader, check memory card compatibility before purchase or use. The memory card is formatted prior to shipping. To reformat the memory card, use a compatible device. Do not use the standard operating system format when formatting the memory card on a PC. For details, refer to the operating instructions of the device or contact your computer support.

WARNING:
If your device requires an adapter for insertion into the handset or another device, do not insert the card directly without the required adapter.

Precautions on Memory Card Use

- Do not use or store the memory card in humid or corrosive locations or in excessive heat such as a closed car in summer, in direct sunlight or near a heater, etc.
- Do not press or bend the end of the memory card adapter with excessive force.
- Do not let dirt, dust, or foreign objects get into the insert port of any memory card adapter.
- Check your handset and its service partners regularly for updates to the memory card.
- Insert the memory card as far as it will go into any memory card adapter needed. The memory card may not operate properly unless fully inserted.
- We recommend that you make a backup copy of important data. We are not responsible for any loss of data or data on the memory card.
- Recorded data may be damaged or lost when you remove the memory card or memory card adapter, or turn off the power while formatting, reading or writing data, or when you use the memory card in locations subject to static electricity or high electrical field emissions.

Protection of personal information

Erse personal data before disposing of the product. To delete data, perform a master reset. Deleting data from the phone memory does not ensure that it cannot be recovered. Sony Ericsson does not warrant against recovery of information and does not assume responsibility for disclosure of any information even after a master reset.

Loudness warning!

Avoid volume levels that may be harmful to your hearing.

End User License Agreement

This contains software, including without limitation any media delivered with the device, ("Device") wireless software owned by Sony Ericsson Mobile Communications AB and its affiliated companies ("Sony Ericsson") and its third party suppliers and licensors ("Software"). As user of this Device, Sony Ericsson grants you a non-exclusive, non-transferable, non-assignable license to use the Software solely in conjunction with the Device on which it is



installed and/or delivered with. Nothing herein shall be construed as a sale of the Software to a user of this Device. You shall not reproduce, modify, distribute, reverse engineer, decompile, otherwise alter or use any other means to discover the source code of the Software or any material related to the Product to be repaired or replaced by Sony Ericsson. Sony Ericsson reserves the right to refuse warranty service if this information has been removed or changed after the original purchase of the Product from the dealer.

2. If Sony Ericsson repairs or replaces the Product, the repair for the defect concerned, or the replaced Product shall be warranted for the remaining time of the original warranty period or for ninety (90) days from the date of repair, whichever is longer. Repair or replacement may involve the use of functionally equivalent reconditioned units.

3. No person or company shall be held responsible for any damage to your Product or its hardware modifications or adjustments, acts of God or damage resulting from liquid. A replaceable battery can be charged and discharged more than a hundred times. However, it will eventually wear out. This is not a defect and corresponds to normal wear and tear. When the talk time or standby time is noticeably shorter, it is time to replace your battery. Sony Ericsson recommends that you use only batteries and chargers approved by Sony Ericsson.

Minor variations in display brightness and color may occur between the phones. There may be small, bright or dark dots on the display. These are called defective pixels and occur when individual dots have malfunctioned and cannot be adjusted. Two defective pixels are deemed acceptable.

Minor variations in camera image appearance may occur between phones. This is not uncommon and is not regarded as a defective camera module.

4. Since the cellular system on which the Product is to operate is provided by a carrier independent from Sony Ericsson, Sony Ericsson will not be responsible for the operation, availability, coverage, or range of the system.

5. This warranty does not cover Product failures caused by installations, modifications, or repair or opening of the Product performed by a non-Sony Ericsson authorised person.

6. The warranty does not cover Product failures which have been caused by the use of accessories or other peripheral devices which are not Sony Ericsson branded original accessories intended for use with the Product.

Sony Ericsson disclaims any and all warranties, whether express or implied, for the Product or to the Product or peripheral devices as a result of viruses, trojan horses, spyware, or other malicious software. Sony Ericsson strongly recommends that you install appropriate virus protection software on your Product and any peripheral devices connected to it, as available, and update it regularly, to better protect your device. It is understood, however, that such software will never fully protect your Product or its peripheral devices and Sony Ericsson disclaims all warranties, whether express or implied, in case of failure by such antivirus software to fulfill its intended purpose.

7. Tarping with any of the seals on the Product will void the warranty.

8. **THIS WARRANTY DOES NOT CONSTITUTE A WARRANTY OF MERCHANTABILITY. OTHER THAN THIS PRINTED LIMITED WARRANTY, ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL SONY ERICSSON OR ITS LICENSORS**

Limited Warranty

Sony Ericsson Mobile Communications AB, SE-221 89 Lund, Sweden, ("Sony Ericsson") or its local affiliates ("Sony Ericsson"), provides this Limited Warranty for the Product and original accessory delivered with your mobile phone (hereinafter referred to as "Product"). Should your Product need warranty service, please return it to the dealer from whom it was purchased, or contact your local Sony Ericsson Call Center (national rates may apply) or visit www.sonyericsson.com for further information.

Our warranty

Subject to the conditions of this Limited Warranty, Sony Ericsson warrants this Product to be free from defects in design, material and workmanship at the time of its original purchase by a consumer. This Limited Warranty will last for a period of two (2) years as from the original date of purchase of the Product for your mobile phone, and for any accessories. (1) Where the Product is purchased from a retailer, the retailer shall be responsible for ensuring that the following the original purchase date of the Product for all original accessories (such as the battery, charger or handset kit) which may be delivered with your mobile phone.

What we will do

If, during the warranty period, this Product fails to operate under normal use and in accordance with the instructions in the user's manual, Sony Ericsson will, at its option, due to defects in design, materials or workmanship, Sony Ericsson authorized distributors or service partners, in the country/region* where you purchased the Product, will, at their option, either repair or replace the Product in accordance with the terms and conditions stipulated herein.

Sony Ericsson and its service partners reserve the right to change a handling fee if a returned Product is found not to be under warranty according to the conditions above.

Please note that some of your personal settings, downloads and other information may be lost when your Sony Ericsson Product is repaired or replaced. At present Sony Ericsson may be prevented by applicable law, other regulations or technical restrictions from making a backup copy of certain downloads. Sony Ericsson does not take any responsibility for any lost information of any kind and will not reimburse you for any such loss. You should always make backup copies of all the information stored on your Sony Ericsson Product such as downloads, calendar and contacts before handing in your Sony Ericsson Product for repair or replacement.

Notre garantie

Sous réserve des conditions de la présente Garantie limitée, Sony Ericsson garantit que le présent Produit sera exempt de défauts de conception, de matériaux ou de fabrication pendant une période de deux (2) ans à partir de la date initiale d'achat du Produit pour votre téléphone mobile ou d'un (1) an à compter de ladite date pour tous les accessoires d'origine (notamment la batterie, le chargeur et le kit mains libres) éventuellement fournis avec ledit téléphone.

Mesures à prendre

Si, pendant la période de garantie, le présent Produit s'avère défectueux dans des conditions normales d'utilisation et d'entretien en raison de défauts de conception, de matériaux ou de fabrication, les distributeurs ou prestataires de services partenaires agréés de Sony Ericsson du pays de la région où vous avez acheté le Produit, ou le vendeur, à leur choix, soit réparera, soit remplacera le Produit conformément aux conditions générales précises ci-après.

Sony Ericsson et ses prestataires de services partenaires se réservent le droit de facturer des coûts pour le transport du Produit vers et depuis le Centre Relation Consommateur. Les réparations ou le remplacement du Produit renvoyé n'est pas couvert par la garantie. Les informations relatives à la garantie sont disponibles sur www.sonyericsson.com. Veuillez noter que certains de vos réglages personnels, téléchargements et autres informations risquent d'être perdus lors de la réparation ou du remplacement de votre produit Sony Ericsson. Actuellement, des contraintes techniques, des réglementations ou la législation en vigueur peuvent empêcher Sony Ericsson d'effectuer des copies de sauvegarde de certains téléchargements. Celle-ci n'assume aucune responsabilité en cas de perte d'informations de quelque sorte que ce soit et ne vous dédommage pas pour de telles pertes. Vous devrez toutefois effectuer des copies de sauvegarde de toutes les informations stockées sur votre Produit avant de le remettre à un réparateur agréé ou au vendeur. En outre, des contacts, avant de rendre ledit produit à des fins de réparation ou de remplacement.

Conditions

1. La présente Garantie limitée est uniquement valable si la preuve d'achat d'origine du présent Produit, délivrée par un revendeur agréé Sony Ericsson, mentionnant la date d'achat et le numéro de série du produit, est présentée avec le produit. Si elle n'est pas présentée, Sony Ericsson se réserve le droit de refuser toute intervention sous garantie si les présents renseignements sont édit supprimés ou modifiés après l'achat initial du Produit auprès du revendeur.

2. Si le revendeur agréé remplace le Produit, la réparation de la panne concernée ou le Produit de remplacement devra être couvert pendant la durée restante de la période de garantie initiale ou pendant une période de quatre-vingt-dix (90) jours à compter de la date de réparation, selon la durée la plus longue. La réparation ou le remplacement pourra être effectué au moyen d'unités reconditionnées équivalentes au plan fonctionnel.

3. La présente garantie ne couvre pas toute défectance du Produit due à l'usage normale, une mauvaise utilisation, y compris, mais de façon non limitative, une utilisation autre que les conditions normales et habituelles, conformément aux instructions de Sony Ericsson en matière d'utilisation ou d'entretien. Elle ne couvre pas non plus toutes défectances du Produit dues à un accident, à l'utilisation du Software à des fins autres que prévues, à des cas de force majeure ou à des dommages résultant du contact avec un liquide.

• Aufgezeichnete Daten können verloren gehen oder beschädigt werden, wenn Sie die Speicherkarte oder den Speicherkartenadapter entnehmen bzw. das Gerät aus dem Netz entfernen, während Sie die Speicherkarte formatieren bzw. Daten lesen oder schreiben oder falls Sie die Speicherkarte in Umgebungen einsetzen, in denen starke Entladungen statischer Elektrizität oder starke elektrische Felder auftreten.

Schutz persönlicher Daten

Löschen Sie alle persönlichen Daten, bevor Sie das Produkt entsorgen. Stellen Sie die Werkseinstellungen im Gerät wieder her, um die Daten zu löschen. Das Löschen der Daten aus dem Telefonspeicher stellt nicht sicher, dass die Daten nicht von einem anderen Benutzer wiederhergestellt werden können. Dieser Ersteller garantiert nicht, dass spätere Benutzer des Geräts nicht auf Ihre persönlichen Daten zugreifen können. Ferner übernimmt Sony Ericsson keine Verantwortung für das Bekanntwerden der Daten, nachdem eine Rücksetzung auf die Werksseinstellungen vorgenommen wurde.

Laustärkewarning:

Vermeiden Sie Laustärkewegel, die Hörschäden nach sich ziehen können.

Endbenutzer-Lizenzvertrag

„Gerät“ enthält Software, die Eigentum von Sony Ericsson Mobile Communications AB und Tochtergesellschaften („Sony Ericsson“) sowie Lieferanten und Lizenzgebern ist („Software“). Sony Ericsson gewährt Ihnen als Benutzer des Geräts eine nicht exklusive und nicht übertragbare Lizenz zur Nutzung der Software auf dem Gerät. Die Software wird installiert ist und/oder mit dem Sie geliefert wird. Keine der Aussagen in diesem Text darf als Verkauf der Software an einen Benutzer des Geräts interpretiert werden. Sie dürfen die Software und deren Komponenten nicht reproduzieren, modifizieren, verbreiten, Methoden des Reverse Engineering (Entziffern), dekomplieren oder anderweitig ändern bzw. verwenden, um Kenntnis des Quellcodes zu erlangen. Um Missverständnisse zu vermeiden: Sie dürfen jederzeit alle Rechte und Pflichten hinsichtlich der Nutzung der Software an Dritte übertragen, jedoch nur in Verbindung mit dem Gerät, mit dem Sie die Software erhalten ausschließen, während Sie die Speicherkarte formatieren bzw. Daten lesen oder schreiben oder falls Sie die Speicherkarte in Umgebungen einsetzen, in denen starke Entladungen statischer Elektrizität oder starke elektrische Felder auftreten.

• Setzen Sie die Speicherkarte keinen Flüssigkeiten aus.

• Überprüfen Sie, ob die Speicherkarte richtig eingelegt wurde.

• Schieben Sie die Speicherkarte so weit wie nötig in den zu verwendenden Speicherkartenadapter. Die Speicherkarte arbeitet nicht ordnungsgemäß, wenn sie nicht richtig eingelegt wurde.

• Wir empfehlen, dass Sie eine Kopie aller wichtigen Daten erstellen. Wir sind nicht für Verlust oder Beschädigung von Daten verantwortlich, die Sie auf der Speicherkarte ablegen.

Garantiebedingungen
Sony Ericsson Mobile Communications AB, SE-221 88 Lund, Sweden, ("Sony Ericsson") oder eine regionale Tochtergesellschaft gewährt diese Garantie für dieses Mobiltelefon und jegliches mit dem Mobiltelefon gelieferte Originalzubehör (insgesamt das „Produkt“). Wenn Sie für Ihr Produkt eine Garantieleistung in Anspruch nehmen müssen, bringen Sie Zubehör und das Produkt mit. Wenn Sie es erworben haben, werden Sie durch die Garantie bei Sony Ericsson Call Center in Ihrem Land (gegebenenfalls werden die nationalen üblichen Gebühren fällig) oder unter der Adresse www.sonyericsson.com

BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOST PROFITS OR COMMERCIAL DAMAGES. THIS WARRANTY DOES NOT EXTEND TO THE UNITED STATES OF AMERICA. Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

The warranty provided does not affect the consumer's statutory rights under applicable legislation in force, nor the consumer's rights against the dealer arising from their sales / purchase contract.

GEOGRAPHICAL SCOPE OF THE WARRANTY

We have purchased your Product in a country in member of the European Economic Area (EEA) or in Switzerland or the Republic of Turkey, and such Product was intended for sale in the EEA or in Switzerland or in Turkey, you can have your Product serviced in any EEA country or in Switzerland or in Turkey, under the warranty conditions prevailing in the country in which you require servicing of the Product, provided that an identical product is sold in such country by an authorized Sony Ericsson distributor. To find out if your Product is sold in the country you are in, please call the local Sony Ericsson Call Center. Please observe that certain services may not be possible elsewhere than in the country of original purchase due, in particular, to the fact that your Product may have an interior or exterior which is different from equivalent models sold in other countries. In addition, please note that it may sometimes not be possible to repair SIM-locked Products.

** In some countries/regions additional information (such as a valid warranty card) may be requested.

Instructions pour une utilisation efficace et sans danger

Respectez-les. Sinon, cela peut entraîner d'éventuels risques pour la santé ou un dysfonctionnement de l'appareil. Si vous doutez de son bon fonctionnement, faites-le vérifier par un professionnel qualifié.

Recommendations d'entretien et d'utilisation sûres de nos produits

- A volume élevé, les sons en provenance de l'extérieur peuvent être inaudibles. Évitez d'utiliser votre appareil en mode baladeur dans des situations où le sens de l'ouïe ne doit pas être altéré : en voiture, à bicyclette ou en traversant la rue par exemple.
- Manipulez l'appareil avec précaution et rangez-le dans un endroit propre, exempt de poussière.

• Avertissement ! La batterie risque d'exploser si vous la jetez au feu. Ne jetez pas votre appareil à des liquides ou à une flamme intensive.

• Ne l'exposez pas à des températures extrêmes. N'exposez pas la batterie à des températures supérieures à +60°C (+140°F).

• Ne tenez pas l'appareil à proximité d'une flamme ou d'une cigarette allumée.

• Évitez de laisser tomber l'appareil.

• Ne peignez pas ou n'essayez pas de démonter ou de modifier votre appareil. Toute intervention doit être obligatoirement confiée à un personnel agréé Sony Ericsson.

• Avant d'utiliser votre produit à proximité de stimulateurs cardiaques ou d'autres appareils médicaux, consultez le personnel médical compétent et lisez les instructions du fabricant de l'appareil concerné.

• Cessez d'utiliser les appareils électroniques ou désactivez la fonctionnalité d'émission radio de l'appareil lorsque vous y êtes invité.

• Utilisez avec votre produit dans des zones présentant un risque d'explosion.

• Ne placez pas votre appareil et n'installez pas d'équipements de télécommunication sans fil au-dessus des coussins de sécurité de votre voiture.

• Ne portez pas un attelage de sécurité lorsque vous êtes dans des bords tranchants ou des écarts au contact desquels vous risquez de vous blesser.

• N'utilisez pas votre oreillette Bluetooth dans une position inconfortable ou dans laquelle elle sera soumise à une pression.

• Attention ! Conservez hors de portée des enfants. Ne laissez pas les enfants jouer avec votre téléphone mobile ou ses accessoires. Ils pourraient se blesser ou blesser des tiers. Ces appareils peuvent contenir des petites pièces susceptibles de se détacher et de présenter des risques d'asphyxie.

Alimentation électrique (chargeur)

Ne branchez le chargeur que sur les sources d'alimentation indiquées sur le produit. Ne l'utilisez pas à l'extérieur ou dans des endroits humides. Ne modifiez pas le cordon et évitez de l'endommager. Ne branchez le chargeur avant de le nettoyer. Ne modifiez jamais la fiche. Si elle ne s'insère pas dans la prise, faites installer une prise adaptée par un électricien. Lorsque le chargeur est branché, il consomme une petite quantité de courant. Pour éviter cette faible perte d'énergie, débranchez-le une fois que vous n'avez plus besoin de charger.

• Ne portez pas de bijoux lorsque vous utilisez votre produit.

• N'utilisez pas votre oreillette Bluetooth dans une position inconfortable ou dans laquelle elle sera soumise à une pression.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

Appels d'urgence

Ces appels ne peuvent être garantis dans toutes les conditions. Ne vous fiez jamais complètement à votre téléphone mobile pour effectuer des communications essentielles. Il peut s'avérer impossible de passer un appel en n'importe quel endroit, sur toutes les réseaux cellulaires ou pendant l'utilisation de certains services réseau ou de certaines fonctions téléphoniques.

Antenne

L'utilisation d'antennes qui ne sont pas commercialisées par Sony Ericsson risque d'endommager votre téléphone, de réduire ses performances et de générer des niveaux de taux d'absorption sélective (SAR) supérieurs aux limites prescrites. Ne couvrez pas l'antenne avec la main, car cela risque d'affecter la qualité de l'appel et le niveau de puissance.

• Ne portez pas de bijoux lorsque vous utilisez votre produit.

• N'utilisez pas votre oreillette Bluetooth dans une position inconfortable ou dans laquelle elle sera soumise à une pression.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

• Attention - Utilisez la fonctionnalité GPS de façon à ne pas être distrait lorsque vous êtes au volant.

+5°C (+41°F) et +45°C (+113°F). Ne mettez pas la batterie en bouche. Ne laissez pas les contacts de la batterie toucher un autre objet métallique. Mettez l'appareil hors tension avant de retirer la batterie. Ne jetez pas votre appareil à des liquides ou à une flamme intensive.

• Ne l'exposez pas à des températures extrêmes. N'exposez pas la batterie à des températures supérieures à +60°C (+140°F).

• Ne tenez pas l'appareil à proximité d'une flamme ou d'une cigarette allumée.

• Évitez de laisser tomber l'appareil.

