



- CONTENU DU PACK:**
- Contrôleur Shadow 6 Wireless
 - Récepteur USB
 - Câble de chargement
 - Guide de l'utilisateur/Carte de garantie
 - Carte d'inscription

MISE À JOUR DU RÉCEPTEUR SANS FIL PS3:

Visitez <http://www.dreamgear.net> à chaque fois qu'il y a une mise à jour du micrologiciel du système PS3 pour voir s'il y a une version récente du pilote de votre récepteur sans fil.

Comment télécharger les fichiers de mise à jour:

1. Allez à <http://www.dreamgear.net>.
2. Allez à la page produits du produit acheté (tapez le numéro d'article dans le champ de recherche pour obtenir rapidement des résultats).
3. Suivez les instructions à l'écran pour télécharger le fichier sur votre PC.

REMARQUE: veillez à sauvegarder les fichiers téléchargés dans un dossier d'accès facile.

REMARQUE: à présent, le récepteur sans fil ne peut pas être mis à jour à partir d'un Mac.

Comment mettre à jour votre récepteur sans fil:

1. Insérez le récepteur sans fil à mettre à jour dans un port USB alimenté de votre PC.
2. Lancez le fichier exécutable (.exe) que vous avez téléchargé à partir du site web dreamGEAR.
3. Une fois le programme lancé, cliquez sur le bouton OpenFile et localisez l'emplacement du plus récent fichier de pilote que vous avez téléchargé à partir du site web dreamGEAR.
4. Sélectionnez et ouvrez le fichier du pilote de mise jour.
5. Cliquez sur le bouton Download.
6. Une fois le téléchargement terminé, la fenêtre Download Successful devrait apparaître. Appuyez sur OK ; cela indique que votre récepteur sans fil est mis à jour et prêt à l'emploi.

CHARGEMENT DE SHADOW 6 WIRELESS:

1. Le contrôleur Shadow 6 Wireless dispose d'une pile interne rechargeable. Pour charger le Shadow 6 Wireless, utilisez le câble de chargement USB inclus ou votre câble de chargement Sony USB d'origine.
2. Connectez le mini-câble USB au mini-port USB situé en haut du contrôleur Shadow 6 Wireless.
3. Connectez la fiche USB standard à n'importe quel port sur votre console de jeux PlayStation 3. Votre PlayStation 3 doit être sous tension pour pouvoir charger le Shadow Wireless. Le bouton du menu DG/PS3 clignote indiquant que le chargement a commencé. Lorsque le contrôleur est totalement chargé, le voyant cesse de clignoter.

REMARQUE: Vous pouvez utiliser n'importe quel port USB alimenté pour charger le Shadow Wireless.

CONFIGURATION DE SHADOW 6 WIRELESS:

1. Connectez le récepteur USB inclus à n'importe quel port USB sur la console de jeux PlayStation 3.
2. Appuyez sur le bouton de connexion sur le récepteur USB. La diode LED du récepteur clignote rapidement.
3. Appuyez sur le bouton du menu DG/PS3. La diode LED sur le récepteur et le contrôleur s'allument en continu lorsque le contrôleur est correctement synchronisé à la PlayStation 3.

CHARGEMENT EFFECTUÉ PENDANT UN JEU:

Le contrôleur Shadow Wireless peut être chargé pendant un jeu.

1. Pour charger le Shadow Wireless pendant un jeu, le câble de chargement USB et le récepteur USB doit être connecté à votre console de jeux PlayStation 3.
2. Pour pouvoir jouer et charger votre contrôleur Shadow Wireless, respectez les informations précédentes sur le chargement et la configuration dans ce guide d'utilisateur.

REMARQUE: Le Shadow 6 Wireless est compatible avec tous les jeux disposant de l'icône SIXAXIS. Pour utiliser, voir le guide de l'utilisateur du logiciel.

DÉPANNAGE:

Problème: Le Shadow 6 Wireless n'est pas connecté/clignotant.

Solution: Connectez le câble de chargement afin de recharger le Shadow 6 Wireless.



Problème: Le contrôleur Shadow Wireless ne fonctionne pas correctement.

Solution: Reconnectez le contrôleur en synchronisant le contrôleur et le récepteur. Si le problème persiste, appuyez sur le bouton de réinitialisation situé à l'arrière de Shadow 6 Wireless.

INFORMATION FCC

Cet appareil a fait l'objet de divers essais et il a été reconnu conforme aux limites concernant un appareillage numérique de la classe B, correspondant à la partie 15 des règles de la FCC. Ces limites sont conçues pour fournir une protection raisonnable contre les interférences nuisibles dans les installations résidentielles. Cet équipement génère, utilise et peut émettre de l'énergie radiofréquence et, s'il n'est pas installé et utilisé conformément aux instructions fournies, peut produire des interférences affectant les communications radio. Cependant, nous ne pouvons garantir qu'aucun brouillage ne se produira dans une installation particulière. Si cet équipement produit des interférences nuisibles sur la réception de la radio ou de la télévision, ce que vous pouvez facilement constater en éteignant et en rallumant l'équipement, nous vous encourageons à prendre l'une ou plusieurs des mesures correctives suivantes :

- Réorienter ou déplacer l'antenne réceptrice.
- Éloigner davantage l'appareil du récepteur.
- Connecter l'équipement à un circuit différent de celui auquel le récepteur est connecté.
- Contacter votre revendeur ou un technicien radio/TV qualifié.

Les changements ou modifications qui n'ont pas été expressément approuvées par la partie responsable de la conformité pourraient annuler l'autorité du propriétaire d'opérer l'équipement.

POUR ASSISTANCE TECHNIQUE
VEUILLEZ CONTACTER: 1-877-999-DREAM
ou support@dreamgear.net

iSound®

dreamGEAR®

WARRANTY CARD

You have purchased a quality product that has been subjected to a thorough series of tests to ensure the highest level of dependability and compatibility. It is unlikely that you will experience any problem but if a defect should become apparent during the use of this product, dreamGEAR warrants to the original consumer purchaser that this product will be free from defects in material and workmanship for a period of 120 days from the date of your original purchase. If a defect covered by this warranty occurs dreamGEAR, at its option, will repair or replace the product purchased at no charge.

This warranty does not cover normal wear and tear, abusive use or misuse, modification, tampering or by any other cause not related to either materials or workmanship. This warranty does not apply to products used for any industrial, professional or commercial purposes.

To obtain warranty service send the defective product postage prepaid, along with a copy of the original sales receipt showing purchase date to:

Attention: Returns Department
dreamGEAR, LLC
P.O. Box 478
Torrance, CA 90508

For further information please call our
Customer Hotline at 877-999-DREAM
(International customers please call 310-222-1045),
or visit our websites www.isound.net or www.dreamgear.net.
Please allow 4 to 6 weeks for processing.



PACKAGE CONTENTS:

- Shadow 6 Wireless Controller
- USB Receiver
- Charging Cable
- User's Guide/Warranty Card
- Registration Card

UPDATING THE PS3 WIRELESS RECEIVER:

Please visit <http://www.dreamgear.net> anytime there is a firmware update for your PS3 system to see if there is an updated driver for your wireless receiver.

How to Download the Updated Files:

1. Go to <http://www.dreamgear.net>.
2. Go to the product page of the purchased product (type in the item number in the search field for faster results).
3. Follow the on-screen directions on how to download the file to your PC.

NOTE: Make sure that the downloaded files are in an accessible folder or area for easy access.

NOTE: The wireless receiver currently cannot be updated on a Mac.

How to Update your Wireless Receiver:

1. Insert the updatable wireless receiver into a powered USB port on your PC.
2. Open the executable (.exe) file that you downloaded from the dreamGEAR website.
3. Once the program is open, click the OpenFile button and find the location of the most current driver file that you downloaded from the dreamGEAR website.
4. Choose the updatable driver file and open it.
5. Click the Download button.
6. After the download is complete, the Download Successful box should pop up. Press OK and you are ready to use your updated wireless receiver.

CHARGING SHADOW 6 WIRELESS:

1. The Shadow 6 Wireless controller features an internal rechargeable battery. To charge the Shadow 6 Wireless, use the included USB charge cable or your original Sony USB charge cable.
2. Connect the mini USB cable to the mini USB port located on the top of the Shadow 6 Wireless controller.
3. Connect the standard USB plug to any available port on your PlayStation 3 game console. Your PlayStation 3 must be powered "ON" in order for the Shadow Wireless to charge. The DG/PS3 menu button will flash to indicate charging has begun. When the controller is fully charged, the LED will become solid.

NOTE: You can also charge Shadow Wireless from any powered USB port.

SHADOW 6 WIRELESS SET-UP:

1. Connect the included USB receiver to any available USB port on the PlayStation 3 game console.
2. Press the connect button on the USB receiver. The receiver LED will flash rapidly.
3. Press the DG/PS3 menu button. The LED on the receiver and controller will become solid when the controller is properly synced to the PlayStation 3.

CHARGING WHILE PLAYING:

The Shadow Wireless controller can be charged during game play.

1. To charge the Shadow Wireless during game play, both the USB charge cable and USB receiver must be connected to your PlayStation 3 game console.
2. To play and charge your Shadow Wireless controller, please follow the previous charge and set-up portion of this User's Guide.

NOTE: The Shadow 6 Wireless is compatible with all games that feature the SIXAXIS icon. Please refer to your software user's guide.

TROUBLESHOOTING:

Problem: The Shadow 6 Wireless is not connecting/flashing.

Solution: Connect the charge cable to re-charge the Shadow 6 Wireless.

Problem: The Shadow Wireless controller does not function properly.

Solution: Reconnect the controller by performing a sync of the controller and receiver. If problems still persist, press the reset button located on the back of the Shadow 6 Wireless.

FCC INFORMATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experience radio/TV technician for help.

You are cautioned that any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



CONTENIDO DEL PAQUETE:

- Controlador Shadow 6 Wireless
- Receptor USB
- Cable de carga
- Guía del usuario/Tarjeta de garantía
- Tarjeta de inscripción

ACTUALIZACIÓN DEL RECEPTOR INALÁMBRICO DE PS3:

Visite <http://www.dreamgear.net> cuando haya una actualización de firmware para su sistema PS3 para verificar si hay un controlador actualizado para su receptor inalámbrico.

Cómo descargar los archivos actualizados:

1. Vaya a <http://www.dreamgear.net>.
2. Vaya a la página del producto adquirido (ingrese el número de artículo en el campo de búsqueda para resultados más rápidos).
3. Siga las instrucciones en pantalla acerca de cómo descargar el archivo a su PC.

NOTA: Asegúrese de que los archivos descargados estén en una carpeta o en una área accesible para un fácil acceso.

NOTA: Actualmente, el receptor inalámbrico no puede actualizarse en un Mac.

Cómo actualizar su receptor inalámbrico:

1. Inserte el receptor inalámbrico actualizable en un puerto USB activo en su PC.
2. Abra el archivo ejecutable (.exe) que descargó del sitio web de dreamGEAR.
3. Una vez que el programa se abre, haga clic en el botón OpenFile y encuentre la ubicación del archivo del controlador más actual que descargó del sitio web de dreamGEAR.
4. Escoja el archivo del controlador actualizable y ábralo.
5. Haga clic en el botón Download.
6. Después de que la descarga esté completa, el cuadro Download Successful aparecerá. Pulse OK y estará listo para utilizar su receptor inalámbrico actualizado.

CÓMO CARGAR SHADOW 6 WIRELESS:

1. El controlador Shadow 6 Wireless incluye una batería recargable interna. Para cargar el Shadow 6 Wireless, use el cable de carga USB provisto o su cable de carga USB Sony original.
2. Conecte el mini cable USB al mini puerto USB ubicado en la parte superior del controlador Shadow 6 Wireless.

FOR TECHNICAL SUPPORT PLEASE CONTACT:
1-877-999-DREAM
or support@dreamgear.net



PARA SOPORTE TÉCNICO
CONTACTE AL: 1-877-999-DREAM
o support@dreamgear.net

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.