IP-COM

Quick Installation Guide

802.11 AC Indoor/Outdoor Wi-Fi Access Point

IUAP-AC-M

The Quick Installation Guide tells you through how to store and how to perform first-time configurations. For product in-hand item details, please see its name, specification.

Package contents

Get to know your device

▶ LED indicator



LED Indicator	Status	Description
SYS	Light on	The system is starting up or is abnormal.
	Blinking	The system is normal.
	Off	The device is not powered on or the LED indicator is turned off.

▶ Port/button



Port/Button	Description
GND	GND terminal Used for ESD and lightning protection. Use a grounding cord and the nearest grounding screw to connect this GND terminal to the earth.
Reset	Reset button When the device is powered on, press and hold down this button for about 8 seconds, and then release it. When the SYS LED indicator flashes and then turns off, the device is restored to factory settings.
PoE/LAN	PoE/LAN port It is a gigabit PoE port used to supply power to network devices that support PoE and connect to a PoE switch or adapter and IEEE 802.3af/at-compliant devices.

Attach antennas

Tips
The ■ indicates the antenna is an omni ■ ; ■ indicates the antenna is directional.
Connect the ■ antenna to the ■ connector.

1. Remove and discard the two rubber plugs on the rubber gaskets remain in place.
2. Connect the antennas to the SMA connectors.

Note
Make sure the antennas are connected firmly to the corresponding connectors. Otherwise, the signal strength may be affected.



Install the device

Option 1 Wall mounting

Tips
Ensure the AP is near a network cable, ■ power socket, and ■ mounted location for the AP. Keep the ■ antenna, screws, and ■ anchors out of the way when it needs to be installed. Make sure the wall is sufficiently strong to withstand at least four times the weight of the AP.

1. Mark the drill ■ -mounted bracket at the target location on the wall with a pencil.
2. Ensure that the bracket is placed 90 degrees vertical to the ground and mark four holes.
3. Drill out the holes to a depth of 25 to 30 mm (0.98 to 1.18 inches).
4. Use a rubber hammer to knock the four plastic anchors (Length: 26.6 mm; Diameter: 6.6 mm) into the holes one by one.
5. Secure the wall ■ -mounted bracket on the wall by using the four screws (Length: 32 mm; Diameter: 4 mm).

6. Attach the AP to the wall ■ -mounted bracket by aligning the mounting tabs to the buckles of the latter.

7. Fix the pre-attached hex nut screw (Length: 12 mm; Diameter: 6 mm) and flat washer (Diameter: 13 mm) to the pre-attached bolt.



Option 2 Pole mounting

Tips
Ensure the pole is ■ , ■ secure, and ■ nearby a power socket and network cable.

1. Slide the wall ■ -mounted bracket down the pole to the desired height. Put the bracket away and keep it on it. You may need it should you change to the wall ■ mounting option.
2. Use the plastic strap to secure the AP onto the pole.



Lightning and ESD protection

Connect the GND terminal of the AP to a grounding terminal, connected the earth or building to protect the AP from over-voltage and overcurrent caused by lightning and ESD.

1. Connect one side of a grounding cord to the ■ -labeled GND terminal of the AP and tighten it.
2. Connect the grounding screw to the GND terminal of the AP, and tighten it.
3. Remove the cable grommet and then replace the port cover.
4. Connect the other side of the grounding cord to the grounding terminal connected to the earth or building.



Power the AP

Option 1 Connect to a PoE adapter

1. Connect the AP to the **PoE** port of the PoE adapter with an Ethernet cable.
2. Connect the **LAN** (network/computer) Connect an Ethernet cable from your LAN to the **LAN** port of the PoE adapter.
3. Connect the power cord to the adapter and then plug the power cord to a power source.



Option 2 Connect to a PoE switch

Connect an Ethernet cable directly from the AP to a PoE port on a PoE switch compliant with IEEE 802.3af/at. The switch will automatically supply power to the AP.



Configure your APs

You can configure the AP through the web UI of the AP, Ruijie Cloud, or the Ruijie Reyee APP. This chapter mainly describes the configuration methods of using the web UI and the Ruijie Cloud. For details about the Ruijie Reyee configuration method, refer to the user guides of target products.

Scenario 1: Through the iUniFi Controller

The network topology diagram for configuration through the Ruijie Cloud is as shown as follows. For details about how to configure APs through the Ruijie Cloud, refer to its user guide.



Scenario 2: Through the Web UI of the AP

❶ Connect devices

Connect the management computer to the switch to which the AP has connected. For details about how to connect other devices, see the following figure.



❷ Configure the IP address of the management computer (Example: Win10)

On the computer desktop, click **Start** > **Settings** > **Change adapter options**. Right-click **Ethernet**, click **Properties**, and double-click **Internet Protocol Version 4 (TCP/IPv4)**. Choose **Use the following IP address**, enter an IP address in the same LAN segment as the IP address (**192.168.0.254**) that is not occupied by other devices) and **Subnet mask** (**255.255.255.0**), and save the configurations.

❸ Log in to the web UI of the AP

Start a web browser on the management computer, and access **192.168.0.254**. Follow the on-screen instructions to login.

Then select **5GHz** from the **Radio Band** drop-down list and repeat the above operations.

Note
It is recommended to log in to the web UI of the AP with its MAC address.

❹ Modify the SSID and password

Choose **Quick Setup**, configure the **SSID** (WiFi name), **Security Mode** (**WPA2-PSK** is recommended), **Key**, and click **Save**.

❶ Modify the IP address of the AP

Choose **Internet Settings** > **LAN Setup**. Modify the IP address of the AP to 192.168.0.X (X: 2 to 253), and ensure that the new IP address has not been occupied in this network, then click **Save**.

Example:

You can set the new IP address of the first AP to 192.168.0.201, and the new IP address of the second AP to 192.168.0.202.

Done

WiFi name: The **SSID** you set in step 4 Modify the SSID and password.

WiFi password: The **Key** you set in step 4 Modify the SSID and password.

(Optional) AP wireless bridge

Tips
If you need to connect an AP to a network in a wireless manner, please refer to this chapter. The AP supports wireless bridge under only one radio band at a time. Those who have 2.4 GHz or 5 GHz is required. This chapter uses 2.4 GHz as an example for illustration.

❶ Connect devices

Connect the management computer to AP2. For details about how to connect other devices, see the following figure.



❷ Configure the IP address of the management computer & Log in to the web UI of AP2

Refer to steps 2 to 3 in **Scenario 2: Through the Web UI of the AP** in **Configure your APs**.

❸ Configure AP2

Set the **Working Mode** of AP2 to **Client+AP**, and click **Scan**.

Select the wireless network of AP1 and its **SSID**, **Security Mode**, and **Encryption Algorithm** are filled in automatically, which are **IP-COM_123456**, **WPA2-PSK**, and **AES** in this example. Enter the **Key** for the wireless network of AP1, and click **Save**.

❹ Check the bridge status

Choose **Tools** > **Diagnostic Tool**, and ping the IP address of AP1. If the IP address can be pinged, the bridge is successful. Otherwise, refer to **Q8** in **FAQ**.

FAQ

Q1. What should I do if I cannot access the web UI of the AP after entering 192.168.0.254?

A1. Try the following options:

- Check if your Ethernet cables are connected properly. If yes, the SYS LED indicator lights up.
- Ensure that the IP address of your computer has been set to 192.168.0.X (X: 2 to 253), and the IP address is not occupied by any other devices in the network.
- Clear the cache of your web browser, or replace the web browser.
- Disable the firewall of your computer, or replace the computer.
- If two or more APs are connected to the network without Ruijie Cloud enabled on its platform, you should leave only one AP in the network first and configure the AP's IP address. Then repeat this procedure to change the IP addresses of the other APs. Meanwhile, ensure that the APs' new IP addresses are in the same network segment with the IP address of the management computer. Then log in to the AP's web UI using their new IP addresses.
- The AP may be managed by Ruijie Cloud or the APP platform and therefore its IP address is no longer **192.168.0.254**. In this case, go to the web UI of the Ruijie Cloud or APP platform to view the new IP address of the AP, and then log in to the AP's web UI using the new IP address.
- If the problem persists, reset the AP.

Q2. How to reset my AP?

A2.

Option 1: Reset using the Reset button

When the **SYS** LED indicator of the AP blinks, hold down the **Reset** button for about 8 seconds. The AP is reset successfully when the SYS LED indicator flashes and then turns off.

Option 2: Reset using the web UI

Log in to the web UI of the AP, choose **Tools** > **Maintenance**, and navigate to the **Reset** section, then follow the on-screen instruction to reset it.

Note: Resetting clears all configurations of your AP.

Q3. What should I do if AP wireless bridge failed?

A3. Try the following options:

- Verify that the **Key** for the wireless network of the uplink device (AP1 in this guide) is correct.
- Check whether the signal of the wireless network of the uplink device (AP1 in this guide) is too weak. If so, move the AP (AP2 in this guide) closer to the uplink device AP1 in the guide.

CE Mark Warning

This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

The mains plug is used as disconnect device, the disconnect device shall remain readily operable.

NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.

RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.

User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

Declaration of Conformity

Hereby, SHENZHEN IP-COM Networks Co., Ltd. declares that the radio equipment type IUAP-AC-M is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: https://www.ip-com.com.cn/service.html

Operating Frequency:

2.4GHz: ETSI 2400&2483.5MHz (CH1~CH13)

5GHz: ETSI 5150~5250MHz (CH36~CH48)

EIRP Power:

2.4GHz: <28dBm

5GHz: <23dBm

Software Version: V1.0.0.3

Operating temperature: -10°C~50°C

Operating humidity: 10%~90% RH, non-condensing

Caution:

Adapter Model: EPA36A1220X

Manufacturer: SHENZHEN HENGFUHUA NETWORK TECHNOLOGY CO., LTD.

Input: 100~240V AC, 50/60Hz 0.5A

Output: 24V DC, 0.5A

NOTE: DC voltage

FCC Statement

The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules.

This equipment should be installed and operated with minimum distance 20cm between the device and your body.

Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Operating Frequency: 2412~2462MHz, 5150~5250MHz, 5725~5850MHz

NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.

For EU/EFTA, this product can be used in the following countries:

BE	BG	CZ	DK	DE	EE	IE	EL	ES	FR	HR	IT	CY	LV
LT	LU	HU	MT	NL	AT	PL	PT	RO	SI	SK	FI	SE	UK

Address: Room 101, Unit A, First Floor, Tower B3, NO.1001, Zhongshanyuan Road, Nanshan District, Shenzhen, China. 518052

Tel: (86755) 2765 3389

Email: info@ip-com.com.cn

Website: www.ip-com.com.cn

Copyright

©2020 IP-COM Networks Co., Ltd. All rights reserved.

This documentation (including pictures, images, and product specifications, etc.) is for reference only.

To improve internal design, operational function, and/or reliability, IP-COM reserves the right to make changes to the products described in this document without obligation to notify any person or organization of such revisions or changes.