DO NOT PRINT PINK DIELINE

VICTROLA™

MODEL: VTA-284B

7-IN-1 TURNTABLE

Important Safety Instructions 3
Product Overview 4
Setup / Basic Operation 5
Listening to a Vinyl Record 6
Listening to a CD 7
Listening to the FM Radio 8
Listening to an External Audio Device (AUX Mode) 9
Listening to an External Audio Device (Bluetooth Mode) 10
Listening to a Cassette Tape 10
USB Recording Operation 10
Maintenance / Proper Handling 11
Specifications 12
Troubleshooting Guide 13
FCC Statement and other warnings 15

Important Safety Instructions

WARNING: To prevent electric shock, do not use this (polarized) plug with an extension cord, receptacle or other outlet unless the blades can be fully inserted to prevent blade exposure.

WARNING: Invisible laser radiation when open and interlock failed or defeated. Avoid direct exposure to laser beam.
PRODUCT COMPLIES WITH DHHS RULE 21 CFR SUBCHAPTER J IN EFFECT AT DATE OF MANUFACTURE.

1. Read these instructions – • All the safety and operating instructions should be read before this product is operated.
2. Keep these instructions – • The safety and operating instructions should be retained for future reference.
3. Heed all warnings – • All warnings on the appliance and in the operating instructions should be adhered to.
4. Follow all instructions – • All operating and use instructions should be followed.
5. Do not use this apparatus near water – • The appliance should not be used near water or moisture – for example, in a wet basement or near a swimming pool, and the like.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding plug. A polarized plug has two blades with one wider than the other. A grounding plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at the plugs, convenience receptacles, and at the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart or rack is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug the apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15.

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
AVERTISSEMENT:
RISQUE DE CHOC ELECTRIQUE – NE PAS OUVRIR.

- The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of non-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.
- **CAUTION:** To reduce the risk of electric shock, do not remove cover (or back) as there are no user serviceable parts inside. Refer servicing to qualified personnel.
- The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance instructions in the literature accompanying the appliance.

16. This equipment is a Class II or double insulated electrical appliance, it has been designed in such a way that it does not require a safety connection to electrical earth.
17. The mains plug is used as disconnect device, the disconnect device shall remain readily operable.
18. To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture, The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall not be placed on apparatus.
19. Use the equipment in a moderate climate.

ACCESSORIES INCLUDED:
- 45 RPM ADAPTER
- INSTRUCTION MANUAL
- WARRANTY (BACK OF MANUAL)
- 45 RPM ADAPTER
- USB CABLE
- AUDACITY® SOFTWARE CD

Product Overview

Front View



1. **POWER** Push to turn the unit ON or OFF.
2. **"PHONO, CD, AUX, FM" SELECTION KNOB** Rotate to select your desired function.
3. **"FM", "" SLIDE SWITCH** Slide to select either FM or Bluetooth.
4. **3.5mm AUX IN JACK** Connects your external source to the AUX IN jack.
5. **PLAY INDICATOR** illuminates when CD is playing.
6. **STBT INDICATOR** Blue light flashes when the unit is waiting for pairing. Blue light stays lit when the external device is connected to the unit. Red light illuminates when station is received in stereo playing mode.
7. **PROGRAM INDICATOR** illuminates when the program playback is set.
8. **REPEAT INDICATOR** Red light stays lit when all tracks repeat. Red light flashes when a single track is repeating.
(Note: This indicator only works in CD mode.)

9. **LED DISPLAY**
10. **TUNING DIAL POINTER**
11. **STEREO SPEAKERS**
12. **BT OUT** Multi-function button.
13. **PLAY/PAUSE** Press to start playback, press again to pause.
(Note: This button only works in CD, Bluetooth mode.)
14. **OPEN/CLOSE** In CD mode, use to open and close the disc tray.
15. **DISC TRAY**
16. **"VOLUME" KNOB** Turn to adjust volume.
17/18. **NEXT/PREVIOUS TRACK & FFWD/REWIND** **(|◄◄ /►►|)**
Press to select the next track or skip to the next/previous track. Press and hold to fast forward/rewind.
(Note: This button will not work in PHONO, FM, AUX mode)
19. **"PROGRAM"** Press to set the program playback.
(Note: This indicator only works in CD mode.)
20. **"REPEAT"** Press to select the repeat mode.
(Note: This indicator only works in CD mode.)
21. **RADIO TUNER KNOB** In FM mode, turn to tune in a station.
22. **3.5mm EARPHONE JACK**
Accepts headphone/earphone plugs.

Right Side View



23. **CASSETTE FF & EJECT** Press fullway to fast forward, press all the way to end and eject the tape.

Rear View



24. **FM Wire Antenna**
While tuned to a station in FM mode, extend the wire and reposition to adjust for best reception.
25. **Line Out Jacks**
For amplifier device with RCA auxiliary input sockets, insert the white and red plugs on the RCA cable into the unit. Insert the opposite end into the amplifier device. Be sure to connect the white plug to the white jack and the red plug to the red jack.
26. **AC Power Cord**
Connect the AC plug into a **wall outlet.**
It is strongly recommended that this product should be operated only from the type of power source indicated on the marking label.

Parts of the Turntable



A. **Turntable.**
B. **Safety Screw (for transport)** Before using the unit, turn the screw **clockwise** using a coin or screwdriver.
Important: When you transport the unit, turn the screw counterclockwise to secure the turntable.
C. **Speed Selector.**
D. **Tone Arm holder.**
E. **Tone Arm.** Before use, completely loosen the twist tie on the tone arm and lift the tone arm to rest.
F. **STYLUS .**
G. **45 RPM adaptor.**
H. **Cue Lever.**

Setup / Basic Operation

Setup

1. Remove white protective needle cover by gently pulling towards front of unit.
2. Remove any packaging materials from the unit.
3. Connect the AC power cord to a **wall outlet.**

Note:
-It is strongly recommended that this product should be operated only from the type of power source indicated on the marking label.
-To prevent interference, avoid bundling audio signal cables together with the AC power cord.

Basic Operation

1. Push the POWER button to turn the unit on.
2. Select the source by turning the selection knob (PHONO/AUX/CD/FM/BT).
3. Rotate the VOLUME knob to adjust to the desired sound level.

Listening through RCA LINE OUT

For amplifier device listening, first reduce the volume level to minimum. Insert the white and red plugs on the RCA cable into the unit, then insert the opposite end into the amplifier device. Be sure to connect the white plug to the white jack and the red plug to the red jack.

Listening through Headphones (not included)

For private listening, first reduce the volume level to minimum.
Insert your headphones' plug into the 3.5mm jack, then adjust the volume up by turning the VOLUME knob.

Note: *The speakers will automatically be deactivated while headphones are plugged in.*

CONDENSATION WARNING:
When the unit is moved from a cold or warm place, or in a cool following a sudden temperature change, there is the danger that water vapor in the air may condense on the unit, preventing proper operation. In such cases, leave the unit for 1-2 hours after plugging it into an AC outlet to allow it to stabilize at the temperature of its surroundings.

Listening to a Vinyl Record

1. Before use, completely loosen the TRANSPORTATION SCREW by turning it clockwise with a coin or screwdriver**.** Detach the stylus guard (white plastic cover).
2. Turn the unit ON by pressing the POWER button.
3. Set the FUNCTION KNOB to the PHONO position.
4. Gently open the dust cover**.** Be careful not to pinch your finger**.**
5. Put the record on the turntable**.** Select the speed**.** When playing a 45 RPM record, use the included 45 adapter**.**
6. Gently push the CLAMPER to the right to release the TONE ARM**.**
7. Raise the CUE LEVER to lift the TONE ARM off the tone arm support**.**
8. Move the TONE ARM gently to the edge of the record (or the starting point of a track)**.** The turntable will begin to turn**.**

9. Gently lower the TONE ARM by slowly releasing the CUE LEVER**.** You can lower the TONE ARM manually if the CUE LEVER has not been raised**.**
10. Turn the VOLUME KNOB to adjust the volume**.**
11. When playback has finished, lightly lift the tone arm using the CUE LEVER and return it to the TONE ARM holder**.** The rotation stops**.**

Important:
- Closing the top cover will help prevent dust from settling on the turntable.
- Always remove the tone arm clip before transporting the unit.
- Do not place anything on top of the turntable cover, especially while playing a record.

Listening to a CD

1. Select 'CD' function.
(Note: The display will say "no" will appear on the display.)
2. Press the OPEN/CLOSE (▲) button.
(Note: This button only works in CD mode.)
3. Place a disc on the tray with the printed label face up**.**
4. Press the OPEN/CLOSE button (▲) to close the tray**.**
5. Press the PLAY/PAUSE button (►II) to begin playback**.**
(Note: The CD playback will start automatically.)
6. To temporarily pause playback, press the PLAY/PAUSE button (►II)**.** Press again to resume**.**
7. To skip tracks forward or backward, press the corresponding skip button (|◄◄ or ►►|)**.** Pressing |◄◄ once will restart the current track**.** Pressing |◄◄ twice in succession will return to the beginning of the previous track**.**
8. To stop playback, press the STOP ■ button**.** Once stopped, press and hold down the corresponding skip button until the desired position is reached**.**
9. To stop playback, press the STOP ■ button

Important:
- Never place more than one disc on the tray.
- The disc must be placed in the center of the disc tray. An incorrectly loaded disc can permanently damage the tray door mechanism.
- Do not push the CD tray – always use the OPEN/CLOSE button.
- Using a receiver for the unit to load a disc, during which all buttons will be temporarily disabled.

Repeat Playback

Each time the REPEAT button is pressed, the repeat mode will cycle through the following options:

REPEAT 1/Repeat one track)
The repeat indicator will flash and the current track will be played repeatedly**.** If you press the |◄◄ or ►►| button to select another track, the track you select will be played repeatedly**.**

REPEAT ALL (Repeat the entire CD)
The repeat indicator will stay lit and the entire CD will be played repeatedly**.**

Notes:
- Repeat playback works with CD discs only.

Programmed Playback

Up to 20 tracks can be programmed to play in the desired order**.**
Notes:
- Programmed playback works with CD discs only.

1. Select "CD" mode, then load a CD.
2. While the CD is stopped, press the PROGRAM button.
3. "PROGRAM" indicator lights up and "01" blinks on the display.
4. Press the |◄◄ or ►►| button to select a track number.
5. Press the PROGRAM button to confirm your program track. "02" appears and blinks.
Repeat steps 4 thru 5 to program the additional tracks.
6. When the selection of track numbers has been finished, press the PLAY button (►II) to start program playback.
(Note: When all 20 program tracks are set, you press PROGRAM button and "F-" will appear on the display)
7. To cancel the program mode, press the STOP (■) II the program indicator won't light.

To check the programmed order:
In the stop mode, press ("|◄◄ or ►►|) repeatedly to show the track numbers which have been programmed.

To add a track to the end of the programmed order:
In the stop mode, press the PROGRAM button**.**
Select a track number by pressing (|◄◄ or ►►|), then press the PROGRAM button**.**
The current track will be added to the end of the program**.**

Listening to the FM Radio

1. Select "FM" mode**.**
2. Slide the slide switch on "FM"**.**
3. Tune to the desired station using the Radio Tuner Knob**.**
Note: In FM Mode, the "STBT" indicator lights up red when tuning in the stereo reception station.

Adjusting for Best Reception
FM broadcast: Extend and reposition the FM antenna.

Listening to an External Audio Device (AUX Mode)

In AUX (auxiliary) mode, this unit can play audio from an external audio source (iPod, MP3 Player, Portable CD Player, etc.)

Playing via 3.5mm AUX-IN Jack on the Front of Unit:

1. Turn the unit ON by pressing the POWER button
2. Set the FUNCTION KNOB to the AUX position**.**
3. Connect the 3.5mm aux-in cable (not included) into the 3.5mm AUX-IN Jack to play an external audio source, such as CD player, tablet, MP3 player, etc.

LINE-OUT Jacks on the Back of Unit:

If you play this device through external powered speakers, you can connect the unit with an RCA component cable (included). Make sure to connect the white plug to white jack (left) and the red plug to the red jack (right).

Listening to an External Audio Device (Bluetooth Mode)

In BT (Bluetooth) mode, this unit can play music from external devices which have a built-in Bluetooth feature.

GETTING CONNECTED USING BLUETOOTH

1. Select "" mode**.**
2. Slide the slide switch on "" and the STBT indicator will flash blue**.**
3. Turn ON the Bluetooth function on your external device**.**
NOTE: *The effective distance between your external device and this apparatus is 10 meters (33ft).*
4. Wait for **"Victrola Ashford"** to appear on the paired devices list of your external device and press **"Victrola Ashford".**
5. When pairing process is complete will ask you a password**.** Fill in "0000" then press "OK" on your external device**.**
6. A few seconds later your Bluetooth connection is successful and the blue indicator stays lit**.**
7. Press the PLAY/PAUSE button (►II) to begin playback**.**
8. To temporarily pause playback, press the PLAY/PAUSE button (►II)**.** Press again to resume**.**
9. To skip to the previous or next tracks, press the corresponding skip button (|◄◄ or ►►|) to listen**.**
NOTE: *Stop, fast forward / rewind are only available on your external device.*

*The product supports Bluetooth wireless connection (**BT OUT**).*
*1. **BT OUT** is a Multi-function button (Page 4).*
2. When in AUX mode, long press this button to activate or cancel the program setting.
1. Turn the function knob to the PHONO, place a vinyl record on the turntable , then move the tone arm to desired playing position on the vinyl record , and press **"BT OUT"** button (The blue light will begin to flash) . Turn on your external Bluetooth receiver (such as Bluetooth headphones and Bluetooth speakers) and set to the pairing mode. When pairing is complete, you will hear a chime and the blue light will stop flashing. (this may take approximately 10-30 seconds) and the sound will be heard from the external Bluetooth speaker (You can ONLY adjust the volume from your external Bluetooth device)
Note:
1 Place the Bluetooth device within 1m (3.3') of the product to perform pairing correctly
2. Pairing process will be automatically cancelled if pairing is not successfully completed , follow the above steps again from the beginning after turning all device OFF
3. "BT OUT" is only compatible with vinyl record playback. BT OUT will NOT work in AUX or regular Bluetooth(BT) function modes.

Listening to a Cassette Tape

1. Load an audio cassette tape into the unit (located on the left side of the unit)**.** Playback will automatically begin**.**
2. Press button halfway to Fast Forward the tape**.**
Press button lightly and playback will resume**.**
3. Press button completely down to end playback and eject tape**.**

NOTE: *When loading in a cassette tape, the SELECTION KNOB function will be temporarily overridden until the cassette tape is ejected*

USB Recording Operation

To properly record your vinyl to MP3 via computer, use the included USB Output Cable and Instructional CD Software**.** Connect one end of the USB cable to the turntable (USB jack on the back of the unit) and the other end into your computer**.** Then connect the AC power cord to the turntable**.** To install and use the software on your computer, insert the Software or PC Installation CD into drive**.** Then follow the prompts provided on the Instructional CD**.** For the most up to date manuals, software, instructional details, troubleshooting or other downloadable content, please go to http://audacityteam.org

Maintenance / Proper Handling

Connect Non-Needles
- Always store the disc on the disc tray with the label side facing upward (compact discs can be played/recorded only on one side)
- When you need to turn its storage case, press down on the center of the case and lift the disc upward, holding it carefully by its edges.
- To clean a disc, wipe the surface from the center hole outward towards the outer edge with a soft, dry cloth.
- Never use such chemicals as record spray, antistatic sprays or lint, benzine or thinner to clean discs; they will irreparably damage the disc's plastic surface.
- Protect discs from direct sunlight. Make every use to protect from dust and scratches.
- Do not store discs in extremely high humidity or high temperature for extended periods of time.
- Printable CD-R and CD-RW discs are not recommended, as the label side may become sticky and damage the unit.
- Use a soft oil-based felt-tipped pen to write information on the label side. Never use a ballpoint or hard-tipped pen, as they may damage the label surface.
- Do not use irregular-shaped CDs (compact 8 heart-shaped, business card size, etc), as they will damage the unit.
- Read all precautions supplied with any CD-R or CD-RW disc.
- Never handle a disc with dirty fingers.
- Never insert a disc that has a crack on the surface.

Handling Vinyl Records
- Do not touch the record's grooves. Only handle records by the edges or the label with clean hands. Touching the record surface can cause poor sound quality to deteriorate.
- Before playback, always use a soft, anti-static cloth to gently wipe the record surface.
- Keep records in their protective sleeves when not in use.
- Always store records upright on their edges.
- Avoid placing records in direct sunlight, close to a heat source (radiators, stoves, etc.), or in a location subject to vibration, excessive dust, heat, cold or moisture.

General Care
- When removing the power plug from the wall outlet, always pull directly on the plug. Never pull the cord.
- To keep the lower pickup clean, do not touch it, and do not forget to close the disc tray.
- Do not attempt to clean the unit with chemicals such as this might damage the finish.
- Use a soft, dry cloth only to clean dirty parts.
- In order to shut off the power to this product completely, unplug the power cord from the wall outlet. Be sure to unplug the unit if you do not intend to use it for an extended period of time.

How to Replace the Turntable Stylus ***(Replacement Needle # (TNP-5))***
The stylus should last about 50 hours under normal use. However, it is recommended that the stylus be replaced as soon as you notice a change in sound quality. Prolonged use of a worn-out stylus may damage the record. The highest speed of 78 RPM records would wear out the stylus more quickly.

Removing the old stylus:
1. Set a screwdriver at the tip of the stylus and push downward (A).
2. Remove the stylus by pulling it simultaneously downward and forward.

Installing a new stylus:
1. Hold the front tip of the stylus and insert its rear edge (B) first.
2. Push the stylus upwards (C) until the tip locks into place.

Caution:
- *Do not bend the stylus.*
- *Do not touch the needle to avoid injury your hand.*
- *Turn off the unit's power before you replace the stylus.*
- *Keep out of reach of children.*

Specifications

GENERAL
Power Requirements ..... AC 120 V~ 60 Hz
Power Consumption 40W
Dimensions (W x H x D) ..... 350 x 256 x 340mm [13.8 x 10 x 13.4in (approx.)
Weight ..... 4.5kg [9.9lbs (approx.)

AMPLIFIER
Output Power ..... 3 W + 3 W
Frequency Response ..... 20 to 20,000 Hz

SPEAKER SYSTEM
Type ..... Dipole
Impedance ..... 8 ohms
Output Power 3Wx2W

FM Radio
Range ..... 88 to 108 MHz

CD PLAYER
Frequency Response ..... 20 to 20,000 Hz +2 dB
Signal-to-Noise Ratio ..... 80 dB (EIAJ)

CASSETTE PLAYER
Tape Speed ..... 4.75cm/s, 2-channel stereo
Wow and Flutter ..... 0.4% (WRMS)
Frequency Response ..... 100 to 6300 Hz +3 dB

RECORD PLAYER
Motor ..... DC servo motor
Drive System ..... Belt Drive
Speeds ..... 33 1/3 rpm, 45 rpm and 78 rpm
S/N Ratio ..... More than 50 dB
Cartridge Type ..... Ceramic Stereo Cartridge
Stylus ..... (TNP-5)

BLUETOOTH
Bluetooth Version ..... Bluetooth V5.0
Bluetooth Profile A2DP/AVRCP
Bluetooth Frequency 2402MHz-2480MHz
Operating Distance ..... 10 meters (33 ft.)

Troubleshooting Guide

	Symptom	Possible Cause	Solution
GENERAL	• Unit will not power on.	• Unit is unplugged.	• Connect the unit to the AC power supply.
	• No sound output from speakers.	• The volume level is set too low. • The input selection does not match the playback source.	• Adjust the volume. • Select the correct input source.
	• Noise/Distortion in sound output.	• The unit is too close to a TV set or another interfering device.	• Turn off the TV or other appliance, and relocate the unit.
	• Unit fails to respond.	• It might result from external factors such as ESD (Electro-static discharge).	• Disconnect the power cord and external audio device. Re-plug the power cord and turn on the unit.
TAPE	• The tape does not play.	• The cassette tape is not inserted properly. • The tape has reached the end.	• Insert the cassette tape correctly. • Flip the cassette.
FM RADIO	• Cannot listen to any station, or signal appears weak.	• The station is not tuned-in properly. • A TV set is being used nearby and is interfering with the radio reception.	• Properly tune-in the desired station. • Turn off the interfering TV set.
	• The sound is distorted.	• The antenna is not oriented properly.	• Re-orient the antenna until reception improves.
CD PLAYER	• CD stops immediately after starting, or unit pauses or skips during playback.	• The CD is inserted upside down. • The CD is dusty or dirty or there is condensation on the CD.	• Insert the CD with the printed side right-side up. • Carefully clean and dry the CD.
	• No sound.	• The CD player is paused.	• Press the PLAY/PAUSE button.
	• CD playback is noisy, or playback stops or skips.	• The CD is scratched, damaged or warped. • The disc is very dirty.	• Replace CD with an undamaged one. • Carefully clean the CD.
	• CD tray will not open.	• AM/FM mode is selected.	• Select AUX, PHONO, CD, or TAPE mode.
	• Buttons are not functioning correctly.	• The unit is processing information ("— Busy" is displayed) • The unit needs to be restarted	• Wait until the unit finishes processing. • Turn the unit off, then on again.
PHONO	• Decline in turntable audio performance	• The turntable stylus is worn out	• Replace the stylus.
AUX	• No sound output with external audio device plugged into rear AUX in jack.	• Both AUX in jacks (front and rear) are plugged.	• Unplug the front AUX in jack.
Bluetooth	• No sound	• The unit is not switched to Bluetooth mode • Your device's and/or the unit's volume is not turn up. • Your device is too far from the unit or there're some obstacle between your device and the unit	• Ensure the unit is switched to BT mode. • Move your Bluetooth device closer to unit • Turn up the volume on your portable device and the unit • Turn OFF your Bluetooth device and unit, Then power them both back ON
	• Sound has a bit of static	• Your device in too far away	• Bring your device closer to the turntable
	• Unable to pair with a Bluetooth device	• Your device doesn't have Bluetooth connectivity. • The Bluetooth pairing is not successful.	• Confirm that your device is Bluetooth compatible. • Re-pair the unit and device again.

Please note: As a result of continual improvements, the design and specifications of this product are subject to change without notice.

Made in China.

Bluetooth is a registered trademark of Bluetooth SIG, Inc.
Other trademarks and trade names are those of their respective owners.

FCC WARNING

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.FCC IC Radiation Exposure Statement

This equipment complies with FCC and IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

IC WARNING

•English:
This device contains (licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference, and
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

•French
Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. L'exploitation est autorisée aux deux conditions suivantes:
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
Cet appareil est conforme à FCC et IC l'exposition aux rayonnements limites fixées pour un environnement non contrôlé. Cet appareil doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps. Cet transmetteur ne doit pas être co-situé ou opérant en liaison avec toute autre antenne ou transmetteur.

Warranty

United States
Victrola Innovative Technology Electronics, LLC warrants to the original retail purchaser that this product will be free from defective materials and workmanship for one (1) year from the date of purchase, subject to the limitations below. This warranty period is not extended if we replace the product. To obtain a replacement under the terms of this warranty, you must contact the dealer from which it was purchased with your original receipt. If assistance from the dealer from which it was purchased is impossible, you may contact our customer service for warranty assistance at victrola.com/contact.

Except as limited below, if the product proves defective in either material or workmanship within one (1) year from the date of purchase, Victrola will replace the product at no charge**.** If the product model is no longer available and cannot be replaced with an identical model, Victrola will issue a merchandise credit for the purchase price to be redeemed at victrola.com.

Limitations:
- This limited warranty does not cover failure of the product arising, in whole or in part, from improper installation, storage, transportation, misuse, abuse, accident, neglect, mishandling, unauthorized repair, modification, or wear from ordinary use or environmental deterioration.
- This limited warranty does not cover cosmetic damage, including paint damage, or consequential damage to other components or premises which may result for any reason from the failure of the product.
- This limited warranty is null and void for products not used in accordance with Victrola's instructions.
- This limited warranty terminates if the original retail purchaser sells or otherwise transfers this product.
- This limited warranty is null and void for defects or damage caused by installation or repair performed by any person or entity other than a Victrola authorized installer or dealer.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state, jurisdiction to jurisdiction or country to country**.** All express and implied warranties for the product, including but not limited to any implied warranties of merchantability and fitness for a particular purpose, are limited in time to the term of this warranty**.** Some states, jurisdictions or countries do not allow the exclusion of certain implied warranties or conditions, or limitations on how long an implied warranty or condition lasts, so this limitation may not apply to you**.** Victrola's responsibility for malfunctions and defects in hardware is limited to replacement or repair as set forth in this warranty statement**.** Victrola does not accept any liability for any damages whatsoever, including but not limited to damages to other real or personal property, and, without limitation, any liability for third party damages or loss by reason of losses or for products not being available for use**.** The maximum liability for which Victrola may be responsible will be no more than the amount you paid for the product that is the subject of the claim**.** Some states, jurisdictions or countries do not allow the exclusion or limitation of special, indirect, incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Canada and US Territories
The Warranty on this product shall comply with applicable law when sold to a consumer in Canada or a US Territory. To obtain any applicable warranty service, please contact the dealer from which you purchased the product. You should contact the dealer from which you purchased the product, with your original receipt. If assistance from the dealer from which it was purchased is impossible, you may contact our customer service for warranty assistance at victrola.com/contact. If this product proves defective in either material or workmanship, Victrola will replace the product at no charge**.** If the product model is no longer available and cannot be repaired effectively or replaced with an identical model, Victrola at its sole option may replace the unit with a current model of equal or greater value.

Outside the U.S, Canada, and US Territories
The Warranty on this product shall comply with applicable law when sold to a consumer outside of the United States, Canada, and US Territories. To obtain any applicable warranty service, please contact the dealer from which you purchased the product, or the distributor that supplied the product, with your original receipt.

204B220506E