USER GUIDE

Wireless Combo


① Keyboard number lock indicator
② Keyboard caps lock indicator
③ Keyboard lower power indicator
④ Keyboard battery compartment
⑤ Mouse left key

⑥ Mouse right key
⑦ Mouse scrolling wheel
⑧ DPI button
⑨ Mouse on/off switch

● Resolution: 800-1200-1600DPI
● Press Fn key and the multimedia key simultaneously to realize the multimedia funtion.

01

1. Take out the batteries from the color gift box, and peel off the plastic film.
2. Open the battery cover at the bottom of the mouse and keyboard.
3. Take out the nano receiver from the mouse.
4. Put the batteries in the mouse and keyboard in correct direction by following the sign of position.
5. Slide the power switch to position <ON>, and then close the battery cover.

02

6. Insert the nano receiver into spare USB port of the computer, the keyboard and mouse will connect with computer automatically.

Mouse not working

1. Ensure your computer is compatible with the system requirements.
2. Ensure the mouse receiver is connected to the USB port.
3. Check if your mouse is power on.
4. Ensure your batteries are charged and replace them when necessary.
5. Ensure that there is no metal material between your mouse and the receiver.
6. If you are using USB hub, please directly insert the receiver into the USB port of your computer.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.