Smart Bracelet

User Guide

ID130S

English Version ——01

日本語バージョン ——16

Thanks for choosing our device, please read the user guide carefully before using.

Setting

Use VeryFitPro on iOS or Android smart phone to set the wristband as follows:

Note: hardware and system of devices should meet the requirements:

iOS 8.0 & Above　Android 4 & Above　Support Bluetooth 2

1. Download VeryFitPro

Search and download

Search and Download "VeryFitPro" from the Apple Store or Andrioid Store.

Scan the QR code and download

It probably has a problem to open the link with WeChat or other scan tools, please copy the link and open it through browser.

2. Product activation and installation

The product must be activated by charging before initial use, and then charge the product to ensure normal power supply. The hand ring will automatically power on.

Take out: Pull open the strap and take out the bracelet body

Charge the battery: Insert the clip-mounted end of the bracelet body into the USB interface to activate the product by charging (be cautious not to reverse the connection) and comply with the required voltage and current: 5V / 500mA

Installation: Mount the bracelet body into the slot of the wrist strap.

Wear on: Adjust the length of the wrist strap until it is appropriate to wear on the wrist

3. Touch key

When selecting the right band from the search list, please slide the screen of wristband to wake up the device and then complete connecting.

Know your Device

1.Wearing Method

Wear the device on your wrist horizontally, about 2cm to sarpal,the same method as wearing watches.

2. Heart Rate Monitoring

To monitor Heart Rate more accurately, please wear the device on the upper arm or upper wrist and a tighter than usual when you are taking exercise

3. Heart Rate Monitoring

Automatic heart rate Monitoring is ON as default, monitor Heart Rate 4H for this automatically.

4. Interface

Click the touch key to display excessively

Function Introduction

1.1 Time Mode

Instructions
Time dial can be switched as follows:
APP Devices Mode>
Click the touch key(1s) to enter the next mode:
Data Mode
(you can customize the shortcut through the app)

1.2 Data Mode

[Click the touch key(1s) to enter the next mode:
Steps Mode
[Press and hold the touch key for 2s]
to enter the sub-mode of "Data Reading"

1.2.1 Data Reading Sub-Mode

Note: To go back to the Data Reading Mode by clicking the touch key on the final interface of Data Reading Sub-Mode

1.3 Heart Rate Mode

Note: Upon staying at the Heart Rate interface for 1s, start to monitor the heart rate, and a flg. like ,---,is displayed behind the correct data is monitored, and upon the correct data being monitored, data is displayed; [Click the touch key] to enter the next mode: Alarm Clock Mode

1.4 Alarm Clock Mode

Note: Alarm clock function should be turned on in App for the alarm clock to be displayed.

[Click the touch key] to enter the next mode:
Sports Mode
[Press and hold the touch key for 2s]
to enter/close alarm clock

[Click the touch key] to enter the next sub-mode of "Sports Underway"[Press and hold the touch key for 2s] to enter any interface of Data Reading, press and hold 2s to exit the sports mode.

Note: The speed and distance of riding can be displayed, but App need to be connected and the riding data synchronized to the App to be seen.

1.5.3 Sports Stop Mode

1): If the sports last less than 1 minute, the user will be reminded of not saving the data.

[Click the touch key] to enter the main interface of sports mode (the data reading interface of sports data display mode is not displayed)

2): If the sports last more than 1 minute, the Sports End Reminder will be displayed

[Click the touch key] to enter the sports data display mode

1.5 Sports Mode



1.5.1 Sports Start Mode

After the countdown interface of 5-2-1-GO, the sports underway mode.

1.5.2 Sports Underway Mode

[Click the touch key] to enter the next sub-mode of "Sports Underway"[Press and hold the touch key for 2s] to enter any interface of Data Reading, press and hold 2s to exit the sports mode.

1.5.4 Event Reminder in Sports Mode

1): Reminder of exiting from sports mode upon a period of no activity

[Click the touch key] to remove the reminder of exiting from sports mode.

Note:
1.If there is no any activity in a period (15 minutes), reminder will be displayed 15s before it stop.
2.Non-activities will remove the reminder of automatic exiting from sports mode.
3.If there are no any new operations before the end of the countdown of automatic quiting from the sports mode, it will exit from the sports mode.

2): Reminder of full-term time quit

[Click the touch key] to confirm the full-term Force Quit

Note: When the memory of vmid stop is full of sports data, the user will be reminded of exiting from the Sports Mode

3): Reminder of force quit for low-battery

[Click the touch key] to accept the force quit from the sports mode

Note: During the sports activities, when the power is low, the sport mode will pause, and remind the user of force quit from the sports mode.

4): Reminder of inaccessable sport mode for low-battery

[Click the touch key] to accept the inaccessible sports mode for low-battery

Note: The reminder will occur when a user tried to start the sports mode with the battery of lower 15%.

1.5.5 Abnormal operations during activity

The reminder will be available soon

[Click the touch key] to quit from the reminder waiting mode

1. Camera mode control

Music Control:
1. Press and hold the touch key to exit from the camera mode
2. Exit through App will make the wrist strap quit from the camera mode.

2. More modes of reminders

1) Call Reminder

Click the touch key to remove the call reminder
Press and hold the touch key for 2s to quit

Note: The call reminder in the App needs to be set open.

2) Message Reminder

In case of pages of messages, Click the touch key to read the remaining text

Note: The relevant settings need to be done in the App.

3) Alarm Clock

Alarm Clock: The relevant settings need to done in the App.

Alarm Clock Types

4.Long Sitting Reminder

Alarm Clock Reminder: The relevant settings need to be done in the App. Note: The clock bar: It will remove the reminder.

5) Target completion reminder

When some goals are achieved, shake the wrist band to remind the target completion reminder: displayed Click the touch key to quit from the reminder

6) Set battery reminder

7) Device Error Notification

Note: When the device is detected with an abnormality, the interface herein will be displayed each time the device is operated.

Status Code:
-01 means the abnormality of acceleration sensor
-02 means the abnormality of heart rate sensor
-03 means the abnormality of touch key
-04 means the abnormality of flash

Basic Specifications

Model No.: ID130S
Battery Capacity: 50mAh
Working Voltage: 3.7V
Host weight: about 23.5g
Size: 35mm*12.5mm
Working temperature: -20℃ -45℃
Charging time: 2h
Working Time: 7days
Product frequency band: 2402-2480MHz
Maximum transmit power: 0dBm

Declaration of toxic and hazardous substances in electronic information products

The device meets the EU RoHS criterion, Please refer to EU 2015/863, EU RoHS Directive 2011/65/EU and revised.

Wearing and Maintenance

Our products are designed for you to wear throughout the day. So please follow a few best practices when you are wearing and maintaining your smart devices. To keep your wristband clean and your skin comfortable, we put forward the following tips:

◆Regularly clean your wrist and the smart wristband, especially after sweating in the exercise or being exposed to sweaters such as soap or detergent which may attach on the internal side of the wristband.

◆Do not wash the wristband with household cleaner.Please use soapless detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.

◆For sports or stains that are not easy to remove, scrub with alcohol and then follow the above steps.

FAQ

◆ Failed to find the device when pairing

Make sure the Bluetooth of smart phone is ON, and smart phone OS Android 4 & Above, iOS 8.0 & Above.

◆ Make sure the distance between phone and device is within Bluetooth range. Keep the Bluetooth connection within distance range within 10meter (after pairing finished).

◆ Make sure the device is not under low battery; if there is still a problem after fully charged, please contact us.

◆ Failed to connect with Bluetooth occasionally

Caused by the abnormality of Bluetooth service when it crashes on the phone.

◆ Restart mobile phone or re-start the Bluetooth service, then it works normal.

◆ How to restore factory defaults

Make sure the device is connected with smart phone, go to the App, enter "device—System setting", and choose "reboot device".

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

CAUTION
RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

Old electrical appliances must not be disposed of together with the residual waste. Instead, they must be separately. The disposal of the consumed collecting point or recycling centre. The first-hand retailer is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and the treatment of toxic substances.

スマート心拍ブレスレット

取扱説明書

ID130S

iOS 8.0 以上/iOS　Android 4.0 以上
Android 4.0以上

Android 4.0 以上　ブルートゥース4.2
サポート

本製品をご利用いただき、誠にありがとうございます。
まず、ご使用前に本取扱説明書をよくご覧下さいませ。

一、プレスレットの設定

iOS及びAndroid搭載のVeryFitProアプリケーションでプレスレットを設定(設定ガイド)手順は以下の通りとなります。

推奨：故障システムハードウェアプラットフォームは以下の条件を満たすもの

iOS 8.0 以上/iOS　Android 4.0 以上
8.0以上/ブルートゥース　Android 4.0以上

ブルートゥース4.2
サポート

1.VeryFitProをダウンロードする

方法①：キーワードを検索してアプリのダウンロードする

Apple Store及びGoogleプリのアプリ"VeryFitPro"を検索してアプリをダウンロードする。

方法②：ニホンエコーをスキャンしてダウンロードします。

ウェーチャット及びそのためスキャンツールでにてインプタ上へ次のアプリのダウンロードリンクを開けない場合があるため、これら方法でレベルアップ中にご知ってください。

2. 製品のアクティベーションと取付け

初めてご使用の製品は充電して製品をアクティベーションし、それから充電し、普段通りの使用時に、プレスレットは自動的にパワーオンします。

製品に、パンドを引張して、プレスレットを本体を取り出します。

チップ取付(内部データ)をにしたい、充電します
(使用しを行は変ていない、電圧電流要求：5V/500mA)

取付け：プレスレットを本体を取パンドカード側に取付ます

装着：パンドの端で先端を長様無を長装着します。

3. タッチボタン

シングルクリックをクリックすると、プレスレットを起動を表示します。

ダブルクリックを長押しすると、入力を表示

4. VeryFitProアプリを開いて、マッチングを完成させます。

携帯電話のブルートゥースを開いて、VeryFitProアプリを開き、自動検索で他のプレスレットを検索し、プレスレットを選択してペアリングを完成させるとペアリングし、パンドが表示されます。

プレスレットを知る

1. 装着方式

プレスレットを腕に合わせて行ません。腕表の(Open)ことに似ず腕を1～2指分の幅の位置に装着します。

2. 心拍数モニタリング

心拍数センサー搭載されたことに伴いなるために、運動時にプレスレットを心拍の測定値を表示します。普段さや中をつかむ心拍数を測ります。

3. 心拍数測定

プレスレットはデフォルトと日常の心拍測定機能をオンし、一日中心拍数の心拍数を測定します。

[クリックボタンをクリックすると]
[プレスボタンを長押し]
[2sはエクスポートのモードに入ります]
[データ・ロードモード]

4. インターフェース説明

ラックボタンをクリックして目標達成に表示します

1.2.1 データ・チェックモード

[クリックボタンをクリック]を[2s]のモードにしたら、
[データ・ロードモード]を[データ・ロードモード]を[2s]
[クリックボタンをクリック]

1.3 心拍数モード

データ・ロードなる前　データ・ロードなる後　0-5秒に収集

説明：心拍数インターフェースにはなるとまったく表示、心拍数センサーは、ユーザーの心拍数を測定するまで待ちます。心拍数データを測定した後に、心拍数データを表示します。
[クリックボタンをクリック]を[2s]
アプリ・ムーブ・[Alarm Mode]

1.4 アラームモード

説明：appにアラーム機能を設定しているから、表示されます。

[クリックボタンをクリックすると]
[プレスボタンを長押しすると]
[2sはエクスポートのモードに入ります]
[データ・ロードモード]

1.5 運動モード

ボックスクッションがしたスタートする

1.5.1 運動開始モード

運動開始インターフェースにたったます。
3-2-1のGOの後に、運動進行中のインターフェースに入ります。

1.5.2運動中モード

[クリックボタンをクリックすると]
[プレスボタンを長押しすると]
[2sはエクスポートのモードに入ります]
[データ・ロードモード]

1.5.3運動終了モード

[クリックボタンをクリックすると]
[プレスボタンを長押しすると]
[2sはエクスポートのモードに入ります]
[データ・ロードモード]

1.5.4 運動時の事件注意

1) 動かない、運動モードから自動すると ないから知ら。

「タッチボタンをクリックする」を[長押し]運動モードからにスタートする。
[長押しボタンをクリックする]を[長押し]運動モードを[2s]
[長押しボタンをクリックする]を[長押し]運動モードを[2s]

説明：APPに接続したら、ECAPPを[ボ]ボタンを[ボ]クリックを[長押し]運動モードを[2s]
[長押しボタンをクリックする]を[長押し]運動モードを[2s]

説明：運動モードの間はAPPを接続する場合、APPの[運動]を[ボタンを]を運動の種類[ボ]、ボタンの[運動]を[ボタンを]を[長押し]運動モードを[2s]

2) 運動時間が一定時間で不足は、ユーザーにデータを保存しないと知らます。

「タッチボタンをクリックする」運動インインターフェースにたったます。[運動]ボタンを[長押し]を[2s]
[長押しボタンをクリックする]を[長押し]運動モードを[2s]
[長押しボタンをクリックする]を[長押し]運動モードを[2s]

3) 運動時間が一定時間で不足は、運動モードを自動で終了します。

[長押しボタンをクリックする]を[長押し]運動モードを[2s]
[長押しボタンをクリックする]を[長押し]運動モードを[2s]

説明：運動モードは、プレスレットを動かせなり[ボタンを]を[長押し]、ユーザーは運動モードから自動終了を知ります。

3) バッテリーの電力が低下で、運動モードから強制的に表示することをいます。

「タッチボタンをクリックする」電力が[ボタンを]を[長押し]運動モードを[2s]
[長押しボタンをクリックする]を[長押し]運動モードを[2s]

説明：運動進行中、電力が低い場合、運動を一時停止して、電力が[ボタンを]を[長押し]運動モードを[2s]

「タッチボタンをクリックする」待っていると言い知らせなりを出ます。

1.撮影制御モード

ハ左右に APPでいち、録画の前の前に録画モードを[ボタンを]を[長押し]を[2s]
[長押しボタンをクリックする]を[長押し]を[2s]

説明：APPで音切りを切り[ボタンを]を[長押し]を[2s]

2.メッセージの出力

複数ページのメッセージ[ボタンを]に、タッチボタンをクリックすると、残りの文を表示します。
説明：APPで設定することが出来ます。

3) アラームお知らせ

アラームお知らせ。APPにて設定お使です

アラームをイプ：

4) 長時間座り続けるお知らせ

長時間座ってタイムいらっしゃいます。

7) 機種異常のお知らせ

説明：表現の異常が発見されれば、表現異常を表示し、このインターフェスが表示されます。

状態コード：
-01加速度センサー異常を表示異常です。
-02心拍数センサー異常を表示異常です。
-03タッチ異常を表示異常です。
-0flashを表示異常です。

製品パラメター

型番号:ID130S
電池容量: 50mAh
作動電圧: 3.7V
本体重量: 23.5g
サイズ:35mm*12.5mm
動作温度: -20℃ -45℃
充電時間: 2h
動作時間: 7日間でいい
製品周波数: 2402-2480MHz
最大発射電力値: 0dBm

電子情報製品有害有害物質の声明

RoHS

本製品は欧州連合RoHS指令第1部に、および2011年6月8日の欧州議会および理事会の指令2011/65/EUの修正指令を考慮したものであることを声明致します。

毎月と保守

当社の製品は、1日中着用することに設計されていますので、スマートブレスを着用し、保守する際に、いくつかの事を注意してください。

◆ 手首および腕のスマートブレスレットを定期的に洗浄してください。特に表面保存、および表面にのみ、石鹸を含む中性洗剤を使用してください。

◆ 石鹸洗剤または、ビニール、ゴム、および、ポリ、ポリ、ポリ