RA-BOOM

DESIGNER
S FROGGATT

ISSUE DATE
22/05/2023

FACTORY
GELITE

DIMENSIONS
H - 80MM
W - 70MM

PAPER TYPE
ART PAPER

FOILS / SPECIAL FINISHES
MATT VARNISH, COLOUR IMAGE WITH SPOT UV GLOSS LOGO & TEXT WITH FOIL DETAILS

Peers Hardy Group

70MM

80MM

THANK YOU FOR CHOOSING REFLEX ACTIVE!

We know you want to get straight to the music, but please take a minute to read these instructions, they'll help you get the most from your Reflex Active product.

COME JOIN US OVER ON SOCIAL!

REFLEX_ACTIVE
REFLEX_ACTIVE

TAG US IN YOUR PHOTOS! #REFLEXACTIVE



FEATURES

1. Power switch
2. AUX in
3. TF card port
4. USB port
5. Type C charging port
6. MIC port
7. Light button
8. Mode button
9. Previous/vol-
10. Play/Pause
11. Next/Vol+
12. Bass

POWER ON/OFF

1. Turn the POWER switch to "on", the LED indicator lights up blue for 3 seconds.
2. Turn the POWER switch to "off".

BLUETOOTH MODE

1. Turn on the Bluetooth speaker. The product is on with Bluetooth mode and enters pairing mode.
2. Then activate Bluetooth on your phone and search for "REFLEX ACTIVE". Click manually to connect.
3. The speaker will automatically reconnect to the last paired device. When the Bluetooth of your device turns on (just turn on the speaker), it will automatically reconnect.

PLAYING MUSIC & VOLUME CONTROL

1. Short press the Play/Pause to pause/play
2. Long press the "-" for PREV
3. Long press the "+" for NEXT
4. Short press the "-" for VOL-
5. Short press the "+" for VOL+

MODE SWITCHING

1. Short press MODE switch to select mode, (Bluetooth/TF/FM/BOOTH/AUX) ect

AUX MODE

1. Connect your phone/music player to the speaker via the provided dual 3.5mm audio cable, then the speaker will automatically recognise it.

USB MODE

1. Insert a USB stick, the speaker will automatically broadcast music in it.

TF MODE

1. Insert a TF card, the speaker will automatically recognise and broadcast MP3 format music in it.

FM MODE

1. Press MODE button on the speaker to switch to FM mode.
2. Short press the "PLAY/PAUSE" button once to enter automatic FM channel searching.
3. Long press ⏮ and ⏭ to select the desired channels, This may take 1-2 minutes.

MIC FUNCTION

1. Insert a microphone (4.25mm) to the mic jack to enter mic function.

BASS

1. When playing music, click "BASS" button to switch bass effects, Click again to cancel bass effects.

LIGHT MODE

1. Turn on the speaker, click the LED button to switch lights mode, (Not available under FM mode).

CONNECTING TWO BOOM SPEAKERS

You can connect two Boom speakers as a pair for stronger stereo and surrounding effect.
1. Make sure the Bluetooth function is OFF on your Bluetooth player.
2. Turn on the two speakers.
3. Long press PLAY/PAUSE button on one of the speakers 3Sec will be the main speaker), both speakers will enter TWS pairing status, bird LED of the main speaker flashes blue and the LED of the auxiliary speaker turns blue, the TWS connection is successful.
4. Then activate the Bluetooth on your phone and search for "REFLEX ACTIVE". Click manually to connect.

CHARGING

This product has a built-in non-removable and rechargable battery, please use the provided Type C cable to charge.
The power LED indicator turns red when charging and goes out when fully charged.

Any Changes expressly or modifications not approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference,
and (2) this device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
This equipment should be installed and operated with minimum distance 20cm between the radiator & you body.

SPECIFICATIONS

SPEAKER / 4"

Output Power / 2.08x80hm
Battery / 3.7V/2000mAh
Frequency Range / 100Hz-18KHz
Wireless Range / 10m
Charging / Type C
Input Voltage / 5V/1A
Support / BT, TWS, AUX, TF, USB, FM, MIC Jack
Product Size / 165 x 155 x 200mm approx

CARING FOR YOUR SPEAKER

Please follow these simple instructions to keep your speaker looking & sounding great!

- Clean product with a damp cloth & mild soap.
- Not designed to be submerged in water, should this occur product will malfunction.
- Keep away from steam & dust as these may affect quality of performance.
- Avoid excessive heating / burning of charging cable as this can cause malfunction.
- Contains no serviceable components, Do not attempt to open the speakers or the casing as this may cause harm.

- Keep away from strong magnetic fields to avoid interference.
- Please charge the product with input power below 9V/1A, in order to protect the battery.
- Please do not use this product in or near water.
- Please store or use the product in a normal temperature environment.
- Please keep the product from heat source, such as radiators, hot air regulators, stoves, or other heat generating instruments.
- Don't join the parts of the product, such as charge port, LED port and microphone etc.
- In order to protect your hearing and extend the speakers service life, it it not recommended to adjust the volume to the maximum level for a long time.

GUARANTEE

Your Reflex Active product is guaranteed against any defective construction or parts for 1 year from date of purchase. Please retain your receipt as proof of purchase. Breakages caused by water damage, accident or mishandling are not covered. This guarantee is in addition to your statutory consumer rights.

In the unlikely event you need to return your Reflex Active product or you need any other assistance with your product, please contact us and we'll be happy to help.

Support@Reflex-Active.Com
+44 (0)121 524 1400
We are available Monday - Friday 9am - 4pm.

IMPORTANT INFORMATION

Enjoy your music, but please stay safe & ensure you stay aware of your surroundings at all times. Do not use this product whilst driving or in other potentially dangerous situations. This product is not a toy, not for use by children. This is a class B product, in a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures. Please note the battery performance may decline over time due to repeated charging. Made in China by Peers Hardy UK Ltd, Precision House, Stanley Way, Birmingham International Business Park, B37 7GN, FR Address: Peers Hardy UK LTD, C/O Global Environment Experts, Rijnlanderweg 764, 2132 NM, Hoofddorp, Netherlands.

DISPOSAL OF GOODS

The crossed out wheelie bin symbol is to remind you that waste electrical products, batteries & accumulators should not be disposed of in household waste. If you are unable to reuse or recycle your article it should be disposed of at a civic amenity site or a local authority recycling facility • Do not dispose of your product within household waste • Disposal of the packaging & your product should be done in accordance with local regulations • Batteries are not to be disposed of in municipal waste stream and require separate collection.

EU DECLARATION OF CONFORMITY

The full UK & CE declaration of conformity can be viewed online at the following web page: https://www.elfcam.com/pages/safety-docs

REFLEX ACTIVE
BOOM
REFLEX-ACTIVE.COM