TORRAS

USER MANUAL
取扱説明書

In order to bring you a better experience, please read this user manual carefully before using this product and keep it properly for future reference.

Specifications

Product Name	Power Bank
Product Model	P80ps
USB-C Input	5.0V ⎓ 3.0A/9.0V ⎓ 2.0A
USB-C Output	5.0V ⎓ 3.0A/9.0V ⎓ 2.0A/12.0V ⎓ 1.5A
Wireless Charging Output	15W MAX
USB-C Wireless Charging Output	10W/5W 15W MAX
Output Power	22.5W MAX
Lithium Battery Energy	10000mAh/37.0Wh/3.7Wh (2 cells in parallel)
Cell Capacity	10000mAh
Rated Capacity	9500mAh (5.0V ⎓ 2.0A)
Transfer Efficiency	≥85%
Limiting Voltage Of Battery Charging	4.35V
Working Temperature	0°C~35°C / 32°F~95°F
Package List	Power Bank x1 Charging Cable x1 User Manual x1

The parameters above are derived from the laboratory of TORRAS. The actual parameters would be different due to different environments and other factors. The images shown here is indicative only.

Overview

Use the Power Bank

1. Button operation

① Click the power button to turn it on and start the wireless charging/wired charging, double-click the power button to turn it off.

② Press the power button for 2 seconds to start the low-current mode for 2 hours (it will automatically turn off after 2 hours). Press and hold again for 2 seconds to turn off the low-current mode and enter the normal charging mode.

2. Magnetic wireless charging

(Only for iPhone series mobile phones that support magnetic wireless charging) Place the Power Bank on the back and magnetically attach the mobile phone to the wireless charging area of the power bank, and the wireless charging mode is turned on. When the wireless charging is successfully turned on, the blue light, and the power indicator will display the current battery level.

3. Regular wireless charging

(Do for non-iPhone mobile phones that support wireless charging) Place the mobile phone on the wireless charging area, supports wireless charging liner up on the power bank, align it with the wireless charging area, and the charging symbol will show on the mobile phone screen. When charging, the indicator will be constantly on blue light, and the power indicator will display the current battery level.

Note:
When the wireless charging output is abnormal or a foreign object (FOD) is detected, the blue light of the wireless charging indicator will continue to flash 3 times/second, and it will resume within 2 seconds after it is removed.

4. Wired charging

Use the USB-C charging cable provided with the product to the power bank and the other end to the USB-C port of the phone/tablet and other devices. The blue light of the wireless charging indicator will be off, and the power indicator will display the current battery level.

Charge the Power Bank

Plug one end of the USB-C charging cable into the USB-C port of the power bank and the other end into the power adapter to charge the power bank. When charging, the power indicator light flashes and displays the remaining battery level; when fully charged, four power indicator lights are always on.



Notes:
01. When it is charging and fully charged, the wireless charging indicator light does not light up.
02. In order to guarantee the normal service life of the battery, please use and charge it at least once every three months.

Attentions

01. This wireless charger is not compatible with non-MagSafe iPhone models.
02. Please store this product in a cool and dry place.
03. Do not place this product in a high temperature or humid environment.
04. Do not use the power bank after being immersed in water.
05. Use of a power supply or charger not recommended or sold by the product manufacturer may result in a risk of fire or electric shock.
06. Do not disassemble the product. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or electric shock.
07. For safety reasons, please do not stop the product. Do not use this product in high temperature or humid environments or near heat sources.
08. During charging, the product may generate heat. This is normal, please do not worry. If overheating occurs, please stop using it temporarily.
09. After fully charging, please unplug the charger plug in a timely manner to avoid damaging the battery due to prolonged charging.
10. In normal conditions, the battery performance will decline after 500 charging cycles.
11. Do not place the product in high temperature or fire. Avoid exposing the product to environments with temperatures exceeding 35°C, as this may result in overheating, fire, or explosion.
12. If the power bank emits any unusual smell, overheats, changes color, or deforms, please stop using it immediately.
13. Do not use harmful chemicals or detergents to clean this product.
14. Warning: charging, or excessive vibration may cause product

Important Safety Instructions

When using this product, basic precautions should always be followed, including the following:

01. Please store this product in a cool and dry place.
02. Do not place this product in a high temperature or humid environment.
03. Do not use the power bank after being immersed in water.
04. Use of a power supply or charger not recommended or sold by the product manufacturer may result in a risk of fire or electric shock.
05. Do not disassemble the product. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or electric shock.
06. For safety reasons, please do not stop the product. Do not use this product in high temperature or humid environments or near heat sources.
07. During charging, the product may generate heat. This is normal, please do not worry. If overheating occurs, please stop using it temporarily.
08. After fully charging, please unplug the charger plug in a timely manner to avoid damaging the battery due to prolonged charging.
09. In normal conditions, the battery performance will decline after 500 charging cycles.
10. Do not place the product in high temperature or fire. Avoid exposing the product to environments with temperatures exceeding 35°C, as this may result in overheating, fire, or explosion.
11. If the power bank emits any unusual smell, overheats, changes color, or deforms, please stop using it immediately.
12. Do not use harmful chemicals or detergents to clean this product.
13. Warning: charging, or excessive vibration may cause product

Wonder. Explore. Forward.

SHENZHEN TORRAS TECHNOLOGY CO., LTD.

Address: RM2715, BLK C, Zhantian Technology BLDG, Shuiwei Avenue, Nhuch ST, Longhua DIST, Shenzhen, China

© Shenzhen TORRAS Technology Co., Ltd. All Rights Reserved.

Email: support@torrasdirect.com

Made in China

FCC Warning
15.19 Labeling requirements.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
15.21 Information to user.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
15.105 Information to the user.
This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.
FCC RF Radiation Exposure Statement:
1.This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2.This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.

TORRAS

USER MANUAL
取扱説明書

In order to bring you a better experience, please read this user manual carefully before using this product and keep it properly for future reference.

Specifications

製品名	モバイルバッテリー
モデル	P80ps
USB-C入力	5.0V ⎓ 3.0A/9.0V ⎓ 2.0A
USB-C出力	5.0V ⎓ 3.0A/9.0V ⎓ 2.0A/12.0V ⎓ 1.5A
ワイヤレス充電出力	最大15W
USB-Cワイヤレス充電出力	10W/5W 最大15W
出力電力	最大22.5W
リチウム電池のエネルギー	10000mAh/37.0Wh/3.7Wh (2セル並列)
セル容量	10000mAh
定格容量	9500mAh (5.0V ⎓ 2.0A)
伝送効率	≥85%
バッテリー充電限界電圧	4.35V
作業温度	0℃~35℃ / 32℉~95℉
同梱物	本体 x1 充電ケーブル x1 取扱説明書 x1

上記のデータはTORRASの実験室から得られたものです。実際のデータは環境などの影響により異なります。ここに示されている画像は参考用です。

概要

モバイルバッテリーの使用方法

1. ボタン操作

①電源ボタンを1回押すと電源がオンになり、ワイヤレス/有線充電が始まります。電源を2回押すと電源がオフになります。

②電源ボタンを2秒間押し続けると微弱モードが起動する(自動的に2時間後にオフになります)。再度2秒間押し続けると微弱モードが解除され、通常の充電モードに入ります。

2.マグネット充電

(マグネット充電に対応するiPhoneシリーズの場合)
iPhoneをモバイルバッテリーの背面に吸着させてワイヤレス充電エリアに配置すると、ワイヤレス充電モードがオンになります。ワイヤレス充電がオンになると、ブルーライトが点灯し、インジケーターは現在のバッテリー残量を表示します。

3.一般充電

(一般電源モード(ほとんどのスマホ)用)
ほとんどの電源対応電源を持ったiPhoneを背面に吸着させ、ワイヤレス充電エリアに合わせます。ワイヤレス充電がオンになると、ブルーライトが点灯し、インジケーターは現在のバッテリー残量を表示します。

ご注意：
モバイルバッテリーは10分に1度動作し(無線を伝ったりします)、ワイヤレス充電異物検知(FOD)を行います。FOD検知中は白色の光が2秒間隔で点滅し、FOD検知が解除されると、2秒以内に通常の充電モードに復帰します。

4. 有線充電

付属の USB-C 充電ケーブルを接続し、スマートフォン/タブレットなどの USB-C ポートに接続します。無線充電のインジケーターライトは消灯します。

モバイルバッテリーの充電方法

USB-Cケーブルの1端を充電ポートに接続し、もう1端をパワーアダプターに接続して充電します。充電中、インジケーターライトは点滅し、バッテリーの残量を表示します。満充電の状態では、4つのインジケーターライトが点灯します。



ご注意：
01. 充電中、満充電時、ワイヤレス充電インジケーターライトは点灯しません。
02. バッテリーを長期間不使用のまま放置しないでください。少なくとも3ヶ月に1回は使用を推奨しています。

注意事項

01. 本製品はiPhoneシリーズ専用のMagSafe非対応のケースには対応しません。
02. 本製品はバッテリーに保管する前に、まず充電を行ってください。
03. 高温多湿な環境で使用しないでください。
04. 本製品を水に浸けた後は使用しないでください。
05. メーカーが推奨していない製品を使用した場合、電源が発火や感電を引き起こすことがあります。
06. 分解しないでください。修理が必要な場合は、サービスセンターまで持ち込んでください。不適切な再組み立ては、火災や感電を引き起こすことがあります。
07. 安全上の理由から、本製品の運転を停止しないでください。本製品を高温・湿度の環境や熱源の近くで使用しないでください。
08. 充電中は、本製品は発熱することがあります。これは正常です。心配しないでください。過熱が発生した場合は、一時的に使用を中止してください。
09. 通常の状態では、500回の充電サイクルの後、バッテリーの性能は低下します。
10. 本製品を35℃を超える高温や火の近くに放置しないでください。本製品を35℃を超える環境にさらすと、過熱、火災、または爆発を引き起こすことがあります。
11. 本製品から異臭が発生したり、過熱したり、変色したり、変形したりした場合は、直ちに使用を中止してください。
12. 有害な化学物質や洗剤を使用して本製品を清掃しないでください。
13. 警告：充電、または過度の振動は製品を損傷する可能性があります。

安全上のご注意

本製品を使用する際には、下記の注意事項を守ってください：

01. 本製品は涼しい場所に保管する。
02. 高温多湿な環境で使用しないでください。
03. 本製品を水に浸けた後は使用しないでください。
04. メーカーが推奨していない製品を使用した場合、電源が発火や感電を引き起こすことがあります。
05. 分解しないでください。修理が必要な場合は、サービスセンターまで持ち込んでください。不適切な再組み立ては、火災や感電を引き起こすことがあります。
06. 安全上の理由から、本製品の運転を停止しないでください。本製品を高温・湿度の環境や熱源の近くで使用しないでください。
07. 充電中は、本製品は発熱することがあります。これは正常です。心配しないでください。過熱が発生した場合は、一時的に使用を中止してください。
08. 満充電後は、充電器プラグを適時に抜いてください。充電が長時間になると、バッテリーが損傷する可能性があります。
09. 通常の状態では、500回の充電サイクルの後、バッテリーの性能は低下します。
10. 本製品を35℃を超える高温や火の近くに放置しないでください。本製品を35℃を超える環境にさらすと、過熱、火災、または爆発を引き起こすことがあります。
11. 本製品から異臭が発生したり、過熱したり、変色したり、変形したりした場合は、直ちに使用を中止してください。
12. 有害な化学物質や洗剤を使用して本製品を清掃しないでください。
13. 警告：充電、または過度の振動は製品を損傷する可能性があります。

警告

本製品に近づくと電波が検知されます。下記の注意事項を必ず守ってください：

01. バッテリー残量が少ないと、充電は、まずは10分間充電してください。10分間充電すると、1時間ごとに10分間、1回の充電を行ってください。
02. バッテリーを分解したり、衝撃を与えたり、圧力をかけたり、ショートさせたりしないでください。バッテリーが破損したり、液漏れが発生したりすると、火災や爆発を引き起こすことがあります。
03. 電池の表面が傷ついたり、変形したり、膨張を伴ったりした場合は、使用を中止してください。
04. 電池を長時間使用しないでください。長期間使用しないと、電池の性能が低下する可能性があります。
05. 本製品を35℃を超える高温や火の近くに放置しないでください。本製品を35℃を超える環境にさらすと、過熱、火災、または爆発を引き起こすことがあります。
06. 本製品から異臭が発生したり、過熱したり、変色したり、変形したりした場合は、直ちに使用を中止してください。
07. 有害な化学物質や洗剤を使用して本製品を清掃しないでください。
08. 警告：充電、または過度の振動は製品を損傷する可能性があります。

物料编码：

物料名称：阳拉斯1 小云宝系列超薄移动电源说明书

结构部分			平面部分		
	材　质：　银禾样合100克本白双胶纸	单　位：mm		印刷颜色：K	LOFFAN DESIGN
	成型尺寸：60*60mm（44P，双钉）	刀　线：———		表面处理：单黑+双围印刷，啤+折，风琴折	
	展开尺寸：	压　线：- - - - - - -		平面设计：陈吉鸿	
	结构设计：	针 刀 线：		平面修改：	
	日　期：	刀模相交：		日　期：2024.06.12	
	备　注：	坑　纹：		备　注：	

特别说明：所有物料需要符合国禾《有害物质限用管理程序》LH-WI-0004（环保要求）