JUST ENJOY

mifa

A90 SPEAKER

USER MANUAL ▸

---

01 Warning
English

⚠

◆To ensure proper use and trouble-free operation, please carefully read this user manual first.
◆For the first use, a full charge is recommended.
◆Please use and store the product at room temperature.
◆Do not throw and drop the product to avoid damages.
◆Do not expose the product to fire, high temperature, direct sunlight, etc.
◆Do not use organic solvents or other chemicals to clean the product.
◆Do not allow small particles to get into the product.
◆Please keep volumes of the speaker moderate to avoid temporary or permanent hearing impairment.
◆Do not dissemble the product, or make any modifications to the structure or any parts of it.
◆Keep the product out of children's reach.
◆If the battery is not properly replaced, there will be an explosion accident, which can only be replaced with the same type of battery.
◆Batteries (battery packs) can not be exposed to such conditions as sunshine, fire or similar overheating conditions.

---

02 Packing list
English

1 × Bluetooth Speaker

1 × User Manual

1 × USB Type-C Charging Cable

1 × 3.5 mm Audio Cable

1 × Strap

---

03 Keys Functions
English

Short Press: Increase volume
Long Press: Play next song

Short Press: Decrease volume
Long Press: Play previous song

Power Button: Press and hold the button for 2 seconds to turn on or turn off
Reset Button: Press and hlod it for 8 seconds to reset the speaker
Power Indicator: Short press the power button to show the remaining power (green light flashes)
(100% power: flashes 4 times   75% power: flashes 3 times
50%: flashes 2 times   25% power: flashes once)

Pairing Status: Blue light flickers quickly
Paired Status: Blue light stays on
AUX/ TF/ USB Mode: Blue light stays on
Pause Status: Blue light flickers Slowly
Min/ Max Volume: Blue light flickers quickly
Low Battery: Red light flashes

Play/ Pause Button: Short press to play or pause.
Call Answer Button: When a call coming, short press to answer or hang up; long press to reject.

Mode Button: Short press to switch the mode in the powered-on status
If it is inserted with a Micro SD card, an USB flash driver and an audio cable, modes switch in turns: Bluetooth mode → Micro SD card mode → Aux-in mode → USB flash driver mode
Press and hold the button for 2 seconds to disconnect the paired device
RGB Light Mode: Double click the mode button to turn on/ off the RGB light and change the RGB light mode.

---

04 Ports Functions
English

Aux-in Jack
Inserted an audio cable in the powered-on state, it will enter the Aux-in mode automatically.

USB Flash Driver Port
Inserted an USB flash driver in the powered-on state, , it will play the music stored in the driver automatically after beeps.

USB Type-C Charging Port:
Use a DC 5V / 2A adaptor to charge the speaker

Micro SD Card Slot
In the powered-on state, insert a Micro-SD card, it will play the music stored in the card automatically after beeps.

Charging Indicator: Red light will stay on when charging, turn off after finish charging.

---

05 Bluetooth Connection
English

1. Turn on the speaker
Press and hold the power button for 2 seconds to turn on the speaker with a prompt sound. And the blue light flashes indicating it is in the pairing mode.

2. Connect it to your device
Turn on the Bluetooth of your device and select Mifa_A90. Once the connection is completed, it will beep and the blue light will stay on.
The speaker will connect to the last-connected device automatically once the device's Bluetooth is turned on.

Other Instructions
To connect to another device, press and hold the **M** button for 2 seconds to disconnect the paired one and the speaker will enter the pairing mode.

---

06 True Wireless Stereo Function
English

**1. Set up the TWS system**
Turn on two speakers and make sure no device connects with either of them. Short press one speaker's "-" and "+" buttons simultaneously and there will be a beep sound to indicate pairing is taking place. Once pairing is complete, there will be another beep sound.

2. Pair two TWS speakers with a Bluetooth device
Select Mifa_A90 in the Bluetooth settings menu of the Bluetooth device. There will be a sound indicating a successful connection and the blue light keeps on.

3. Stop the TWS
Short press either speaker's "-" and "+" buttons simultaneously to disconnect it with the other one.

Tips:
1. For the first time of setting up the TWS system, the speaker which you press the "-" and "+" button will work as the main speaker and left channel, the other one work as the dependent speaker and right channel.
2. The true wireless stereo function supports only 2 speakers.
3. After the first connection, the main speaker will keep working as the main speaker and the dependent one will keep working as the dependent one in the future connection. And they will connect with each other automatically once they power on.
4. After setting up the TWS system, the dependent speaker's blue light stays on and the main one's blue light indicates your operation.
5. After the TWS system is set up successfully, you just need to operate either speaker. The other one will do the same operation simultaneously.

Speaker 1

Speaker 2

---

07 Specifications
English

Basic Parameters	
Speaker Type	Portable Bluetooth Speaker
Supported Storage	Up to 32 GB Micro SD Card
Power Supply	Built-in 8000 mAh Lithium Battery
	DC 5V / 2A USB Adapter
Audio Input	Bluetooth, Micro SD Card, 3.5mm Aux-in

Technical Parameters	
Loudspeaker	Dual 66mm Speakers + Dual 78mm Low Frequency Amplifiers
Frequency	60Hz ~ 18KHz
Bluetooth Version	Bluetooth 5.0
USB Standard	USB 2.0 (Compatible with USB1.1)
Supported Media Type	APE/ FLAC/ WAV/ WMA/ MP3
Bit Rate	MP3: 8Kbps-320Kbps WMA: 32Kbps-384Kbps WAV: 32Kbps-1414Kbps APE: 100Kbps-1200Kbps FLAC: 100Kbps-1200Kbps

250mm

115mm

106mm

Size: 250* 106 * 115 mm
Weight: 1155g (including the built-in Lithium battery)

---

08 Trouble Shooting
English

FAQ	Solutions
Not able to connect to your device	1. Restart the speaker and try again
	2. If your device requires a Pin Code, please enter 0000
Keeps cutting out when playing	Please ensure the speaker is within the operating range and there are no obstacles between the speaker and the device
Not able to play the music in Micro SD card	1. Please ensure the format of the Micro SD card is FAT32. It only supports FAT32 Micro SD card 2. Please ensure the formats of the music files are APE, FLAC, WAV, WMA or MP3
No sound when playing	1. Please adjust the volume of the speaker 2. Please adjust the volume of your device 3. Please check if the speaker is paused
No sound in AUX-in mode	Please ensure the audio cable is connected well
Not able to turn on	Please try to charge the speaker for about 3 hours
No respond to any operation	Press and hold the power button for 8 seconds to reset the speaker.