REMOTE CONTROL STUNT VEHICLE
TOY BOX
FLIP ACTION
DOUBLE SIDED
LED LIGHTS
360° ROTATION
27MHZ
$5
2x AA
4x AAA
BATTERIES SOLD SEPARATELY
REMOTE CONTROL STUNT VEHICLE
AGE 5+
BATTERY REPLACEMENT
To replace batteries refer to the following directions:
VEHICLE
1. Turn the power switch to the OFF position.
2. Use a Phillips screwdriver to loosen and remove the battery compartment door as shown.
3. Remove old batteries and replace with 4 new 1.5V "AAA" batteries.
4. Replace the battery compartment door and tighten the screw.
REMOTE CONTROL
1. Use a Phillips screwdriver to loosen and remove the battery compartment door as shown.
2. Remove old batteries and replace with 2 new 1.5V "AA" batteries.
3. Replace the battery compartment door and tighten the screw.
BATTERY CAUTION
• Alkaline batteries are recommended.
• Avoid battery leakage: Do not mix old and new batteries or mix battery types (alkaline, standard or rechargeable batteries) or different brands.
• Do not use rechargeable batteries, Non-rechargeable batteries are not to be recharged.
• Only batteries of the same or equivalent type as recommended are to be used.
• Batteries must be inserted with the correct polarity.
• The supply terminals are not to be short-circuited.
• If batteries are loose, bend out the contacts for a tight fit.
• Remove exhausted batteries from the product.
• Do not use battery compartment cover if loose or missing. Keep battery compartment cover secured with screw.
• Exhausted batteries are to be removed from toy. Immediately and safely dispose of any used batteries. Do not burn or short circuit batteries. Do not try to recharge non-rechargeable batteries.
• When toy is not in use for an extended period of time, remove batteries to prevent possible leakage and damage to the unit.
• Check the product periodically for signs of damage to electrical parts; do not play with product until damage has been properly assessed.
If the unit malfunctions, please remove the batteries for one minute and reinstall again.
ADULT SUPERVISION IS RECOMMENDED WHEN INSTALLING BATTERIES.
MAKE SURE THE BATTERIES ARE NOT INSERTED WITH A REVERSED AND INSERTED CORRECTLY AND ALWAYS FOLLOW BOTH THE PRODUCT AND BATTERY MANUFACTURER'S INSTRUCTIONS.
BATTERY INSTALLATION OR REPLACEMENT MUST BE DONE BY ADULTS. ADJUSTMENT MUST ALWAYS BE DONE BY ADULT.
Not all of a DVD pack this product unless battery door is ensured. Batteries are small objects and could be ingested. Keep all batteries away from small children.
Don't forget to remove batteries from the vehicle and remote control when you have finished operating your vehicle.
Remove all packaging before giving toy to child. Please keep packaging for future reference. Color, contents and designs may vary.
Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits set forth for an uncontrolled environment.
This transmitter must not be co - located or operating in conjunction with any other antenna or transmitter.
Alkaline batteries are recommended.
VEHICLE
USE 4 x 1.5V "AAA" BATTERIES NOT INCLUDED
REMOTE CONTROL
USE 2 x 1.5V "AA" BATTERIES NOT INCLUDED
27MHz
HOW TO OPERATE
Forward — Push the left control stick upwards.
Backward — Push the left control stick downwards.
Spin — To spin counterclockwise, keep pushing the left control stick to the left. To spin clockwise, keep pushing the right control stick to the right.
Turn left forward — Push the left control stick upwards while pushing the right control stick left.
Turn right forward — Push the left control stick upwards while pushing the right control stick right.
Turn left and back — Push the left control stick downwards while pushing the right control stick left.
Turn right and back — Push the left control stick downwards while pushing the right control stick right.
1 Year
1.5V "AA" x 2
1.5V "AAA" x 4
Do not put in trash. Recycle or manage as hazardous waste.
1 815 3464 053312 3
W2133-0000-TB-OMEN
DISTRIBUTED BY:
GREENBERG TRADING GLOBAL, INC.
500 VELVET PARKWAY,
CHESAPEAKE, VA 23320
MADE IN CHINA