WALKIE TALKIE USER MANUAL

W01

W01 Walkie Talkie Screen Contains

- CH — Channels 1-22
- SUB — Sub-Channels 1-99
- PRI — Priority channel 1-99
- VOX — Voice Activated Transmission
- PTT — Push To Talk
- Battery Level
- Volume Level

W01 Walkie Talkie

Tips:

These W01 Walkie Talkies Fit for HOCAZOR H201, Walker's Razor slim electronic muff Earmuffs, ACT FIRE Ear Protection (not for Razor Quad Earmuffs or Passive Earmuffs) Walkie-talkie and earmuffs must be turned on simultaneously when in use.

Radio Operation

Turn On/Off: Long press ⏻

Select Mode: Short press MODE Button to choose base channel and SUB channel and PRI channel as well as VOX status.

Volume Adjustment: While not in the mode selection, the volume be adjusted by pressing the up or down volume buttons on the unit.

Channel Selection: Short Press the ⏻ /MODE button to enter the menu. "CH" will display, press the up or down buttons until the desired channel appears on the screen. W01 Walkie-Talkie supports standard GMRS/FRS channels 1 to 22. Press the ⏻ /MODE button four times to exit the menu. Alternatively, the menu will exit after 10 seconds of inactivity.

Communication: All radios in the group must be set to the same channel. To talk, press and hold the PTT button and speak. The PTT icon will flash on the screen while transmitting. Release PTT button when finished.

Power Supply: 3 AAA Batteries(Not include)

Channel Effective Range: 3 Miles Line-to-Line Or 7 floors height about 86 Feet

Advanced Operation

Using SUB Channels

Selecting a SUB-channel will cause your W01 Walkie Talkie to only receive a transmission from other radios set to the same channel and sub-channel. This allows multiple groups to communicate on the same channel independently.

Note that other radios will receive transmissions from your channel regardless of sub-channel.

1. Press the Power/MODE button twice to enter the sub-channel menu. "SUB" will display.
2. Press the up or down buttons to select any of the 99 sub-channels.
Press the Power/Menu button three times to exit the menu. Alternatively, the menu will exit after 10 seconds of inactivity.

Voice Activated Transmit (VOX)

To allow for hands-free operation of the W01 Walkie Talkie, VOX, can be enabled. When activated, the unit will automatically transmit when the wearer is speaking. PTT is still available while VOX is enabled.

1. Press the Power/MODE button three times to enter the VOX menu. "VOX" will be displayed.
2. Press the up or down volume buttons to scroll through the available options. OF disables VOX and is the default setting. LO is for low sensitivity and is meant for environments with external noise such as wind. HI is for high sensitivity ideal for low wind areas or indoors.
3. Press the Power/MODE button twice to exit the menu.
Alternatively, the menu will exit after 10 seconds of inactivity.

Attention:
This radio complies with IEEE and ICNIRP exposure limits for occupational/controlled RF exposure environment at operating duty factors of up to 50% and is authorized by the FCC for occupational use only. An appropriate warning lable is affixed to all units. In order to comply with RF exposure requirements, a minimum distance of 0cm must be maintained when held-to-ear, and limit operations are restricted to the approved original
accessories (earphone). a minimum distance of 0cm. Do not use this device when antenna shows obvious damages.

Using a PRI Channel

Setting a PRI channel will allow the W01 Walkie-Talkie to scan a secondary channel on which important messages may be broadcast. This channel might be used by a Rangemaster to alert shooters of a cease-fire or by a site foreman to warn workers of an immediate job site hazard. While receiving transmissions from the priority channel, the headset cannot transmit.

1. Press the Power/Menu button four times to enter the priority channel menu. "PRI" will be displayed.
2. Press the up or down volume buttons to scroll through the channels. The priority channel can be set to any of the 22 channels available other than the one currently set as the main channel.
3. Press the Power/Menu button one more time to exit the menu.
Alternatively, the menu will exit after 10 seconds of inactivity.

This product is compliance to FCC RF Exposure requirements and refers to FCC website https://apps.fcc.gov/oetcf/eas/reports/GenericSearch.cfm search for FCC ID: 2AYWU-RH07 to gain further
information include SAR Values.

HOCAZOR W01 WALKIE TALKIE FCC STATEMENT

FCC ID: 2AYWU-RH07

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)this device may not cause harmful interference, and
(2)this device must accept any interference received, including interference that may cause undesired operation.