尺寸：100*120mm　材质：105g哑粉　装订方式：钉装

封面　　封底

KAWA

USER MANUAL

取扱説明書

KAWA AUTO

KAWA AUTO

Google Play

App Store

E-mail: support@kawa-in.com

Website: www.kawa-in.com

Warranty: 12 month limited warranty

Manufacturer: KAWA ELECTRONICS COMPANY LIMITED

Address: R.M 1,2,3 7/F,CHEUNG LO INDUSTRIAL BLDG 127 CHAI WAN HONG KONG

E-mail: support@kawa-in.com

Website: www.kawa-in.com

二维码待提供

Scan the QR code for the online user manual

QRコードをスキャンし、電子マニュアルを取得してください

Scanez le code QR pour afficher le manuel d'utilisation en ligne

Escanear los dos QR Codes, uno de Bedienungsanleitung y otro para

Scansionare il codice QR per consultare il manuale utente online

Digitalizar o código QR para consultar o manual do utilizador online

Escanear el código QR para ver el manual en línea

Отсканируйте QR-код для просмотра Руководство пользователя онлайн

Ноч QR кодны сканирлаж онлайн удирдлагын гарамж руу очоорой

QR 코드를 스캔하여 온라인 사용자 매뉴얼을 확인하세요.

English　1

日本語　12

User Manual for KAWA Dash Cam D8

Product Appearance

Warranty: 12 month limited warranty

Manufacturer: KAWA ELECTRONICS COMPANY LIMITED

Address: R.M 1,2,3 7/F,CHEUNG LO INDUSTRIAL BLDG 127 CHAI WAN HONG KONG

E-mail: support@kawa-in.com

Website: www.kawa-in.com

1

Product Installation

Install the Dash Cam D8 on the windshield in the defined area indicated in the diagram. Ensure the lens is positioned directly behind the rearview mirror to minimize blind spots and avoid obstructions.

Adjust the lens to capture the road ahead, and fully compress the air bubble between the anti-slip mat and the windshield during installation.

1. Install the Micro SD Card

Insert the Micro SD card into the Micro SD card slot until you hear a "click" sound.

2. Install the Mount

To ensure a firm fixture, please install the base into the car mount adhesive paper on the back of the holder, and attach the mount to the windshield. Wait for 24 hours for the adhesive to fully cure before installing the camera. This ensures optimal adhesion and prevents accidental detachment.

3. Connect the Power Adapter

Connect the power adapter to the rear-facing USB port located on the base of the holder, and attach the other end to the cigarette lighter socket. Ensure the connection is secure to prevent any disconnections during operation. Your dash cam will now be powered by the vehicle's electrical system.

4. Adjust the Angle of the Camera

Adjust the angle of the camera to ensure the camera angle according to the preview screen to ensure the camera's lens is facing straight ahead.

Button Functions

Power button	Long press for 3 seconds to power on/off the device. Short press to switch between different modes.	Function button	Short press to switch between different modes.
Reset button	Short press to restart the device. Long press for 5 seconds to restore factory settings.	Mic	Short press to mute/unmute the microphone.
Charging port	Connect to a power adapter for charging.	Micro SD card slot	Insert a Micro SD card to store recorded videos and photos.

2

LED Functions

Unless otherwise specified, the LED status will indicate the corresponding function.

Status	Function
Remains green	Normal video recording
Flashing quickly in green	Parking surveillance recording
Remains red	Recording in parking mode
Flashing quickly in red	Recording in emergency lock mode
Blue light solid	SD card error or SD card not inserted
Blue light flashing	Formatting storage card or processing the album
	Formatting storage card in progress
	Factory reset in progress

Instructions for Use of Micro SD Card

1. Compatibility: The dash cam supports Micro SD cards. Please use a Class 10 or higher Micro SD card with 64GB storage capacity or less.

- Please insert an appropriate Micro SD card before using the dash cam.
- The lifespan of the memory card may differ from brand to brand. Choose a high-quality Micro SD card from a reputable brand to ensure optimal performance and reliability. We recommend using high-quality Micro SD cards from brands like SanDisk, Samsung, or Kingston.
- Do not place or insert any other objects into the Micro SD card slot. Doing so may damage the device.
- Do not remove the Micro SD card while the device is in use. Doing so may cause data loss or damage to the card.
- Regularly back up important video files to prevent data loss.
- Avoid exposing the Micro SD card to extreme temperatures, direct sunlight, or moisture.
- Do not attempt to disassemble or modify the Micro SD card.
- Please use a reputable and high-quality Micro SD card. For an inferior Micro SD card, there may be a risk of data loss or corruption. We are not responsible for any data loss or damage caused by the use of low-quality or counterfeit products. The warranty does not cover and has been voided for any video loss or damage caused by the use of low-quality or counterfeit products.
- In rare cases, a faulty Micro SD card may damage the device. If this occurs, please do not insert or remove the Micro SD card after the dash cam is turned on.

3

Precautions before Installation

- Please ensure the dash cam is installed in a stable and secure manner to prevent accidents in the event of sudden or unexpected vehicle movements, which may damage the dash cam or cause injuries to the driver and passengers. Avoid installing the dash cam in areas that may obstruct the driver's vision or interfere with the deployment of airbags.
- Do not install the dash cam in a manner that obstructs the driver's vision or interferes with the deployment of airbags.
- Please ensure the dash cam is installed in a way that does not obstruct the driver's vision or interfere with the deployment of airbags. Avoid installing the dash cam in areas that may block the driver's line of sight or airbag deployment zones.
- Do not install the dash cam in a way that obstructs the driver's vision or interferes with the deployment of airbags.
- Please ensure the dash cam is installed in a way that does not obstruct the driver's vision or interfere with the deployment of airbags.

Notes

- Prolonged or strong sunlight exposure may cause the device to overheat and enter a temporary shutdown state. This is a protective measure to prevent overheating. The device will resume normal operation once the temperature returns to a safe level.
- Please use a reputable and high-quality Micro SD card. For an inferior Micro SD card, there may be a risk of data loss or corruption. We are not responsible for any data loss or damage caused by the use of low-quality or counterfeit products. The warranty does not cover and has been voided for any video loss or damage caused by the use of low-quality or counterfeit products.
- In rare cases, a faulty Micro SD card may damage the device. If this occurs, please do not insert or remove the Micro SD card after the dash cam is turned on.

4

Quick configuration

1. Download the app

Download the app by scanning the QR code below. After downloading the app, you can set up the dash cam and view real-time video from the dash cam, adjust the dash cam's installation angle, and more.

Google Play

App Store

2. Add to APP:

Connect to the KAWA-D8 WiFi, enter the "1" in the pop-up login screen, select "KAWA Dash Cam SET" and finally click on the "Add" button to add the device to the app.

Note: The default WiFi password is 12345678.

Note: Ensure your phone's location permission is enabled for the app to access the dash cam's WiFi and stream video in real-time.

Note: The dash cam's Wi-Fi network doesn't support internet access. If you want to access the cam's network while connected to its Wi-Fi, disconnect from the cam's Wi-Fi network first.

5

6

Function

- Parking mode for remote protection, this camera needs to be used together with the rear-direction camera.
- When being powered by the mobile power and connected to the rear-direction camera, it can capture images from the rear of the vehicle and store them in the rear-direction storage card.

Instructions

- The camera is powered by the main device and will automatically turn on when the main device is powered on. The camera will automatically shut down when the main device is powered off.
- If the rear-direction only connects power to the camera, there is no recording special scene. If the main device is not receiving external power, it cannot provide power to the camera.
- When the main device is powered by the mobile power, the camera will automatically enter a low-power state. The camera will not record during this time. Only when charge with sufficient power, the camera will resume normal operation.

Product Installation

1. Install the dash cam: Place the dash cam in the designated area on the windshield as shown in the diagram. Ensure the lens is positioned directly behind the rearview mirror to minimize blind spots and avoid obstructions.

Adjust the lens to capture the road ahead, and fully compress the air bubble between the anti-slip mat and the windshield during installation.

2. Install the Micro SD Card: Insert the Micro SD card into the Micro SD card slot until you hear a "click" sound.

3. Install the Mount: To ensure a firm fixture, please install the base into the car mount adhesive paper on the back of the holder, and attach the mount to the windshield. Wait for 24 hours for the adhesive to fully cure before installing the camera. This ensures optimal adhesion and prevents accidental detachment.

4. Connect the Power Adapter: Connect the power adapter to the rear-facing USB port located on the base of the holder, and attach the other end to the cigarette lighter socket. Ensure the connection is secure to prevent any disconnections during operation. Your dash cam will now be powered by the vehicle's electrical system.

5. Adjust the Angle of the Camera: Adjust the angle of the camera to ensure the camera angle according to the preview screen to ensure the camera's lens is facing straight ahead.

7

Notes

- Prolonged or strong sunlight exposure may cause the device to overheat and enter a temporary shutdown state. This is a protective measure to prevent overheating. The device will resume normal operation once the temperature returns to a safe level.
- Please use a reputable and high-quality Micro SD card. For an inferior Micro SD card, there may be a risk of data loss or corruption. We are not responsible for any data loss or damage caused by the use of low-quality or counterfeit products. The warranty does not cover and has been voided for any video loss or damage caused by the use of low-quality or counterfeit products.
- In rare cases, a faulty Micro SD card may damage the device. If this occurs, please do not insert or remove the Micro SD card after the dash cam is turned on.

8

Notes

- Prolonged or strong sunlight exposure may cause the device to overheat and enter a temporary shutdown state. This is a protective measure to prevent overheating. The device will resume normal operation once the temperature returns to a safe level.
- Please use a reputable and high-quality Micro SD card. For an inferior Micro SD card, there may be a risk of data loss or corruption. We are not responsible for any data loss or damage caused by the use of low-quality or counterfeit products. The warranty does not cover and has been voided for any video loss or damage caused by the use of low-quality or counterfeit products.
- In rare cases, a faulty Micro SD card may damage the device. If this occurs, please do not insert or remove the Micro SD card after the dash cam is turned on.

9

Certification

Hereby, KAWA declares that this product complies with the radio interference requirements of the European Community.

Use the CE01 CAB001 in accordance with the harmonised between: LVD and EC Directives, 2 Wireless Equipment Directive (RED) 2014/53/EU, 3 EMC.

This equipment is in compliance with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & body.

FCC ID: 2ALEK2-D8

For Adapter: Shall be installed near the equipment and shall be easily accessible.

For Battery: Battery shall be replaced only by same model battery type. Adapter of overload battery charging by the same manufacturer.

Manufacturer: KAWA ELECTRONICS COMPANY LIMITED

Manufacturer: Shell Electronics (Shenzhen) Limited

Address: R.M 1,2,3 7/F,CHEUNG LO INDUSTRIAL BLDG 127 CHAI WAN HONG KONG

E-mail: support@kawa-in.com

Website: www.kawa-in.com

10

The device contains Source-exempt transmitter(s) /receiver(s) that comply with Innovation, Science and Economic Development Canada' s licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exemptés de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée à la condition que les deux conditions suivantes soient remplies:

(1) L'appareil ne doit pas produire de brouillage;

(2) L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible de compromettre le fonctionnement de l'appareil.

Radio Frequency Exposure Statement:

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Cet équipement doit être installé et utilisé avec un minimum de 20 cm entre le radiateur et votre corps.

IC: 27108-D8

Hereby, KAWA declares that this product complies with the essential requirements and other relevant provisions of Directive 2011/65/EU.

Warranty: 12 month limited warranty

Manufacturer: KAWA ELECTRONICS COMPANY LIMITED

Address: R.M 1,2,3 7/F,CHEUNG LO INDUSTRIAL BLDG 127 CHAI WAN HONG KONG

E-mail: support@kawa-in.com

Website: www.kawa-in.com

11

KAWA ドライブレコーダー D8取扱説明書

製品外観

12

製品の設置

運転席前方の指定エリアに、ダッシュボードカメラを設置してください。

ダッシュボードカメラのレンズは、バックミラーの真後ろに配置されていることを確認してください。これにより、死角を最小限に抑えられます。

レンズを調整して、道路の前方を撮影するようにします。ステッカーを設置する際、滑り止めマットとフロントガラスの間の空気を完全に抜いてください。

1. マイクロSDカードを挿入する

マイクロSDカードをマイクロSDカードスロットに挿入し、「カチッ」という音がするまで押し込みます。

2. 取付ベースを設置する

ベースを車両の取付ステッカーに貼り付けてください。ステッカーが完全に固定されるまで、24時間待ってから、カメラを取付ベースに取り付けてください。これにより、最適な接着力を確保し、ベースが誤って外れるのを防ぎます。

3. 電源アダプターを接続する

電源アダプターを、ホルダーの背面にある USB ポートに接続し、もう一方の端をシガーソケットに接続します。接続が安全であることを確認してください。これにより、運転中に接続が外れるのを防ぎます。ダッシュボードカメラは、車両の電気系統から電源を供給されます。

4. カメラの角度を調整する

カメラの角度を調整し、プレビュー画面に従ってカメラの角度を調整し、カメラのレンズが正面を向いていることを確認します。

ボタン機能

電源ボタン	3秒間長押しして電源のオン/オフを切り替えます。短押しで各モードを切り替えます。	機能ボタン	短押しで各モードを切り替えます。
リセットボタン	短押しで再起動します。5秒間長押しして工場出荷時の設定に戻します。	マイク	短押しでミュート/ミュート解除します。
充電ポート	電源アダプターを接続して充電します。	マイクロSDカードスロット	マイクロSDカードを挿入して録画ビデオや写真を保存します。

13

LED機能

特に指定がない場合、LEDインジケーターの状態は、対応する機能を示します。

ステータス	機能
緑色点灯	通常の録画状態
緑色点滅	駐車監視録画
赤色点灯	駐車モードで録画
赤色点滅	緊急ロック録画
青色点灯	SDカードエラー/SDカードが挿入されていません
青色点滅	ストレージカードをフォーマット中/アルバムをフォーマット中
	ストレージカードをフォーマット中
	工場出荷時のリセット中

Micro SDカードの使用方法

- 本製品はMicro SDカードをサポートします。Micro SDカードは容量が64GB以下の Class 10 以上のものをご使用ください。
- ドライブレコーダーの使用中は Micro SD カードを挿入しないでください。ドライブレコーダーがオンの状態でMicro SDカードを挿入または取り外すと、カードが破損する可能性があります。
- Micro SD カードの寿命はブランドによって異なります。ドライブレコーダーの安定性を確保するには、SanDisk、Samsung、Kingston などの信頼できるブランドの高品質 Micro SD カードを使用することをお勧めします。
- Micro SD カードを使用する前に、カードに重要なビデオファイルがないことを確認してください。カードをフォーマットすると、カードに保存されているすべてのデータが消去されます。
- 高温多湿や強い直射日光にさらされると、Micro SD カードの性能が低下したり、データが失われたりする可能性があります。
- 高品質の Micro SD カードを使用してください。安価な Micro SD カードを使用すると、データの損失や破損のリスクがあります。当社は、安価な製品または偽造品の使用によるデータの損失または破損に責任を負いません。保証は、安価な製品または偽造品の使用によるビデオの損失または破損については無効となります。
- 稀に、故障した Micro SD カードがデバイスを損傷する場合があります。この場合、ドライブレコーダーの電源を入れた状態で Micro SD カードを挿入または取り外さないでください。

14

設置前の注意事項

- 設置は安定した安全な方法で行ってください。突然の予期せぬ動きによる事故や、ドライブレコーダーの破損、運転者や乗員の怪我を防ぐためです。ドライブレコーダーを、運転者の視界を遮ったり、エアバッグの展開を妨げたりするような場所に設置しないでください。
- ドライブレコーダーを、運転者の視界を遮ったり、エアバッグの展開を妨げたりするような方法で設置しないでください。
- ドライブレコーダーを、運転者の視界を遮ったり、エアバッグの展開を妨げたりするような方法で設置しないでください。
- ドライブレコーダーを、運転者の視界を遮ったり、エアバッグの展開を妨げたりするような方法で設置しないでください。

Notes

- 長時間の強い直射日光にさらされると、デバイスが過熱し、一時的にシャットダウンモードに入ることがあります。これは保護機能であり、デバイスが過熱するのを防ぎます。デバイスは、温度が安全レベルに戻ると、通常の動作を再開します。
- 高品質の Micro SD カードを使用してください。安価な Micro SD カードを使用すると、データの損失や破損のリスクがあります。当社は、安価な製品または偽造品の使用によるデータの損失または破損に責任を負いません。保証は、安価な製品または偽造品の使用によるビデオの損失または破損については無効となります。
- 稀に、故障した Micro SD カードがデバイスを損傷する場合があります。この場合、ドライブレコーダーの電源を入れた状態で Micro SD カードを挿入または取り外さないでください。

15

クイック構成

1. アプリをダウンロードしてください

下記のQRコードをスキャンしてアプリをダウンロードしてください。アプリをダウンロードしてドライブレコーダーを設定し、リアルタイムのビデオを表示し、ドライブレコーダーの取付角度を調整するなど、さらに多くの機能を利用できます。

Google Play

App Store

2. 追加 to APP:

KAWA-D8 WiFi に接続します。ポップアップ表示されるログイン画面で「1」を選択し、「KAWA Dash Cam SET」を選択して、「追加」ボタンをクリックしてデバイスをアプリに追加します。

デフォルトのWiFiパスワードは12345678です。

ご注意：ドライブレコーダーがビデオをリアルタイムでストリーミングできるように、お使いのスマートフォンの位置情報アクセス権が有効になっていることを確認してください。

ドライブレコーダーのWiFiネットワークはインターネットアクセスをサポートしません。カメラのネットワークにアクセスしながらカメラのWiFiに接続する場合は、まずカメラのWiFiネットワークから切断してください。

16

2. フロントカメラ画像
3. リアカメラ画像
4. デュアルカメラ画像
5. ビデオリスト
6. ビデオを削除
7. ビデオをロック
8. ビデオを再生
9. すべてのビデオを削除
10. すべてのビデオをロック
11. すべてのビデオを再生
12. ビデオ品質
13. ループ録画
14. 重力センサー
15. 駐車監視
16. タイムウォーターマーク
17. 日付ウォーターマーク
18. 速度ウォーターマーク
19. 速度単位
20. タイムゾーン
21. 日付と時刻
22. 言語
23. 音声プロンプト
24. 画面自動オフ
25. 画面輝度
26. 音量
27. メモリーカードをフォーマット
28. 工場出荷時設定に戻す
29. ファームウェアのバージョン
30. ビデオグループリスト
31. ビデオグループリスト
32. ビデオグループリスト
33. ビデオグループリスト
34. ビデオグループリスト
35. ビデオグループリスト
36. ビデオグループリスト
37. ビデオグループリスト
38. ビデオグループリスト
39. ビデオグループリスト
40. ビデオグループリスト
41. ビデオグループリスト
42. ビデオグループリスト
43. ビデオグループリスト
44. ビデオグループリスト
45. ビデオグループリスト
46. ビデオグループリスト
47. ビデオグループリスト
48. ビデオグループリスト
49. ビデオグループリスト
50. ビデオグループリスト
51. ビデオグループリスト
52. ビデオグループリスト
53. ビデオグループリスト
54. ビデオグループリスト
55. ビデオグループリスト
56. ビデオグループリスト
57. ビデオグループリスト
58. ビデオグループリスト
59. ビデオグループリスト
60. ビデオグループリスト
61. ビデオグループリスト
62. ビデオグループリスト
63. ビデオグループリスト
64. ビデオグループリスト
65. ビデオグループリスト
66. ビデオグループリスト
67. ビデオグループリスト
68. ビデオグループリスト
69. ビデオグループリスト
70. ビデオグループリスト
71. ビデオグループ