Retro 2 Mini Bluetooth Keyboard
Model:B307, B309

Connect up to 4 devices

The mode switch dial allows you to connect up to four devices. (Wired mode / Bluetooth mode (1, 2, 3 channel))

- **Wired mode (1 device)**
  USB to C cable (Green LED)
- **Bluetooth mode (3 devices)**
  Bluetooth CH 1 (Blue LED)
  Bluetooth CH 2 (Blue LED)
  Bluetooth CH 3 (Blue LED)

Wired mode connection method (USB to C cable)

1. You can select the wired mode by toggling the mode switch dial (Green LED flips on).
2. Connect the included USB to C cable to connect the keyboard to the wired device (PC, Mac, etc).
3. Upon completion of the settings, you can start using it immediately.

English

Bluetooth connection method (3 devices connected)

(CH 1) Connecting to the first Bluetooth device
1. Select the first channel (CH 1) by toggling the mode switch dial (Blue LED blinking / ready to pair). 2. Activate the Bluetooth function on the device to be connected, and then select "actto(BT- Bare No. B307 or B309)". (Blue LED flights off)

(CH 2) Connecting to the second Bluetooth device
1. Select the second channel (CH 2) by toggling the mode switch dial (Blue LED blinking / ready to pair). 2. Activate the Bluetooth function on the device to be connected, and then select "actto(BT- Bare No. B307 or B309)". (Blue LED flights off)

(CH 3) Connecting to the third Bluetooth device
1. Select the third channel (CH 3) by toggling the mode switch dial (Blue LED blinking / ready to pair). 2. Activate the Bluetooth function on the device to be connected, and then select "actto(BT- Bare No. B307 or B309)". (Blue LED flights off)

If the LED remains illuminated on the corresponding channel once pairing has been completed, **Allow to expand** (You can re-pair your device with another device by pressing **Fn** + **F** button for approximately 3 seconds. Refer to the "How to reset Bluetooth pairing" section for the "mode switch dial" to change. (Automatic connection to devices registered to each channel).

Bluetooth connection method (Mac PC)

1. Click "System Preferences" > "Bluetooth" on your computer. 2. Click "Turn Bluetooth On."
3. The Bluetooth channel is selected by rotating the mode switch dial (CH 1 to 3). (Blue LED blinking / ready to pair)
4. Activate the Bluetooth function on the device to be connected, and then select "actto(BT- Bare No. B307 or B309)". (Blue LED flights off)

Bluetooth connection method (Windows 10 / 11)

Before using this product, make sure your computer is equipped with a built-in Bluetooth receiver. Some computers may not have a built-in Bluetooth receiver, so it is essential that you purchase and install a Bluetooth receiver after installation.

1. Bluetooth receivers appear in the taskbar of your Windows computer when they are connected to the computer. Click on the icon to open the Bluetooth settings menu. 2. Click "Add a Bluetooth device" or "Add device".
3. Select the type of device you want to search. (Select "Bluetooth"). 4. Rotate the mode switch dial to select the Bluetooth channel (CH 1 to 3). (Blue LED blinking / ready to pair). 5. Activate the Bluetooth function on the device to be connected, and then select "actto(BT- Bare No. B307 or B309)". (Blue LED flights off)

How to reset Bluetooth pairing

If it is possible to delete all device information connected to CH 1 to 3 by pressing and holding **Fn** + **E** for approximately 3 seconds.

Please delete the Bluetooth connection information from each existing connected devices. You must delete the pairing history without disabling the Bluetooth function.

① **Battery indicator** (Low voltage indication = Green LED blinks, Charging = Green LED on, When fully charged = Green LED off)
② **Caps Lock indicator** (Upon pressing the Caps Lock key, the LED turns on)
③ **Num Lock indicator** (Upon pressing the Num Lock key, the LED turns on)

The Num Lock feature is not supported on iOS devices, and the LED is not switched on.

14 function keys (11 hot keys)

System conversion

Ensure that the keyboard and the device to be connected are set to each other at all times.

- **Android** : Fn + E
- **Windows** : Fn + R
- **iOS, Mac** : Fn + L

Some keys may not work depending on the device and system. **If the OS connected to each device is different, please use the keyboard layout that matches the corresponding OS.**

Status Indicator LED



Fn
E
R
T
Y
U
I
O
P
A
S
D
F
G
H
J
K
L
Z
X
C
V
B
N
M
Q
W
E
R
T
Y
U
I
O
P
A
S
D
F
G
H
J
K
L
Z
X
C
V
B
N
M
Shift
Shift
Fn
Ctrl
Alt
Space
Alt
Ctrl
Fn
Shift
Shift
Enter
Backspace
Tab
Caps Lock
Esc
1 2 3 4 5 6 7 8 9 0 - =
~ ! @ # $ % ^ & * ( ) _ +
` 1 2 3 4 5 6 7 8 9 0 - =
Q W E R T Y U I O P [ ] \
A S D F G H J K L ; '
Z X C V B N M , . / ?
Z X C V B N M , . / ?
Q W E R T Y U I O P [ ] \
A S D F G H J K L ; '
Esc
F1 F2 F3 F4 F5 F6 F7 F8 F9 F10 F11 F12
F1 F2 F3 F4 F5 F6 F7 F8 F9 F10 F11 F12
Print Screen
Scroll Lock
Pause
Insert
Home
Page Up
Delete
End
Page Down
Insert
Home
Page Up
Delete
End
Page Down
Num Lock
/ * -
/ * -
7 8 9 +
7 8 9 +
4 5 6
4 5 6
1 2 3 Enter
1 2 3 Enter
0 .
0 .
Num Lock
Scroll Lock
Caps Lock
Shift
Ctrl
Alt
Alt
Ctrl
Shift
Fn
Fn