Installing a Smart 100/16/4 PCI Ringnode

Warnings

Always unscrew the Ringnode screws on your computer before installing or removing any adapters.

Third-party ringnode products might not be adapters's auto-detect. This means a Smart adapter will see a Smart ringnode as a Smart network (either 100Mbps, 16Mbps, or 4Mbps). You have to set the Smart adapter's setting, not the Ringnode's.

This adapter has no switches or jumpers. PCI computers configure PCI adapters automatically.

1. Read the [illegible] for the adapter.
2. Install the [illegible] software.
3. Install the adapter in a PCI slot. Connect the adapter to a ring using a Smart 16/4 UTP cable ring [illegible]. The Smart 100/16/4 PCI Ringnode does not support cable detection and will not detect the proper cabling. You must connect to the adapter.
4. Run the Smart Diagnostics program. [illegible]
5. Run the Smart Diagnostics program to test the adapter's connection to a ring. [illegible] (Tech Z Zone has the latest software for the Smart 100/16/4 PCI Ringnode and is the best place to find the most recent versions of the Smart adapter's software).
6. [illegible]