13.8cm

17.8cm

17.8cm

13 x 5.45 x 7 in

13.8cm

17.8cm

33cm

17.8cm

TURBO DRIFTER

RADIO CONTROLLED ACTION VEHICLE

BATTERY INSTALLATION

The car requires 4 "AA" 1.5V batteries (not included).The controller requires one 9V battery (not included). When changing batteries, adult supervision is required. Use alkaline batteries for the best performance.

NOTE: for best operation, operate car on a hard surface.

- Carefully remove items from the package.
- Locate the battery door on the bottom of the car. Using a Phillips screwdriver, remove the screw.
- Pull the tabs on the door to the left and lift up to access the battery compartment. Insert 4 "AA" batteries while observing the correct polarity (Fig1).
- Replace thebattery compartment door.
- Repeat presss on the back of the remote control x open battery door.
- Insert one 9" battery while observing the correct polarity (Fig.2).
- Replace thebattery compartment door.
- Switch both the car and controller power switchesto the "ON" position.

SAFETYPRECAUTIONS

- Do not operate during thunderstorms or rain.
- Avoid water,sand and snow when operating vehicle.
- Do not submerge vehicle or controller in water.
- Never operate vehicle on the street or highway.
- Adult supervision is recommended when operatingvehicle.
- Remove all batteries when not in use to avoid accidental operation.
- Never operate vehicle in a confined or crowded area, and do not use people or animals as obstacles.
- Do not run vehicle into furniture, objects or hard surfaces, as this will cause damage to both the objects and the vehicle.
- Keep fingers, hair and loose clothing away from th- tires, gears and motor while the vehicle is switched to "ON"
- Do not leavevehicle or controller near sources of hat or under direct sunlight for extended periods.
- Do not leavevehicle or controller outside overnight Dampness is harmful to interior components.

BATTERY WARNING!

- Use only fresh batteries of the required size and type.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Insert batteries with the correct polarity. Do not short-circuit the supply terminals.
- Remove exhausted batteries from the toy. Charge rechargeable batteries only under adult supervision.
- Remove rechargeable batteries before charging.
- Do not charge non-rechargeable batteries.
- Batteries must be inserted to the correct polarity.
- Exhausted batteries are to be removed from the toy.
- Do not charge exhausted batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Supply terminals are not to be short-circuited.
- The supply terminals are not to be used for charging.

KEEP THIS INSTRUCTION SHEET FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

TURN LEFT/TURN RIGHT

FORWARD / BACKWARD

POWER ON / OFF

2905107 D3459

Made in China

WARNING! Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

© 2021 Mad Dinosa LLC. In Mad Dinosa and all associated logos are trademarks of Mad Dinosa, LLC. All rights reserved.

Contained in Mad Dinosa LLC, Irvine, CA 92618.
Lot Made in China. Date Made in October.

The artwork and design of this package are protected by US copyright law and may not be reproduced, distributed, displayed, published or used for any purpose without prior written permission. You will be prosecuted to the fullest extent permitted by copyright and other laws for any infringement.

BLUE HAT

FULL FUNCTION REMOTE CONTROL

TWO FREQUENCIES FOR COMPETITIVE PLAY

- Drift Style Racing Action on Smooth Surfaces
- Available in Two Frequencies for Competitive Play
- Full Function Remote Control

EXCITING RC DRIFT RACING

BATTERY OPERATED PLAY VEHICLE

AGES 6+

MULTI-DIRECTIONAL OPERATION