FASCINATING DINOSAUR FACTS
Dinosaurs were the diversified advantaged terrestrial vertebrates living in the Mesozoic, and they once controlled the global terrestrial ecosystems over one hundred and sixty million years.
Dinosaurs New World
INTO ACTION WITH SOUND
The name Tyrannosaurus meant the vicious tyrant lizard. They were one of the largest flesh-eaters and the most famous predatory dinosaurs. As one of categories of the latest found dinosaurs, Tyrannosaurus owned the average body length of 13 meters with the longest one of 14.6 meters, the average hip height of 4 meters, the 5 to 5.6 meters distance between head and ground, and the highest height being more than 5 meters. They also had the strongest occlusal force among predatory dinosaurs for their 8 tons average weight and the heaviest one being 14.85 tons. They lived in the period between Maastrichtian Stage of upper Cretaceous (68.5 million years ago) and the latest phase of Cretaceous (65 million years ago), and were one of the dinosaur categories in the Cretaceous Tertiary extinguishment event. Their fossils spread over nations in North America like the US and Canada as well as other countries like Mexico, China and so on, with more wide spreading range than other tyrannosaurs. They were one of the latest extinguished dinosaurs which also including other dinosaurs like Carnotaurus and Tarbosaurus and so on.
The New World of Dinosaurs
"Grrrrr!"
HEAD SWING AND SOUND
WARNING:
CHOKING HAZARD–Small parts. Not for children under 3 years.
NO.9981
RUiCHENG
NO.9981
RADIO CONTROL
WALKING
HEAD SWING
DINOSAUR SOUND
LIGHTING
1.5V AA
USE 3 "1.5 AA" SIZE BATTERIES (INCLUDED)
FRIEND, LET'S EXPLORE THE DINOSAUR WORLD TOGETHER.
FRIENDS TO EXPERIENCE THE FUN OF DINOSAURS
INTO ACTION WITH SOUND
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions : (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help
The device must not be co-located or operating in conjunction with any other antenna or transmitter.
Function: Remote Control:
1.The left button controls the movement. Press the button one time, then the dinosaur will move forward, shake head and cry after 6 footsteps. It will stop after pressing the button once again. If you don't press the button to stop the dinosaur, it will keep moving forward with shaking head about 5 minutes then automatically stop. After the stop, if you do nothing, it will make a cry every 60 seconds with shaking head, then sleep, namely the entering power save model. Press the demonstration button to activate it.
2.Press the right button, the dinosaur will shake head and produce sound. After the sounds stop, press the button once again, it will make different dinosaur sounds.
3.Demonstration Button: Press this button, then the dinosaur will shake head and make sounds.
4.After turning on the electric dinosaur each time, you should press the demonstration button to activate the remote control function.
The New World of Dinosaurs TM
SPEC.
USE 3 "1.5 AA" SIZE BATTERIES (INCLUDED)
FORWARD
POWER INDICATOR
DEMONSTRATION
Tail Assembly:
Attach the tail until it "clicks."
On/Off Switch:
Toggle Switch on belly controls Walking action and sound.
Walking
Head swing and sound
Roaring t-rex sounds!
USE 2 "1.5 AA" SIZE BATTERIES (NOT INCLUDED)
SPECIFICATIONS COLOURS AND CONTENTS MAY VARY FROM ILLUSTRATIONS.
• NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED.
• ONLY BATTERIES OF THE SAME OR EQUIVALENT TYPE AS RECOMMENDED ARE TO BE USED.
• BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY.
• EXHAUSTED BATTERIES ARE TO BE REMOVED FROM THE TOY
• THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED.
• DO NOT USE RECHARGEABLE BATTERIES.
• DO NOT MIX OLD AND NEW BATTERIES.
• DO NOT MIX ALKALINE STANDARD (CARBON ZINC), OR RECHAR-GEABLE (NICKEL CADMIUM)BATTERIES.
NOT SUITABLE FOR CHILDREN UNDER 3 YEARS DUE TO SMALL PARTS
COUNTRY OF ORIGIN:CHINA
Tested according to international standards
PRECAUCIONES
ATENÇÃO:
ВНИМАНИЕ!
0-3
MADE IN CHINA