Remote Control Functions

⏻	(**POWER** button) Turns the TV on or standby.
HOME	Brings you back to the Home Page.
BACK	Returns to the previous display, or exits the application.
MENU	Shows or hides the TV options/menu/menu control.
OK	Displays the channel list in TV mode. Confirm your selection or enter the next screen.
⋀⋁	Change TV channels or external input mode. In menu system, move focus up or down.
⋖⋗	Adjust the TV volume level. In menu system, move focus left or right, or go to the previous / next Screen.
INPUT	Displays the the video input list.
EXIT	Exits the current display.
MUTE	Turns the volume on and off.
MOUSE	Turns the mouse function on .
GUIDE	Enter or exit the Primetime. When watching DTV channels, press GUIDE on remote control, EPG would pop up at the middle of screen. The button GUIDE is invalid when watching ATV channels. Press BACK on remote control, EPG would disappear.
VOICE	Enter Voice Search.
SEARCH	Enter typing Search.
YOUTUBE	Use the YouTube video-sharing website.
VUDU	Enter Vudu.
AMAZON	Enter Amazon.
INFO	If no menus are currently active, press **INFO** to display the Channel information.
SLEEP	Sets the TV to turn off after a given amount of time.
M-GO	Enter M-GO.
0-9	(Alphanumeric buttons) Enters a channel number, then press **OK** (or let the entry timeout). Or enters numbers in the input box.
•	(dot) To enter a digital channel with a sub-channel, enter the main channel; then, press the dot (•), the sub-channel, and then the **OK** button.
INPUT	Press **INPUT** repeatedly to select the video input
VOL+/-	Adjust the TV volume level.
CH+/-	Change TV channels or external input mode.
◀◀/▶▶/▶I /■	These buttons can be used for playing music, pictures and videos in the USB menu.