

FCC File Number: 0019-EX-PL-2006

Determination of Necessary Bandwidth

The determination of necessary bandwidth is based on Annex J of the NTIA Manual of Regulation & Procedures for Radio Frequency Management.

Where:

$$B(-20 \text{ dB}) = 6.36/t$$

B(-20dB) is the necessary bandwidth in MHz.

t is the pulse width in us.

All necessary bandwidth calculations were based on this method