

Range Networks QC1 experimental installation block diagram.

Operating procedures require that the power amplifier not be enabled until power levels and spectrum are verified at the output of the cavity filter and the input to the amplifier. Final output spectrum is verified again immediately after enabling the amplifier.

