

## Necessary Bandwidth

The necessary bandwidth is calculated by adding the carrier modulation of 167 MHz plus the tolerance on the transmitter frequency of 183 MHz for a total of 350 MHz.