

Step Three: Attach the body directly to the base and adjust it to a suitable angle to complete the installation.

Note: Set the network before installation is completed.

