

1.1 Set-up for Conducted RF test at Antenna Port

PCB in antenna port test



1.2 Set-up for Spurious Emissions below 1GHz

PCB



1.3 Set-up for Spurious Emissions above 1GHz

PCB



1.4 Set-up for Conducted Emissions

PCB

