

切线  
折线

版本	标注	ECO编号	变更日期	变更描述	设计者
V0	NA		2021.12.01	初版发行	Tamia

## FRONT

### QUICK START GUIDE

**WELCOME TO WYZE**

Hi! Thanks for getting your hands on a Wyze Lock Bolt. If this is your first Wyze product, welcome to the Wyze family! This guide will help you get things set up. In the app, you can also follow these steps and watch the video tutorial. For an easier installation, we recommend having a helping hand nearby.

**SETUP**

Download the Wyze app and sign in or create an account.

In the Wyze app, tap the + plus sign, then Add Device > Home > Wyze Lock Bolt. Follow the in-app installation and setup instructions to complete Wyze Lock Bolt setup.

**OVERVIEW**

Here's a look at the installation steps you'll go through in this guide:

- Remove the existing lock
- Install the Deadbolt and Strike Plate
- Install the Keypad Assembly
- Install the Mounting Plate
- Install the Interior Assembly

**IN THE BOX**

- Keypad Assembly
- Interior Assembly
- Mounting Plate
- Deadbolt
- Strike Plate
- Dust Box
- USB-C Charging Port
- AA Battery x 4
- Thumb Latch
- Strike Screws (M2.5) x 2
- Mounting Plate Screws x 1
- Interior Assembly Screws (M2.5) x 2
- Compartments
- Mounting Plate Screws (M2.5) x 2
- Fasteners

## BACK

**INSTALL THE MOUNTING PLATE**

1. Separate the mounting plate from the interior assembly. Route the cable through the mounting plate hole as shown. Then install the mounting plate on the interior-facing side of the door.

2. Using the screws provided (labeled "13"), tighten the mounting plate and ensure the mounting plate and keypad assembly are aligned properly.

Tip: Have a friend hold the keypad assembly against the door so it doesn't move around during this step. You can also use a Rolpin to make sure the screws labeled "13" are aligned with the corresponding holes on the keypad assembly.

3. If the plate or assembly is loose, loosen the screws, adjust the position as needed, then re-tighten the screws.

**INSTALL THE INTERIOR ASSEMBLY**

4. Remove the battery cover from the interior assembly. You should see a sticker at the bottom of the battery cover. Remove your thumbs there to pop it out. You may remove the sticker when done.

5. Connect the cable wires into the back of the interior assembly. The side with a mark on it faces up. You can also check if the red/orange wires are on the right.

**IMPORTANT!**  
Make sure the connector is properly plugged in.

6. Rotate the thumb latch to make sure the latch retracts normally.

7. Using the screws provided (labeled "15"), install the interior assembly to the mounting plate.

**CHECK THE INSTALLATION**

- Insert the batteries provided. Don't put in the cover yet. We do that once setup is done in the app.
- Check if the interior assembly is secure and aligned properly.
- Check if the keypad assembly is secure and aligned properly.

材质：金东太空梭105G无光铜纸  
表面处理：无

SCALE 1:1  
SHEET 1/1

备注：  
1. 印刷色：Black  
2. 装订方式：折页  
3. 符合云丁科技《有害物质管理标准》

SELECT	TOL.	A	B	C	V	EPS	EPE	EPP	BAG	CTN	LABEL
0~6		0.05	0.05	0.10							0.20
6~30		0.10	0.15	0.20	0.50	0.50	0.50	3.00			0.20
30~120		0.15	0.20	0.30	0.50	0.50	0.50	5.00	2.00		0.25
120~300		0.20	0.30	0.40	1.00	1.00	1.00	10.00	3.00		0.30
300~450		0.25	0.40	0.50	2.00	2.00	2.00	15.00	5.00		0.50
450~600		0.30	0.50	0.60	3.00	3.00	3.00	20.00	5.00		0.80
DRAFT TOLERANCE				± 0.20°				CRITICAL DIM. MARK		*	

物料名称：说明书		产品名称		料号		设计		核准	
Bolt		0524087002		雷艳芬		周树温			