

www.pivotalcommware.com Pivotal Commware, Inc. (425) 365-0408

HOW TO SET UP

YOUR

PIVOTAL

ECHO 5G[™]

erizon Wireless authorizes the use of this device Verizon Wireless network only




Scan to read the Pivotal Echo 5G[™] Installation Manual

To contact Support: ne: 1-855-956-2016

Email: support@pivotalcon 1mware.com are.freshdesk.com/support/ho

WARNING. This is not a CONSUMER device. This device may not be sold at retail. You MUST have an FCC LICENSE or express onsent of an FCC Licensee (or express consent of your service provider) to operate this device. Antennas must be installed at least 20 cm (8 inches) from any person. Unauthorized use may result in significant forfeiture penalties, including penalties in excess of \$100,000 for each continuing violation



Remove the adhesive from the Velcro on the pre-attached spacer ring on the IDU and press to the glass in the circle of the alignment cling.

Apply force and hold for 30 seconds.

Plug the Echo 5G IDU into your wall outlet. Blue and green LED lights on the IDU will appear and blink before going solid. If the green light blinks for more than 30 seconds, consult the Troubleshooting Help on the back of this page.






d) Then press 'Go' on the next page.

e) When the LED on the inside of the ODU (facing indoors) turns a solid green, your Echo 5G commissioning is complete!

Troubleshooting Help

What the lights indicate



ODN not powered or is not detecting <u>.</u> How to tell if the IDU



- - Green light indicator DC power to the IDU **(**(1-
- Blinking green: probing for an ODU
- Solid green: IDU is powering the ODU
- 30 secs, the spacer needs to be removed or IDU needs If the length of the blinking green LED is longer than repositioning



How to tell if the ODU is receiving a weak signal



Removal Instructions



Slide the end of the removal tool under the rails, starting at the bottom.



Work your way up the rails from the bottom or side.



When you have loosened the adhesive enough you can carefully remove it by hand.



Use WD40 and the rough side of a sponge to clean any remaining adhesive off your window.