



C30-C32 should be placed near by ball out position and same side of the chips

50 Ohm impedance for BT trace

26MHz crystal

26MHz crystal must be placed near by AB1565 ball out position

Approved by	Checked by	Designer	AMPACS CORPORATION	
Eddie		Boyce	Project Number RIG800proAB_HX_TX	
			Size Custom	Title AB1565_RF
			Date: Friday, February 25, 2022	Rev A
			Sheet 4 of 4	