



**Flom Test Lab**  
EMI, EMC, RF Testing Experts Since 1963

toll-free: ( 866 ) 311-3268

fax: ( 480 ) 926-3598

[www.flomlabs.com](http://www.flomlabs.com)

[info@flomlabs.com](mailto:info@flomlabs.com)

**Answers to RT dated 2/5/09  
Met 81408**

**1. The FRN listed on Form 731 is not the one listed on the FCC website for Kenwood.**  
The form 731 has been revised to reflect the correct FRN.

**2. It appears only spurious emissions were performed for the one channel. Please provide measurements for the other two channels as well.**

The spurious emissions for the low, mid, and high channels have been retested and the report has been edited.

**3. The final RF power amplifier has changed and therefore the emissions mask and occupied bandwidth needs to be measured and recorded.**

The emissions masks have been plotted and the report has been edited to include this data.