

NOTE: ADD 3000 TO ALL REFERENCE DESIGNATORS.

NOTES:

- UNLESS NOTED, SOLDER ALL FENCES TO P.C. BOARD AT THE MOUNTING TABS ONLY. SOLDER TABS ON ITEM 2 INTO SLOTS OF ITEM 7, 6 PLACES.
- TRIM ALL LEADS AND FENCE MOUNTING TABS TO NOT MORE THAN .030" BELOW THE FARSIDE SURFACE.
- PRINTED CIRCUIT ASSEMBLY IDENTIFICATION MUST BE IN ACCORDANCE WITH SPEC. 001-01101-0000.
- LIQUID STAKE ALL FASTENERS PER SPEC. 001-01080-0000.
- ITEM 13 IS ATTACHED TO THE TOP OF COM PRESELECTOR COVER (ITEM 8). AND NAV VCO COVER (ITEM 6).
- POSITION COM PRESELECTOR COVER (ITEM 8) TO MINIMIZE OVERHANG ON THE EDGE OF THE BOARD.
- MOUNT L15 VERTICALLY WITH INSULATING SLEEVING (ITEM 15) OVER EXPOSED LEAD. FIX POSITION OF L15 WITH RTV 016-01071-0000.
- GROUND MTG6 WITH COPPER TAPE 016-01134-0002 .05" X .150" TYP. SOLDER TO MTG6 AND TO GROUND PLANE.
- MOUNT R328 ON TOP OF C101.
- SECURE CR34 AND R327 WITH RTV 016-01071-0000.





