



Product Label

3. Assemble the right cover with left cover.
4. Fasten 3 screws!
5. Stick 2 rubber feet.
6. Stick the product label.

UNIT NO.	001	002	003	004	005	006	007	008	009	010
DATE	01/10	01/10	01/10	01/10	01/10	01/10	01/10	01/10	01/10	01/10
TIME	08:00	08:00	08:00	08:00	08:00	08:00	08:00	08:00	08:00	08:00
OPERATOR	001	002	003	004	005	006	007	008	009	010
NO.	001	002	003	004	005	006	007	008	009	010

SEE NOTES		SEE NOTES		DATE	FOXCANN HON HAI PRECISION IND. CO., LTD. CNSBG	
PART NO.		MODEL		REV	DESIGNED	
NVG468MQ FA		U62L050.00		A3	RASON	
PART NAME		CUSTOMER MODEL		CUSTOMER PART NO.		APPROVED
		NVG468MQ				TIM