

12 Attach the serial number (510-00015-001) of the ST-654 unit on the Enclosure as shown.

NOTE: Make sure to record the serial number of the ST-654 TAG unit and mate with the two CCA boards (Serial/Power and Main) inside for Tracability purpose.



13 Attached the Savi Model number (735-00086-901) on the Enclosure as shown.

Align the left side of the label to the left edge of the indent wall.



10 Apply Savi Logo label (735-00085-901) on the unit as shown.



11	<p>Apply the Caution label (735-00012-001) on the unit as shown.</p> <p>Align the right side of the label to the right edge of the indent wall.</p>	
12	<p>Apply FCC ID label (P/N 735-00095-906) on the bottom side of the tag as shown.</p>	