



<p>6 Attach the serial number (510-00015-001) of the ST-673 unit on the Enclosure as shown.</p> <p>Apply Savi Logo label (P/N 735-00085-902) on top of the serial number as shown</p> <p><b>NOTE: Make sure to record the serial number of the ST-673-030 TAG unit and mate with the three CCA boards (Serial/Power,Main board and Sensor board) inside for Tracability purpose.</b></p>	
<p>7 Apply the Caution label (735-00012-001) on the unit as shown.</p> <p>Align the right side of the label to the right edge of the indent wall.</p> <p>Apply the Model number label (P/N 735-00086-904) next to the caution label.</p> <p><b>Do not leave any space between the labels</b></p>	
<p>8 Attach Gasket (730-05114-002) into the round recess of the back in the Base Plate after ultrasonic welding process.</p> <p>Apply FCC ID label as shown.</p>	