





STEP 3:

(B)

PLACE THE BOTTOM COVER AGAINST THE TOP COVER ENSURING THAT THE THREE SNAP ARE LOCKING SECURELY BETWEEN THE PARTS.