



- ▲ 2 REMOVE EXISTING RF CABLE AND REPLACE WITH ITEM 3, PDE-5 PWA AND MOUNTING HARDWARE, ITEMS 5 THRU SEE VIEW A-A, PAGE 2.
- ▲ 3 APPLY FCC LABEL, ITEM 4 OVER THE EXISTING FCC LABEL.
- ▲ 4 REMOVE EXISTING CONNECTOR & ANTENNA AND REPLACE WITH ITEMS 11 & 12, AS SHOWN.
- 5 SOLDER IAW J-STD-001, CLASS 2, USING ITEM 10.

