1.1 LABEL INSERTION

Insert Barcode Label (#22) into label recess as shown in figure 25. Press label into place. Adhere CE Label (#23) to housing, positioning as shown in figure 25. Press label into place.

Figure 25