

TEST SETUP PHOTOS

For Part 22/Part 24 & RSS 132/RSS 133

Occupied Bandwidth, Modulation Characteristic, Conducted Power Measurement, Spurious Emission At Antenna Terminals (+/- 1MHz),
Conducted Spurious Emission Measurement Setup



Frequency Stability Under Temperature & Voltage Variations Setup



ERP Test, Radiated Spurious Measurement(30MHz to 1GHz) Setup



Radiated Spurious Measurement (Above 1GHz), EIRP Test Setup

