

Preliminary User's Manual

1. You should have Windows 98 installed on your computer
2. Run HIDVIEW v 3.0
3. Removed and reinsert the USB Device
4. The Program should recognize available USB device
5. Run **“get data from device”**
6. Run **“continuous”**
7. Place transponder on mousepad