Preliminary User's Manual

1.   You should have Windows 98 installed on your computer

2.   Run HIDVIEW v 3.0

3.   Removed and reinsert the USB Device

4.   The Program should recognize available USB device

5.   Run **"get data from device"**

6.   Run **"continuous"**

7.   Place transponder on mousepad