

5. With the side latches folded outwards, place the PRC-4090 transceiver on top of the SDS so that the locating feet meet their corresponding holes.



6. Fold the side latches back into position and turn the fasteners to secure.

