

**Imation Corp.**  
**Model: Travan FW-20GB Drive**  
**Installation Instructions**

## **1. Getting Started**

Thank you for purchasing the Imation Travan™ FireWire 20GB Drive. Designed for digital video editors, this drive is ideal for archiving and backing up your “in-process” and completed video projects. The FireWire interface is compatible with the Macintosh™ G4, PowerBook, and iMac DV.

Your new tape drive is a powerful, state-of-the-art tool that allows for rapid storage and backup for up to 20 gigabytes of data.

**You can use your new tape drive to perform all of the following:**

- Backup and restore in-process and completed video projects as well as other important files and folders.

- Create space by archiving files on your hard drive or network.

- Protect private information by removing secure information from the network or personal hard drives and backing up on tape.

**Make sure the following items are included in your box:**

- Imation Travan FireWire 20GB Drive

- AC power adapter

- Power supply cord

- FireWire cable

- Travan NS20 cartridge

- Installation CD-ROM (containing Dantz Retrospect™ backup software and this guide)

- Quick Start and warranty card

### **Macintosh™ Requirements:**

- Macintosh OS 9.x or later with built-in FireWire port

- 64MB of RAM

- 32MB of available hard disk space

## 2. Installation

1. Insert the CD-ROM provided with the drive into your Macintosh™.
2. Double-click on the Dantz Retrospect CD-ROM when it appears on your desktop.
3. Double-click on the Install Retrospect icon, then follow the prompts to load the Dantz Retrospect software.

**Note:** Refer to the *Dantz Retrospect User Guide* PDF located on the CD-ROM for information regarding the software.

4. Connect the power supply cord into the wall outlet.

**Note:** Two FireWire ports are available on the drive. It does not matter which FireWire port you connect to on the drive. The second port is available to daisy-chain other devices.

5. Connect the AC power adapter to the Travan™ FireWire Drive.
6. Connect the Travan FireWire interface cable to the FireWire ports on the drive and the Macintosh™.

Your Travan FireWire drive is now ready for use.