


## ALL KEY FOBs MUST BE PRESENT AND REPROGRAMMED WHEN PROGRAMMING NEW FOBs

### Programming Instructions:

- 1) Turn vehicle ignition key to ON position, without starting engine (Key-On Engine-Off - Position "1").
- 2) Insert Programmer into OBD / DLC port  - located under steering column, near pedals.
- 3) A **Chime sounds for 1 second** Indicating programming mode is active.
- 4) Press the LOCK & UNLOCK buttons on the Key-Fob simultaneously for 5 seconds. Press the UNLOCK button for 2 seconds.
- 5) Repeat step 4 for all additional remotes.
- 6) When all Key fobs have been programmed, turn ignition key off and remove programmer from the OBD / DLC port.
- 7) Wait 2 minutes and verify each Key fob functions properly. If programming was unsuccessful, restart the procedure.

## FCC WARNING

Statement 15.19(a)(3): This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by Dorman Products Inc. could void the user's authority to operate the equipment.

## IC WARNING

This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

FVIN: 6313778IC

## **ALL KEY FOBS MUST BE PRESENT AND REPROGRAMMED WHEN PROGRAMMING NEW FOBS**

Cet appareil est conforme aux CNR exempts de licence d'Industrie Canada. Son fonctionnement est soumis aux deux conditions suivantes:

- (1) Ce dispositif ne peut causer des interférences; et
- (2) Ce dispositif doit accepter toute interférence, y compris les interférences qui peuvent entraîner un mauvais fonctionnement de l'appareil.

FVIN: 6313778IC