


## ALL KEY FOBS MUST BE PRESENT AND REPROGRAMMED WHEN PROGRAMMING NEW FOBS

### Programming Instructions:

- 1) Turn vehicle ignition key to ON position, without starting engine (Key-On Engine-Off - Position "1").
- 2) Insert Programmer into OBD / DLC port (  - located under steering column, near pedals).
- 3) A **Chime sounds for 1 second** Indicating programming mode is active.
- 4) Press the LOCK & UNLOCK buttons on the Key-Fob simultaneously for 5 seconds. Press the UNLOCK button for 2 seconds.
- 5) Repeat step 4 for all additional remotes.
- 6) When all Key fobs have been programmed, turn ignition key off and remove programmer from the OBD / DLC port.
- 7) Verify each Key fob functions properly. If programming was unsuccessful, restart the procedure.

## FCC WARNING

Statement 15.19(a)(3): This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by Dorman Products Inc. could void the user's authority to operate the equipment.

## IC WARNING

The term IC before the Certification/Registration number only signifies that the Industry Canada technical specifications were met. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

FVIN: 6313777IC