

DORM43

Comment	Designertor	Footprint	Quantity
8. 2pF	C2	0603	1
100pF	C1	0603	1
100nF	C3	0603	1
2. 2uF	C4	0603	1
100nH	L1, L2	0603	2
SI4010	U1	SOP-20	1
1. 7	SW1, SW2	SW4	2
2. 0	SW3, SW4	SW4	2
CR2032	BAT1		1