



Cease Operation Test Set-Up

(although the photo shown is labeled "Occupied BW", the setup for Cease Operation is identical and this picture is representative for this investigation.)



Radiated Emissions Test Set-Up – 30-1000MHz





Radiated Emissions Test Set-Up -1-5GHz



Radiated Emissions Test Set-Up -1-5GHz