

Operational Description

1. Insert the enclosed AAA Type Alkaline Battery (1.5V * 2) into the battery holder at the back of transmitter, and make sure the poles are in the right direction.

2. Insert a receiver into USB port.

3. X-Pointer II is installed automatically and works right after it is inserted into USB port.

(Windows 98 CD might be required along with the use of USB port.)

4. If the receiver receiving the signal from the transmitter, the receiver demodulate the signal and then send that to USB HUB.