

Hardware, Tools, and Fasteners Required

The Altai 2.4 GHz 5 dBi Omni antenna does not come with a mounting installation kit. AX500-X requires two 2.4 GHz Omni antennas.

Wrenches will be needed to install the antenna.

Installation Process

The following sections contains the procedures for installing the antenna on an AX500-X.

1. Attach the antennas to the 2.4 GHz N-connectors of the AX500-X. Torque the N-connectors to 0.9 +/- 0.15 nm.

